

**SPARE PARTS FOR
COMMERCIAL VEHICLES**

BERGISISCHE ACHSEN

we keep your business
ON THE MOVE



www.augerautotechnik.de

Auger
GERMANY

Auger Nr.	OEM Nr.	Description	Model	Picture
31145	03.106.77.04.0	Brake Drum		
31146	03.106.77.52.0 03.109.77.72.0	Brake Drum	H Series (SN 42..) H..LL Series (SN 42..) H (M)..L Series (SN 42..)	
31147	03.106.67.62.0 03.109.67.13.0 03.109.67.82.0	Brake Drum	H Series (SN 42..) H..LL Series (SN 42..) H (M)..L Series (SN 42..)	
31148	03.109.90.24.0 03.105.90.04.0	Brake Drum	K..LL Series (SN 36..) K..L Series (SN 36..) K Series (SN 36..)	
31149	03.109.67.74.0 03.106.67.54.0	Brake Drum	H Series (SN 42..) H..LL Series (SN 42..) H (M)..L Series (SN 42..)	
31150	03.109.90.22.0 03.105.90.02.0	Brake Drum	K..LL Series (SN 36..) K..L Series (SN 36..) K Series (SN 36..)	
31151	03.105.46.29.0 03.109.46.49.0	Brake Drum	N Series (SN 30..) N..LL Series (SN 30..) N..L Series (SN 30..)	

Auger Nr.	OEM Nr.	Description	Model	Picture
31152	03.105.46.20.0 03.109.46.40.0	Brake Drum	N Series (SN 30..) N..LL Series (SN 30..) N..L Series (SN 30..)	
31153	03.109.67.19.0	Brake Drum	H Series (SN 42..) H..LL Series (SN 42..) H (M)..L Series (SN 42..)	
31154	03.109.77.17.0	Brake Drum	H Series (SN 42..) H..LL Series (SN 42..) H (M)..L Series (SN 42..)	
31155	03.106.77.53.0	Brake Drum	H Series (SN 42..)	
31156	03.106.77.59.0	Brake Drum	H Series (SN 42..)	
31157	03.109.46.06.0	Brake Drum	N Series (SN 30..) N..LL Series (SN 30..) N..L Series (SN 30..)	
31158	03.109.77.18.0	Brake Drum	H Series (SN 42..) H..LL Series (SN 42..) H (M)..L Series (SN 42..)	

Auger Nr.	OEM Nr.	Description	Model	Picture
31159	03.109.77.16.0 03.109.77.77.0 03.106.77.57.0 03.106.77.28.0	Brake Drum	H Series (SN 42..) H..LL Series (SN 42..) H (M)..L Series (SN 42..)	
31160	03.105.90.05.0	Brake Drum Ø360/Ø230/277x8/221	K Series (SN 36..)	
31161	03.106.77.56.0	Brake Drum Ø420/Ø291/307x6/245	H Series (SN 42..) H..LL Series (SN 42..) H (M)..L Series (SN 42..)	
31163	03.106.77.63.0 03.106.77.45.0	Brake Drum	H Series (SN 42..)	
31164	03.106.77.61.0	Brake Drum	H Series (SN 42..) H..LL Series (SN 42..) H (M)..L Series (SN 42..)	
31165	03.106.77.55.0	Brake Drum	H Series (SN 42..) H..LL Series (SN 42..) H(M)..L Series (SN 42..)	 Sample
31166	03.106.67.56.0	Brake Drum		

Auger Nr.	OEM Nr.	Description	Model	Picture
31167	03.105.36.12.0	Brake Drum	N Series (SN 30..) N..LL Series (SN 30..)	
31168	03.109.67.27.0	Brake Drum	H Series (SN 42..) H..LL Series (SN 42..) H (M)..L Series (SN 42..)	 Sample
65426	05.091.27.83.0 05.091.27.79.0 S	Brake Shoe, Brake Drum, Unlined ø410x200mm		
65529	05.091.27.54.2 S	Brake Shoe, Brake Drum, Unlined, without Roller ø420x200mm		
66578	05.090.26.06.2	Brake Shoe, Brake Drum, Unlined ø420x180mm		
75440	05.091.46.17.0 S	Brake Shoe, Brake Drum Unlined, Thick 8mm, Without Roller ø410x180	H Series (SN 42..) H..LL Series (SN 42..) H (M)..L Series (SN 42..)	
52321	03.084.46.23.0	Pin, Brake Shoe ø36x145	H Series (SN 42..)	
52325	03.084.46.22.0	Pin, Brake Shoe ø36x135	H Series (SN 42..) K Series (SN 36..) H..LL Series (SN 42..) K..LL Series (SN 36..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	

Auger Nr.	OEM Nr.	Description	Model	Picture
53511	03.084.46.30.0	Pin, Brake Shoe ø36x145	N Series (SN 30..)	
52330	03.084.55.11.0	Pin, Brake Shoe ø22/ø25x77	EH Series	
52769	03.084.75.24.0	Pin, Brake Shoe ø26x58,5	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
52327	03.084.46.04.0	Pin, Brake Shoe ø36x157		
53189	03.084.46.05.0	Pin, Brake Shoe ø36x147		
53507	03.084.66.15.0	Pin, Brake Shoe ø36x121,5	EH Series	
52324	03.177.23.10.0 03.177.23.10.1	Pin, Brake Shoe M20x1,5/ø28/ø31,6x153	N Series (SN 30..) N..L Series (SN 30..)	
52322	03.112.33.08.0	Bushing, Brake Shoe ø36xø40x59	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	

Auger Nr.	OEM Nr.	Description	Model	Picture
52323	03.112.33.04.0	Bushing, Brake Shoe ø36xø40x28		
52333	03.112.22.24.0 03.112.22.30.0 03.112.22.07.0 03.112.22.21.0	Bushing, Brake Shoe ø32xø36x54	N Series (SN 30..) N..LL Series (SN 30..) N..L Series (SN 30..)	
52328	03.331.34.05.0	Roller, Brake Shoe ø26/ø36,75xø42x78	H Series (SN 42..) K Series (SN 36..) H..LL Series (SN 42..) K..LL Series (SN 36..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
52331	03.331.34.02.0	Roller, Brake Shoe ø32/ø36,75xø42x78	EH Series	
52332	03.331.34.01.0	Roller, Brake Shoe ø22xø42x59	N Series (SN 30..) N..LL Series (SN 30..) N..L Series (SN 30..)	
52329	03.200.34.02.0	Roller, Brake Shoe ø25,7xø35/ø42x51	EH Series	
52770	05.331.44.02.0	Roller, Brake Shoe ø26,2xø45x33,5	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
52142	03.188.02.02.0	Lock Plate, Brake Shoe 33x9,5	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	

Auger Nr.	OEM Nr.	Description	Model	Picture
52326	03.167.23.02.0	Lock Plate, Brake Shoe 52x58x15	H Series (SN 42..) K Series (SN 36..) H..LL Series (SN 42..) K..LL Series (SN 36..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
53512	03.167.24.01.0	Lock Plate, Brake Shoe 47x86x27,5	N Series (SN 30..)	
53515	03.167.23.09.0	Lock Plate, Brake Shoe 52x55,5x23	H Series (SN 42..) K Series (SN 36..) H..LL Series (SN 42..) K..LL Series (SN 36..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
52296	05.397.45.10.0 03.397.45.10.0	Spring, Brake Shoe ø21,5x106	K Series (SN 36..)	
52300	03.397.34.01.0	Spring, Brake Shoe ø20,5x100		
52313	03.397.44.06.0	Spring, Brake Shoe ø21x105	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
53516	03.397.44.10.0	Spring, Brake Shoe ø21x119	K Series (SN 36..)	
53506	03.397.34.10.0 03.397.34.11.0	Spring, Brake Shoe ø21x178		








Auger Nr.	OEM Nr.	Description	Model	Picture
52301	05.397.46.07.0	Spring, Brake Shoe	H Series (SN 42..)	
	05.397.46.06.0		H..LL Series (SN 42..)	
	05.397.45.01.0	ø25x260	H (M) ..L Series (SN 42..)	
52311	05.397.45.05.0	Spring, Brake Shoe		
	05.397.45.04.0	ø22x155		
52312	05.397.46.12.0	Spring, Brake Shoe	N Series (SN 30..)	
		24x166		
52314	05.397.56.07.0	Spring, Brake Shoe	H Series (SN 42..)	
	05.397.56.04.0			
	05.397.57.03.0	ø25x269		
52761	05.397.34.17.0	Spring, Brake Shoe	N Series (SN 30..)	
		ø20x180		
52762	05.397.35.03.0	Spring, Brake Shoe	N Series (SN 30..)	
	05.397.35.01.0	ø22,5x163	N..LL Series (SN 30..) N..L Series (SN 30..)	
52763	05.397.46.13.0	Spring, Brake Shoe	K Series (SN 36..)	
		ø24,5x235	K..LL Series (SN 36..) K..L Series (SN 36..)	
52764	05.397.45.14.0	Spring, Brake Shoe	K Series (SN 36..)	
	05.397.35.02.0		K..LL Series (SN 36..)	
	05.397.46.09.0	ø23,5x216	K..L Series (SN 36..)	

Auger Nr.	OEM Nr.	Description	Model	Picture
52766	05.397.58.03.0	Spring, Brake Shoe ø35x274	H Series (SN 42..) H..LL Series (SN 42..) H (M)..L Series (SN 42..)	
54002	05.397.34.16.0	Spring, Brake Shoe ø20x167	N Series (SN 30..)	
52767	05.397.46.03.0	Spring, Brake Shoe ø24,5x263		
54001	03.397.35.05.0	Spring, Brake Shoe ø20x220		
52758	03.397.33.07.0	Spring, Brake Shoe ø19x120	H Series (SN 42..) K Series (SN 36..) H..LL Series (SN 42..) K..LL Series (SN 36..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
52759	03.397.33.06.0	Spring, Brake Shoe ø19x115	H Series (SN 42..) K Series (SN 36..) H..LL Series (SN 42..) K..LL Series (SN 36..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
53513	03.397.33.08.0	Spring, Brake Shoe ø18,5x134	N Series (SN 30..)	
53514	03.397.33.09.0	Spring, Brake Shoe ø18,5x128	N Series (SN 30..)	

Auger Nr.	OEM Nr.	Description	Model	Picture
52308	03.084.52.08.0	Spring Pin, Brake Shoe ø12x52,5		
52306	03.001.08.03.0 03.084.52.28.0	Spring Pin, Brake Shoe ø12x70	N Series (SN 30..) N..LL Series (SN 30..) N..L Series (SN 30..)	
52305	03.084.52.06.0	Spring Pin, Brake Shoe ø14x100		
52768	03.001.08.05.0 03.001.08.01.0 03.084.42.01.0	Spring Pin, Brake Shoe ø12x90	H Series (SN 42..) N Series (SN 30..) H..LL Series (SN 42..) H (M)..L Series (SN 42..)	
52307	03.084.42.02.0	Spring Pin, Brake Shoe ø12x120	N Series (SN 30..) N..LL Series (SN 30..) N..L Series (SN 30..)	
52304	03.084.42.05.0	Spring Pin, Brake Shoe ø12x125	KH ../ KR ..	
52309	03.084.52.21.0	Spring Pin, Brake Shoe ø14x126		
53520	09.084.66.02.0	Repair Kit, Brake Shoe ø36x121,5		

Auger Nr.	OEM Nr.	Description	Model	Picture
52350	09.084.46.11.0	Repair Kit, Brake Shoe ø36x157		
52355	09.084.46.12.0	Repair Kit, Brake Shoe ø36x147		
52348	09.177.23.09.0	Repair Kit, Brake Shoe M20x1,5/ø28x153	N Series (SN 30..) N..L Series (SN 30..)	
53525	09.084.46.39.0	Repair Kit, Brake Shoe ø36x145	N Series (SN 30..)	
52342	09.084.46.35.0	Repair Kit, Brake Shoe ø36x145	H Series (SN 42..)	
52343	09.084.46.36.0	Repair Kit, Brake Shoe ø36x135	H Series (SN 42..) K Series (SN 36..) H..LL Series (SN 42..) K..LL Series (SN 36..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
52349	05.331.84.01.0	Repair Kit, Brake Shoe ø25xø42x51/77	EH Series	
52352	09.801.02.91.0	Repair Kit, Brake Shoe ø26xø45x33,5/58,5	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) K..LL Series (SN 36..) K..L Series (SN 36..)	

Auger Nr.	OEM Nr.	Description	Model	Picture
52335	09.801.02.09.0 S	Repair Kit, Brake Shoe ø32/ø36,75/ø42x78		
52336	09.801.02.11.0 S	Repair Kit, Brake Shoe ø22/ø42x59	H Series (SN 42..) N ..LL Series (SN 30..) N ..L Series (SN 30..)	
52337	09.801.02.10.0 S	Repair Kit, Brake Shoe ø26/ø36,75/ø42x78	H Series (SN 42..) K Series (SN 36..) H..LL Series (SN 42..) K..LL Series (SN 36..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
52339	09.801.02.12.0 S	Repair Kit, Brake Shoe ø22/ø42x59	N Series (SN 30..)	
52356	09.801.02.10.0	Repair Kit, Brake Shoe ø26/ø36,75xø42x78	H Series (SN 42..) K Series (SN 36..) H..LL Series (SN 42..) K..LL Series (SN 36..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
52341	09.801.02.12.0	Repair Kit, Brake Shoe ø22xø42x59	N Series (SN 30..)	
52503	09.801.02.09.0	Repair Kit, Brake Shoe ø26/ø36,75xø42x78		

Auger Nr.	OEM Nr.	Description	Model	Picture
52338	09.801.02.11.0	Repair Kit, Brake Shoe ø22xø42x59	H Series (SN 42..) N ..LL Series (SN 30..) N ..L Series (SN 30..)	
53539	09.801.02.44.0	Repair Kit, Brake Shoe	H Series (SN 42..) H..LL Series (SN 42..) H (M)..L Series (SN 42..)	
52351	09.801.02.01.0	Repair Kit, Brake Shoe	H / R Series	
52346	09.801.02.03.0	Repair Kit, Brake Shoe		
52345	09.801.02.02.0	Repair Kit, Brake Shoe	H / R Series	
52347	09.801.02.04.0	Repair Kit, Brake Shoe		
53528	09.801.02.47.0	Repair Kit, Brake Shoe	N Series (SN 30..)	








Auger Nr.	OEM Nr.	Description	Model	Picture
53529	09.801.02.45.0	Repair Kit, Brake Shoe	K Series (SN 36..) K..LL Series (SN 36..) K..L Series (SN 36..)	
53543	09.801.02.46.0	Repair Kit, Brake Shoe	K Series (SN 36..)	
52773	05.801.52.72.0	Repair Kit, Brake Shoe	H Series (SN 42..) K Series (SN 36..) H..LL Series (SN 42..) K..LL Series (SN 36..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
70855	-	Repair Kit, Brake Shoe		
71370	-	Repair Kit, Brake Shoe		
71449	-	Repair Kit, Brake Shoe ø26/ø36,75/ø42x78	H Series (SN 42..) H..LL Series (SN 42..) H (M) ..L Series (SN 42..)	
75543	09.801.06.79.0	Repair Kit, Brake Shoe	H Series (SN 42..) H..LL Series (SN 42..) H (M)..L Series (SN 42..)	

Auger Nr.	OEM Nr.	Description	Model	Picture
52139	03.229.02.18.0	Retainer, Brake Cam Shaft ø10/ø90xø61,5x20	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..)	
52141	03.229.02.16.1	Retainer, Brake Cam Shaft ø10/ø90xø61,5x22,5	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..)	
52138	03.229.02.16.0	Retainer, Brake Cam Shaft ø10/ø90xø61,5x23	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..)	
52133	03.229.02.10.0	Retainer, Brake Cam Shaft ø10/ø90xø59,6x21,5	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..)	
52140	03.229.02.19.0	Retainer, Brake Cam Shaft ø10/ø90xø61,5x20,5	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..)	
52137	03.229.02.17.0	Retainer, Brake Cam Shaft ø10/ø90xø61,5x23	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..)	
52136	03.229.02.09.0	Retainer, Brake Cam Shaft ø10/ø90xø59,6x21,5	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..)	

Auger Nr.	OEM Nr.	Description	Model	Picture
52134	03.229.02.01.0	Retainer, Brake Cam Shaft ø8,5/ø90xø59,6x17	EH Series	
52135	03.229.02.03.0	Retainer, Brake Cam Shaft ø8,5/ø90xø59,6x17	EH Series	
52143	03.113.14.01.0	Spherical Bearing, Brake Cam Shaft ø42xø59,6x37	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..)	
52144	03.113.14.03.0	Spherical Bearing, Brake Cam Shaft ø42,25xø61,5x38	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..)	
54919	05.377.00.02.0	Spherical Bearing, Brake Cam Shaft ø42xø61,5x38		
52150	03.112.44.34.0 03.112.44.30.0	Bushing, Brake Cam Shaft ø42xø46x72,5	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) H (M)..L Series (SN 42..) K..L Series (SN 36..) N..L Series (SN 30..)	
52145	03.120.63.01.0 03.120.43.09.0	Dust Cover, Brake Cam Shaft ø39,5x25	NH, NR Series	
52146	03.120.43.10.0	Dust Cover, Brake Cam Shaft ø34x25,5	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..)	

Auger Nr.	OEM Nr.	Description	Model	Picture
52147	03.120.43.14.0	Dust Cover, Brake Cam Shaft ø41x24,5	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..)	
52148	03.120.43.12.0	Dust Cover, Brake Cam Shaft ø41x20	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..)	
75351	03.285.55.21.0	Bracket, Brake Cam Shaft ø9xø90/ø72,5	H Series (SN 42..)	
52162	09.801.00.14.0	Repair Kit, Brake Cam Shaft		
52163	09.801.00.14.1	Repair Kit, Brake Cam Shaft		
52159	09.801.00.24.2	Repair Kit, Brake Cam Shaft	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..)	
53524	09.801.00.43.1	Repair Kit, Brake Cam Shaft ø41x24,5	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..)	
52164	09.801.00.14.2	Repair Kit, Brake Cam Shaft ø39,5x25	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..)	

Auger Nr.	OEM Nr.	Description	Model	Picture
52165	09.801.00.43.0	Repair Kit, Brake Cam Shaft ø41x24,5		
52161	09.801.00.37.0	Repair Kit, Brake Cam Shaft		
52344	-	Repair Kit, Brake Cam Shaft		
52154	03.112.44.30.0 S	Repair Kit, Brake Cam Shaft ø42xø46x72,5 <i>Spherical Bearing: 52143</i> <i>Bushing: 52150</i> <i>Retainer: 52134-52135</i> <i>Dust Cover: 52145</i>	K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..) N..L Series (SN 30..)	
68131	09.801.02.13.1	Repair Kit, Brake Cam Shaft ø42xø46x72,5		
52152	-	Repair Kit, Brake Cam Shaft ø42xø46x72,5 <i>Spherical Bearing: 52143</i> <i>Bushing: 52150</i> <i>Retainer: 52133-52136</i> <i>Dust Cover: 52145</i>		
52155	09.801.02.15.0	Repair Kit, Brake Cam Shaft ø42xø59,6x37	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..)	

Auger Nr.	OEM Nr.	Description	Model	Picture
52166	09.801.02.16.0	Repair Kit, Brake Cam Shaft ø42xø59,6x37	EH.. / ER.. Series	
52153	-	Repair Kit, Brake Cam Shaft ø42xø46x72,5		
52157	-	Repair Kit, Brake Cam Shaft ø42xø46x72,5		
52160	09.801.02.13.0 09.801.02.14.0	Repair Kit, Brake Cam Shaft ø42xø46x72,5	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..)	
52715	09.801.06.09.0	Repair Kit, Brake Cam Shaft ø42xø46x72,5		
52156	09.801.06.09.0 S	Repair Kit, Brake Cam Shaft ø42xø46x72,5 <i>Bushing : 52150</i> <i>Retainer : 52139 - 52140</i> <i>Dust Cover : 52147</i>		
52158	09.801.02.22.0	Repair Kit, Brake Cam Shaft ø42xø46x72,5	H / KH Series	

Auger Nr.	OEM Nr.	Description	Model	Picture
52353	09.801.02.23.0	Repair Kit, Brake Cam Shaft ø42xø46x72,5	NH / NR Series	
53203	09.801.06.09.1	Repair Kit, Brake Cam Shaft ø42xø46x72,5	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..)	
75528	09.801.02.15.1	Repair Kit, Brake Cam Shaft ø42	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..)	
75865	05.865.00.02.0	Repair Kit, Brake Cam Shaft	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..)	
57891	05.174.54.70.0	Brake Slack Adjuster Right, Manuel		
57879	05.174.90.20.0	Brake Slack Adjuster Right, Automatic ø14x145 / S-ABA / Double Bent		

Auger Nr.	OEM Nr.	Description	Model	Picture
57890	05.174.54.69.0	Brake Slack Adjuster Left, Manuel		
57826	05.174.96.63.0	Brake Slack Adjuster Left, Automatic ø14x145x144° / Double Bent		
58015	05.174.90.19.0	Brake Slack Adjuster Automatic ø16x165/140x30° / Double Bent		
57806	05.174.52.34.0	Brake Slack Adjuster Manuel		
58151	05.174.52.61.0	Brake Slack Adjuster Manuel	H Series (SN 42..) K Series (SN 36..)	
58150	05.174.65.22.0	Brake Slack Adjuster Manuel	H Series (SN 42..) K Series (SN 36..)	
58149	05.574.82.87.3 05.174.82.39.2	Brake Slack Adjuster Automatic ø14x250/180/165/150/135/ 120 / S-ABA / Saddle Type		

Auger Nr.	OEM Nr.	Description	Model	Picture
58147	05.174.82.26.2	Brake Slack Adjuster	K Series (SN 36..)	
	05.174.82.09.1	Automatic		
	05.174.82.09.2	ø14x250/180/165/150/135/		
	05.174.82.26.0	120x150° / Bent		
58142	05.574.82.43.2	Brake Slack Adjuster	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..)	
	05.174.82.02.2	Automatic		
	05.174.82.21.2	ø14x250/180/165/150/135/		
	05.574.82.02.1	120x50° / Saddle Type		
58145	05.174.82.31.2	Brake Slack Adjuster	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..)	
	05.174.82.14.0	Automatic		
	05.174.82.14.2	ø14x250/180/165/150/135/		
	05.174.82.24.2	120x110° / Saddle Type		
58152	05.174.65.13.0	Brake Slack Adjuster Manuel	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..)	
52310	05.397.28.01.0	Spring, Brake Slack Adjuster	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..) N..L Series (SN 30..)	
		29,5x120,6		
52760	05.397.26.03.0	Spring, Brake Slack Adjuster	H / H..LL / H (M)..L Series (SN42..) K / K..LL / K..L Series (SN 36..) N / N..LL / N..L Series (SN 30..)	
	05.397.27.01.0			
	05.397.36.05.0	ø25,5x146		
52780	05.397.26.05.0	Spring, Brake Slack Adjuster	H / H..LL / H (M)..L Series (SN42..) K / K..LL / K..L Series (SN 36..) N / N..LL / N..L Series (SN 30..)	
		ø22,5x180		

Auger Nr.	OEM Nr.	Description	Model	Picture
52765	05.397.26.02.0	Spring, Brake Slack Adjuster ø22,5x233	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) K..L Series (SN 36..) N..L Series (SN 30..)	
31004	03.088.34.06.0 03.088.34.02.0 03.088.34.06.7	Brake Disc	SKH Series (SB 3745) SKH..LL Series (SB 3745)	
31005	03.088.34.04.7 03.088.34.04.0	Brake Disc	SKH Series (SB 3745) SKH..LL Series (SN SB 3745)	
31006	03.088.34.01.7 03.088.34.01.0	Brake Disc	SKH Series (SB 3745) SKH..LL Series (SN SB 3745)	
31007	03.088.34.03.7 03.088.34.03.0	Brake Disc	SKH Series (SB 3745) SKH..LL Series (SN SB 3745)	
31008	03.088.35.01.0	Brake Disc	SH Series (SB 4345)	
31009	03.088.35.05.7 03.088.35.05.0 03.088.35.03.0	Brake Disc Ø430/Ø335x10/160x45	SH Series (SB 4345) SH..LL Series (SB 4309 / SB 4345)	

Auger Nr.	OEM Nr.	Description	Model	Picture
31144	03.088.34.10.0 03.088.34.10.7	Brake Disc	SKH..LL Series (SN SB 3745) SKH Series (SB 3745)	
31162	03.088.34.08.0	Brake Disc	SKH Series (SB 3745) SKH..LL Series (SB 3745)	
56065	09.801.06.34.0	Repair Kit, Brake Caliper	SKH Series (SB 3745) SKH..LL Series (SB 3745) SH Series (SB 4345) SH..LL Series (SB 4309 / SB 4345)	
56066	09.801.06.11.0	Repair Kit, Brake Caliper	SKH Series (SB 3745) SKH..LL Series (SB 3745) SH Series (SB 4345) SH..LL Series (SB 4309 / SB 4345)	
54167	09.801.06.32.0	Repair Kit, Brake Caliper, Knorr Type	SH Series (SB 4345) SKH Series (SB 3745) SKH..LL Series (SB 3745) SH..LL Series (SB 4309 / SB 4345)	
54168	09.801.02.63.0	Repair Kit, Brake Caliper, Knorr Type	SH Series (SB 4345) SKH Series (SB 3745) SKH..LL Series (SB 3745) SH..LL Series (SB 4309 / SB 4345)	
56063	09.801.06.24.0	Repair Kit, Brake Caliper	SKH Series (SB 3745) SKH..LL Series (SB 3745)	

Auger Nr.	OEM Nr.	Description	Model	Picture
56064	09.801.06.31.0	Repair Kit, Brake Caliper	SKH Series (SB 3745) SKH..LL Series (SB 3745) SH Series (SB 4345) SH..LL Series (SB 4309 / SB 4345)	
54069	09.801.06.33.0	Repair Kit, Brake Caliper, Knorr Type	SH Series (SB 4345) SKH Series (SB 3745) SKH..LL Series (SB 3745) SH..LL Series (SB 4309 / SB 4345)	
70656	09.801.07.62.0	Repair Kit, Brake Caliper		
70657	09.801.07.61.0	Repair Kit, Brake Caliper		
70658	09.801.07.63.0	Repair Kit, Brake Caliper		
70659	05.006.03.45.1	Repair Kit, Brake Caliper		
53509	03.010.91.58.0	Brake Dust Cover ø406x79	SKH..LL Series (SN SB 3745)	

Auger Nr.	OEM Nr.	Description	Model	Picture
53510	03.010.91.59.0	Brake Dust Cover ø406x79	SKH..LL Series (SN SB 3745)	
55505	03.010.91.53.0	Brake Dust Cover ø406x79	SKH Series (SB 3745)	
53521	09.801.06.19.0	Brake Dust Cover Kit	SKH..LL Series (SB 3745)	
57029	09.801.06.38.0	Brake Dust Cover Kit	SKH Series (SB 3745) SKH..LL Series (SB 3745)	
53551	09.801.06.40.0	Brake Dust Cover Kit	SH Series (SB 4345) SH..LL Series (SB 4309/SB 4345)	
53552	09.801.06.41.0	Brake Dust Cover Kit	SH Series (SB 4345) SH..LL Series (SB 4309/ SB 4345)	
68132	09.801.07.30.0	Brake Dust Cover Kit ø404x43		

Auger Nr.	OEM Nr.	Description	Model	Picture
68133	09.801.06.42.0	Brake Dust Cover Kit ø450x45	SH Series (SB 4345) SH..LL Series (SB 4309 / SB 4345)	
68134	09.801.06.49.0	Brake Dust Cover Kit ø400x43	SKH Series (SB 3745)	
68128	09.801.06.39.0	Brake Dust Cover Kit ø400x53	SKH Series (SB 3745) SKH..LL Series (SB 3745)	
68129	09.801.07.31.0	Brake Dust Cover Kit ø455x44	SH..LL Series (SB 4309 / SB 4345)	
68127	09.801.06.18.1	Brake Dust Cover Kit ø458x77	SH Series (SB 4345) SH..LL Series (SB 4309 / SB 4345)	
57028	09.801.06.17.0 09.801.06.17.1	Brake Dust Cover Kit ø458x79,5	SH Series (SB 4345)	
57027	09.801.06.16.0	Brake Dust Cover Kit ø406x79	SKH Series (SB 3745)	

Auger Nr.	OEM Nr.	Description	Model	Picture
52183	99.00.000.0.93	Brake Dust Cover Kit 121xø447x53	H Series (SN 42..)	
52184	99.00.000.0.71	Brake Dust Cover Kit 124/129xø447x21	H Series (SN 42..)	
52185	99.00.000.0.88	Brake Dust Cover Kit 121xø447x21	H Series (SN 42..)	
52186	99.00.000.0.80	Brake Dust Cover Kit 154,5/158xø447x22	H Series (SN 42..)	
52187	99.00.000.0.73	Brake Dust Cover Kit 154,5/158xø447x31	H Series (SN 42..)	
52188	99.00.000.0.40	Brake Dust Cover Kit ø193,5xø470x36	EH Series	
52189	99.00.000.0.85	Brake Dust Cover Kit ø131xø447x31	H Series (SN 42..)	

Auger Nr.	OEM Nr.	Description	Model	Picture
52190	99.00.000.0.75	Brake Dust Cover Kit 124/128xø447x31	H Series (SN 42..)	
52191	99.00.000.0.42	Brake Dust Cover Kit ø160xø470x33	EH Series	
52192	99.00.000.0.95	Brake Dust Cover Kit 153xø447x52,5	H Series (SN 42..)	
52193	99.00.000.0.76	Brake Dust Cover Kit 154/158,5xø447x31	H Series (SN 42..)	
52194	99.00.000.0.72	Brake Dust Cover Kit ø131xø447x22	H Series (SN 42..)	
52195	99.00.000.0.70	Brake Dust Cover Kit 124/128xø447x33	H Series (SN 42..)	
52196	99.00.000.1.31 99.00.000.0.97	Brake Dust Cover Kit 121/123xø447x63	H Series (SN 42..)	

Auger Nr.	OEM Nr.	Description	Model	Picture
52197	99.00.000.0.89	Brake Dust Cover Kit 121xø447x31	H Series (SN 42..)	
52198	99.00.000.0.94	Brake Dust Cover Kit ø130xø447x52,5	H Series (SN 42..)	
52199	99.00.000.0.87	Brake Dust Cover Kit 121xø447x35	H Series (SN 42..)	
52200	99.00.000.0.98	Brake Dust Cover Kit 152xø447x63	H Series (SN 42..)	
52340	99.00.000.0.37	Brake Dust Cover Kit ø192,5xø455x35	EH Series	
52354	99.00.000.0.84	Brake Dust Cover Kit ø131,5xø334x28	N Series (SN 30..)	
53031	99.00.000.0.81	Brake Dust Cover Kit ø131,5xø392x28	K Series (SN 36..)	

Auger Nr.	OEM Nr.	Description	Model	Picture
53032	99.00.000.1.06	Brake Dust Cover Kit 121xø390x65	K Series (SN 36..)	
53033	99.00.000.0.83	Brake Dust Cover Kit 124/128xø392x28	K Series (SN 36..)	
53530	99.00.000.1.01	Brake Dust Cover Kit ø131xø334x5,5	N Series (SN 30..)	
53531	99.00.000.1.09	Brake Dust Cover Kit 121xø331x65,5	N Series (SN 30..)	
53532	99.00.000.1.02	Brake Dust Cover Kit 121xø334x5,5	N Series (SN 30..)	
53533	99.00.000.1.00	Brake Dust Cover Kit ø135xø334x28	N Series (SN 30..)	
53534	99.00.000.1.08	Brake Dust Cover Kit ø89xø392x28	K Series (SN 36..)	

Auger Nr.	OEM Nr.	Description	Model	Picture
53535	99.00.000.1.03	Brake Dust Cover Kit ø131xø334x11	N Series (SN 30..)	
53536	99.00.000.1.05	Brake Dust Cover Kit 121xø334x28	N Series (SN 30..)	
57040	99.00.000.1.07	Brake Dust Cover Kit 121xø447x53	H Series (SN 42..)	
53540	03.010.99.69.0 S 03.010.99.71.0 S	Brake Dust Cover Kit ø130xø447x63	H Series (SN 42..)	
53547	03.010.96.62.0 S 03.010.96.63.0 S	Brake Dust Cover Kit ø142,5xø392x28	K..L Series (SN 36..)	
53548	03.010.98.63.0 S 03.010.98.64.0 S	Brake Dust Cover Kit 148/208,5xø447x32	H (M)..L Series (SN 42..)	
57039	99.00.000.0.99	Brake Dust Cover Kit ø447x33	H..LL Series (SN 42..)	

Auger Nr.	OEM Nr.	Description	Model	Picture
70655	05.801.51.52.0	Brake Dust Cover Kit		
71396	99.00.000.1.26	Brake Dust Cover Kit 150/155xø447x64		
71845	99.00.000.1.23	Brake Dust Cover Kit 124xø447x56		
75792	99.00.000.1.24	Brake Dust Cover Kit 150/155xø447x52,5	H Series (SN 42..)	
75793	99.00.000.1.25	Brake Dust Cover Kit 121/124xø447x64	H Series (SN 42..)	
75794	99.00.000.1.27	Brake Dust Cover Kit 121/123xø447x64	H Series (SN 42..)	
75795	99.00.000.1.30	Brake Dust Cover Kit 153/156xø447x52,5	H Series (SN 42..)	

Auger Nr.	OEM Nr.	Description	Model	Picture
75796	09.801.07.51.0	Brake Dust Cover Kit	BPW ECO Disc TSB 3709	
75797	09.801.07.52.0	Brake Dust Cover Kit	BPW ECO Disc TSB 4309	
75798	09.801.07.53.0	Brake Dust Cover Kit	BPW ECO Disc TSB 4312	
21004	-	Service Brake Chamber, for Disc Brake M16/120,7x97,5/140,5x164 T16 STR 57		
21005	05.444.32.01.0 05.444.32.02.0 02.0327.70.00 02.0327.71.00	Service Brake Chamber, for Disc Brake, With Repair Kit M16/120,7x97,5/140,5x164 T16 STR 57		
21006	-	Service Brake Chamber, for Disc Brake M16/120,7x105/164x174 T20 STR 64		
21007	05.444.34.01.0 05.444.34.02.0 02.0327.74.00 02.0327.75.00	Service Brake Chamber, for Disc Brake, With Repair Kit M16/120,7x105/164x174 T20 STR 64		

Auger Nr.	OEM Nr.	Description	Model	Picture
21008	-	Service Brake Chamber, for Disc Brake M16/120,7x103/160x186 T24 STR 64		
21009	05.444.36.01.0 05.444.36.02.0 02.0327.78.00 02.0327.79.00	Service Brake Chamber, for Disc Brake, With Repair Kit M16/120,7x103/160x186 T24 STR 64		
21010	10.309.60.10.6	Service Brake Chamber, for Drum Brake M16/120,7x112,5/297,5x164 T16 STR 75		
21011	05.444.13.01.0 02.0327.27.00	Service Brake Chamber, for Drum Brake, With Repair Kit M16/120,7x112,5/339,5x164 T16 STR 75		
21012	10.309.60.15.0	Service Brake Chamber, for Drum Brake, M16/120,7x113/298x174 T20 STR 75		
21013	05.444.14.01.0 02.0327.32.00 02.0336.20.00	Service Brake Chamber, for Drum Brake, With Repair Kit M16/120,7x113/340x174 T20 STR 75		
21014	-	Service Brake Chamber, for Drum Brake M16/120,7x112,5/297,5x186 T24 STR 75		

Auger Nr.	OEM Nr.	Description	Model	Picture
21016	-	Service Brake Chamber, for Drum Brake		
		M16/120,7x117,5/302,5x208		
		T30 STR 75		
21017	05.444.16.01.0 02.0327.29.00 05.444.16.10.0 05.444.16.11.0	Service Brake Chamber, for Drum Brake, With Repair Kit		
		M16/120,7x117,5/344,5x208		
		T30 STR 75		
21018	-	Double Diaphragm Brake Chamber, for Drum Brake		
		M16/120,7x274,5/459,5x208		
		T24-30 STR 75/75		
21020	-	Double Diaphragm Brake Chamber, for Drum Brake		
		M16/120,7x271,5/456,5x208		
		T30-30 STR 75/75		
21021	05.444.21.01.0 05.444.21.04.0 05.444.21.11.0	Double Diaphragm Brake Chamber, for Drum Brake, With Repair Kit		
		M16/120,7x271,5/498,5x208		
		T30-30 STR 75/75		
21000	-	Double Diaphragm Brake Chamber, for Disc Brake		
		M16/120,7x236/380x186		
		T16-24 STR 57/57		

Auger Nr.	OEM Nr.	Description	Model	Picture
21001	05.444.40.01.0	Double Diaphragm Brake Chamber, for Disc Brake, With Repair Kit M16/120,7x236/380x186 T16-24 STR 57/57		
21002	-	Double Diaphragm Brake Chamber, for Disc Brake M16/120,7x252/396x186 T20-24 STR 64/64		
21003	05.444.44.01.0	Double Diaphragm Brake Chamber, for Disc Brake, With Repair Kit M16/120,7x252/396x186 T20-24 STR 64/64		
75352	03.182.34.77.0	Bracket, Brake Chamber	H Series (SN 42..)	 
71932	02.3317.01.00 02.3317.05.00	Sensor, ABS	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..) N..L Series (SN 30..)	 
74966	02.3317.07.00	Sensor, ABS L: 350 mm	SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) SH..LL Series (SB 4309 / SB 4345) SKH..LL Series (SN SB 3745)	 

Auger Nr.	OEM Nr.	Description	Model	Picture
55579	03.189.14.61.0	Bracket, ABS ø18/ø9x39	H SERIES (SN42..) K SERIES (SN36..) SH SERIES (SB4345) SKH SERIES (SB3745)	
55580	03.189.07.58.0	Bracket, ABS ø18/ø8x32x38	H SERIES (SN42..) K SERIES (SN36..) SH SERIES (SB4345) SKH SERIES (SB3745) H..LL SERIES (SN42..) H(M)..L SERIES (SN42..) SH..LL SERIES	
55853	03.310.08.51.0	Ring, ABS ø125xø156/ø165,75x8,8	K Series (SN 36..) SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) SKH..LL Series (SB 3745)	
70648	03.310.08.18.0	Ring, ABS ø152xø170x15	K Series (SN 36..) N Series (SN 30..) K..LL Series (SN 36..) N..LL Series (SN 30..) K..L Series (SN 36..)	

Auger Nr.	OEM Nr.	Description	Model	Picture
-----------	---------	-------------	-------	---------

Diaphragms - Normal Stroke

Auger Nr.: 52576

OEM Nr. —

Type 9"

Auger Nr.: 52578

OEM Nr. —

Type 12"

Auger Nr.: 52580

OEM Nr. —

Type 16"

Auger Nr.: 52581

OEM Nr. —

Type 20"

Auger Nr.: 52582

OEM Nr. —

Type 24"

Auger Nr.: 52583

OEM Nr. —

Type 30"

Auger Nr.: 52584

OEM Nr. —

Type 36"



Diaphragms - Long Stroke

Auger Nr.: 52585

OEM Nr. —

Type 16"

Auger Nr.: 52586

OEM Nr. —

Type 20"

Auger Nr.: 52587

OEM Nr. —

Type 24"

Auger Nr.: 52588









OEM Nr. —

Type 30"



Auger Nr.	OEM Nr.	Description	Model	Picture
52103	05.113.90.06.0	Rubber Bushing, Spring ø24xø50x68	Trailing Arm (width 100 mm)	
52104	05.113.93.03.0	Rubber Bushing, Spring ø36xø65,5xø68		
52105	02.0316.06.00	Rubber Bushing, Spring ø30xø60x102	Trailing Arm (width 100 mm)	
52106	05.113.98.08.0	Rubber Bushing, Spring ø40xø84x130		
52108	02.0316.65.00 02.0316.05.00	Rubber Bushing, Spring ø50xø100,5x130	VB-K, VB-C Series	
52110	05.113.97.10.0	Rubber Bushing, Spring ø60xø105x145		
52118	02.0316.90.00	Rubber Bushing, Spring ø30xø57x102	Trailing Arm (width 100 mm)	
53947	02.0315.98.00	Rubber Bushing, Spring ø30xø60x72	Trailing Arm (width 70 mm)	

Auger Nr.	OEM Nr.	Description	Model	Picture
68413	02.0314.24.00	Rubber Bushing, Spring ø24xø60x72		
52167	03.181.90.10.0	Mounting, Spring ø25/59x90x25		
52168	03.181.90.06.0 03.181.90.06.1 03.181.90.02.0	Mounting, Spring 112x158x64		
52169	03.181.90.05.0 03.181.90.01.0	Mounting, Spring ø24x69/74x110		
54042	03.340.15.20.0 03.340.15.27.0 03.340.15.10.0 03.340.15.08.0	Bolt, Spring 190/M30x3,5		
54041	03.340.15.23.0	Bolt, Spring 210/M30x3,5	Trailing Arm (width 100 mm)	
54033	03.340.15.37.0	Bolt, Spring 260/M30x3,5	Trailing Arm (width 100 mm)	
54026	03.341.05.05.0	Bolt, Spring 173/M30x3,5	Trailing Arm (width 70 mm) (Airlight II)	

Auger Nr.	OEM Nr.	Description	Model	Picture
54028	03.341.05.04.0	Bolt, Spring 202/M30x3,5	Trailing Arm (width 100 mm)	
54025	03.341.05.03.0	Bolt, Spring 202/M30x3,5	Trailing Arm (width 100 mm)	
54030	03.177.16.28.0	Bolt, Spring 230/M42x3		
54027	03.177.16.25.0	Bolt, Spring 232/M42x3		
54031	03.177.16.29.0	Bolt, Spring 242,5/M42x3		
54051	02.5220.81.26 02.5220.81.82 03.260.15.01.0	Nut, Spring, Self-Locking M30x3,5	Trailing Arm (width 100 mm)	
54056	02.5220.91.26	Nut, Spring M42x3		
54059	02.5207.46.04	Nut, Spring M42x3		

Auger Nr.	OEM Nr.	Description	Model	Picture
54917	03.181.20.08.0	Bushing, Spring ø30,5x50/59x20,5	Trailing Arm (width 100 mm)	
53965	03.113.23.01.0	Bushing, Spring 30,3/42,5xø73,7x24	Trailing Arm (width 100 mm) Trailing Arm (width 70 mm) (Airlight II)	
53508	03.113.01.34.0	Bushing, Spring ø30,5xø56x29	Trailing Arm (width 100 mm)	
68115	03.113.01.46.0	Bushing, Spring ø30,5xø73,5x24		
52318	03.113.01.14.0	Bushing, Spring ø30,3xø57,7x35		
52320	03.113.02.04.0	Bushing, Spring ø32,3xø57,7x35		
52334	03.113.02.06.0	Bushing, Spring ø30,3xø54,7x24	Trailing Arm (width 100 mm)	
52317	03.200.34.05.0	Bushing, Spring ø30,3xø49,7x29,5	VB - C VBT- C	

Auger Nr.	OEM Nr.	Description	Model	Picture
52315	03.113.02.05.0	Bushing, Spring ø32,3xø57,7x30		
52316	03.113.01.15.0	Bushing, Spring ø30,3xø57,7x30		
52319	03.200.34.03.0	Bushing, Spring ø30,3xø49,7x43,5	VBT-C	
70642	03.113.03.10.0	Bushing, Spring, Metal 24,5/36,5xø67,5x22		
75529	03.113.00.50.1	Bushing, Spring, Metal 24,5/36,2xø90/ø55x20	Trailing arm (width 70 mm)	
75530	03.113.01.43.1	Bushing, Spring, Metal 30,2/42,3xø90/ø55x20	Trailing arm (width 70 mm)	
74115	05.032.21.18.0	Bracket, Spring, Right	For Disc Brake BPW SB 3745 For Disc Brake BPW SB 4345 For Disc Brake BPW SB 4309 Trailing arm (width 70 mm) (AirlightII)	
74116	05.032.21.19.0	Bracket, Spring, Left	For Disc Brake BPW SB 3745 For Disc Brake BPW SB 4345 For Disc Brake BPW SB 4309 Trailing arm (width 70 mm) (AirlightII)	

Auger Nr.	OEM Nr.	Description	Model	Picture
70643	03.345.23.02.1	Bracket, Spring 42x122x44	Trailing Arm (width 100 mm)	
70646	03.032.21.58.0	Bracket, Spring 180x241x61,5		
54920	05.189.13.19.0	Bracket, Spring ø50,5x155x184,5	Trailing Arm (width 100 mm)	
54835	03.281.54.14.0	Washer, Spring 31x72x103,5x8	Trailing Arm (width 100 mm)	
54836	03.281.54.18.0	Washer, Spring 31x57,5x103,5x8	Trailing Arm (width 100 mm)	
54837	03.164.35.01.0	Washer, Spring ø30x121/125x11,5	Trailing Arm (width 100 mm)	
54838	03.164.35.02.0	Washer, Spring ø30x121/125x14,5	Trailing Arm (width 100 mm)	
53522	05.857.00.04.0	Repair Kit, Spring M30x3,5/210	Trailing Arm (width 100 mm)	

Auger Nr.	OEM Nr.	Description	Model	Picture
53553	05.857.00.03.0	Repair Kit, Spring M30x3,5/190	Trailing Arm (width 100 mm)	
53538	03.341.05.05.0 S	Repair Kit, Spring M30x3,5/173	Trailing Arm (width 70 mm) (Airlight II)	
53523	05.857.00.12.0	Repair Kit, Spring M30x3,5/202	Trailing Arm (width 100 mm)	
53549	03.177.16.28.0 S	Repair Kit, Spring M42x3/ø60x230,5		
53550	03.177.16.29.0 S	Repair Kit, Spring M42x3/ø60x242,5		
53542	02.0316.65.00 S 02.0316.05.00 S	Repair Kit, Spring ø50xø100,5x130	"VB-K, VB-C Series"	
57045	05.857.00.24.0	Repair Kit, Spring M30x3,5/202		

Auger Nr.	OEM Nr.	Description	Model	Picture
53546	05.857.00.18.0	Repair Kit, Spring M30x3,5/173	Trailing Arm (width 70 mm) (Airlight II)	
53545	05.857.00.15.0	Repair Kit, Spring M30x3,5/202	Trailing Arm (width 100 mm)	
53537	05.857.00.09.0	Repair Kit, Spring M30x3,5/202	Trailing Arm (width 100 mm)	
53526	09.801.06.28.0	Repair Kit, Spring ø30xø57x102	Trailing Arm (width 100 mm)	
53527	09.801.06.29.0	Repair Kit, Spring ø30xø60x102	Trailing Arm (width 100 mm)	
57042	09.801.06.92.0	Repair Kit, Spring ø30xø57x102		
68126	09.801.07.02.0	Repair Kit, Spring ø30xø57x102		

Auger Nr.	OEM Nr.	Description	Model	Picture
68130	09.801.07.03.0	Repair Kit, Spring ø30xø57x102		
57041	09.801.06.87.0	Repair Kit, Spring ø30xø57x102		
53544	09.801.06.77.0	Repair Kit, Spring ø30xø57x102	Trailing Arm (width 100 mm)	
70651	05.857.00.16.0	Repair Kit, Spring	Trailing Arm (width 100 mm)	
70652	05.857.00.13.0	Repair Kit, Spring	Trailing Arm (width 100 mm)	
70653	05.857.00.20.0	Repair Kit, Spring	Trailing Arm (width 70 mm) (Airlight II)	
70654	05.857.00.21.0	Repair Kit, Spring		

Auger Nr.	OEM Nr.	Description	Model	Picture
72152	02.0316.90.00 S	Repair Kit, Spring ø30xø57x102	Trailing Arm (width 100 mm)	 NEW
75531	09.801.07.75.0	Repair Kit, Spring ø30xø57x102	Trailing arm (width 100 mm)	 NEW
75532	09.801.07.77.0	Repair Kit, Spring M30x3,5/265	Trailing arm (width 100 mm)	 NEW
75533	09.801.07.76.0	Repair Kit, Spring ø30xø57x102	Trailing arm (width 100 mm)	 NEW
75534	09.801.07.78.0	Repair Kit, Spring M30x3,5/265	Trailing arm (width 100 mm)	 NEW
75535	09.801.07.79.0	Repair Kit, Spring ø24xø60x72	Trailing arm (width 70 mm) (Airlight II)	 NEW
75536	09.801.07.80.0	Repair Kit, Spring ø30xø60x72	Trailing arm (width 70 mm) (Airlight II)	 NEW







Auger Nr.	OEM Nr.	Description	Model	Picture
75537	09.801.07.81.0	Repair Kit, Spring ø24xø60x72	Trailing arm (width 70 mm) (Airlight II)	
75538	09.801.07.82.0	Repair Kit, Spring ø30xø60x72	Trailing Arm (width 70 mm) (Airlight II)	
75539	09.801.07.83.0	Repair Kit, Spring ø30xø60x72	Trailing Arm (width 70 mm) (Airlight II)	
75540	09.801.07.84.0	Repair Kit, Spring ø24xø60x72	Trailing arm (width 70 mm) (Airlight II)	
75541	05.857.00.28.0	Repair Kit, Spring M24x2/168	Trailing arm (width 70 mm) (Airlight II)	
75542	05.857.00.06.0	Repair Kit, Spring M30x3,5/210	Trailing arm (width 100 mm)	
68406	03.140.16.01.0	Bearing, Spring 119.5x150x263		
68407	03.140.14.01.0	Bearing, Spring 89x152x260		

Auger Nr.	OEM Nr.	Description	Model	Picture
65645	03.138.44.15.4	U Bolt, Spring		
	03.138.44.15.3	M24x3/125x324		
	03.138.44.15.0			
65646	03.138.41.05.4	U Bolt, Spring		
	03.138.41.05.0	M24x3/152x351		
69074	03.138.42.01.4	U Bolt, Spring		
	03.138.42.01.0	M24x3/192x419		
69075	03.138.45.03.4	U Bolt, Spring		
	03.138.45.03.0	M24x3/180x403		
69076	03.138.45.06.4	U Bolt, Spring		
	03.138.45.06.0	M24x3/180x384		
69077	03.138.45.07.4	U Bolt, Spring		
	03.138.45.07.0	M24x3/180x365		
69078	03.138.45.08.4	U Bolt, Spring		
	03.138.45.08.0	M24x3/180x356		
69079	03.138.41.29.4	U Bolt, Spring		
	03.138.41.03.0	M24x3/152x418		

Auger Nr.	OEM Nr.	Description	Model	Picture
69080	03.138.41.06.4	U Bolt, Spring		
	03.138.41.06.0	M24x3/152x368		
69081	03.138.41.08.4	U Bolt, Spring		
		M24x3/152x324		
69082	03.138.41.13.4	U Bolt, Spring		
	03.138.41.13.0	M24x3/152x304		
69083	03.138.41.17.4	U Bolt, Spring		
	03.138.41.17.0	M24x3/152x293		
69084	03.138.41.09.4	U Bolt, Spring		
	03.138.41.09.0	M24x3/149x362		
69085	03.138.41.11.4	U Bolt, Spring		
		M24x3/151x314		
69086	03.138.41.14.4	U Bolt, Spring		
		M24x3/151x294		
69087	03.138.44.11.4	U Bolt, Spring		
	03.138.44.11.0	M24x3/126x430		

Auger Nr.	OEM Nr.	Description	Model	Picture
69088	03.138.44.01.4	U Bolt, Spring		
	03.138.44.01.3	M24x3/125x359		
	03.138.44.01.2			
69089	03.138.44.09.4	U Bolt, Spring		
	03.138.44.09.3	M24x3/125x314		
	03.138.44.09.0			
69090	03.138.61.02.0	U Bolt, Spring		
		M36x4/290x654		
69091	03.138.61.01.0	U Bolt, Spring		
		M36x4/290x618		
72061	03.138.44.08.0	U Bolt, Spring		
	03.138.44.08.3	M24x3/125x280		
	03.138.44.08.4			
72062	03.138.44.04.1	U Bolt, Spring		
		M24x3/125x306		
65643	03.138.44.18.4	U Bolt, Spring		
	03.138.44.18.3	M24x3/125x343		
	03.138.44.18.0			
65644	03.138.44.04.4	U Bolt, Spring		
	03.138.44.04.3	M24x3/125x306		

Auger Nr.	OEM Nr.	Description	Model	Picture
A 34644	02.2002.44.00	Air Spring ø130,8xø210x395		
A 34662	02.2002.46.00	Air Spring ø198,1xø300x360		
A 34719	02.2002.40.00	Air Spring ø198,1xø300x530		
A 34720	02.2002.41.00	Air Spring ø130,8xø238x460		
A 34762	02.2002.42.00	Air Spring		
AU 34940	05.429.40.91.0	Air Spring ø259x426		







Auger Nr.	OEM Nr.	Description	Model	Picture
AU 344940	05.429.41.56.0	Air Spring ø259x426		
AU 34941	05.429.40.03.0	Air Spring ø259x527		
AU 34942	05.429.40.05.0	Air Spring ø311x595		
AU 344881	05.429.41.01.0	Air Spring ø311x420		
AU 344961	05.429.42.04.0	Air Spring ø259x527		
AU 344941	05.429.41.25.0	Air Spring ø259x527		

Auger Nr.	OEM Nr.	Description	Model	Picture
AU 344960	05.429.41.77.0	Air Spring ø259x426		
AU 34881	05.429.40.01.0	Air Spring ø311x523		
AU 34881-K	05.429.40.61.1 05.429.41.42.1 05.429.41.35.1 05.429.40.48.1	Air Spring ø340x470		
AU 34881-KP	05.429.43.51.0	Air Spring ø340x470		
AU 34940-KP01	05.429.43.22.0	Air Spring ø275x355		
AU 34940-K	05.429.42.41.1 05.429.40.93.1	Air Spring ø275x355		

Auger Nr.	OEM Nr.	Description	Model	Picture
AU 34940-KP	05.429.43.21.0	Air Spring		
	05.429.41.29.0	ø275x355		
	05.429.42.19.1			
	05.429.42.40.0			
AU 34941-K	05.429.40.10.1	Air Spring		
	05.429.40.28.1	ø275x445		
	05.429.40.36.1			
AU 34941-KP	05.429.43.20.0	Air Spring		
	05.429.40.59.1	ø275x445		
	05.429.41.24.1			
	05.429.42.18.1			
AU 34942-K	05.429.41.69.0	Air Spring		
	05.429.41.71.1	ø340x490		
AU 344881-K	05.429.41.31.1	Air Spring		
	05.429.41.03.1	ø340x350		
AU 344881-KP	05.429.43.41.0	Air Spring		
		ø340x350		

Auger Nr.	OEM Nr.	Description	Model	Picture
AU 344941-K	05.429.43.25.0	Air Spring ø275x445		
20002	03.139.39.48.0	Piston, Air Spring ø247x143		
20004	03.139.39.49.0	Piston, Air Spring ø197x141,5		
20005	03.139.39.42.0	Piston, Air Spring ø197x193		
20032	03.139.39.43.0	Piston, Air Spring ø247x187,6		
20266	03.139.00.04.0	Piston, Air Spring ø250/ø30x203	Air bag BPW 36 Air bag BPW 36-1	

Auger Nr.	OEM Nr.	Description	Model	Picture
20267	03.139.00.17.0	Piston, Air Spring ø250/ø30x293	Air bag BPW 36	 
20268	05.139.39.50.0	Piston, Air Spring ø203x194	Air bag BPW 30	 
20269	05.139.39.51.0	Piston, Air Spring ø202x149	Air bag BPW 30 K	 
20270	05.139.39.53.0	Piston, Air Spring ø252x143	Air bag BPW 30 K	 
20255	05.139.39.52.0	Piston, Air Spring for AU 34881-KP ø254x188		 
20030	03.320.09.35.0	Flange, Air Spring M16x2/ø17xø249,5x19		

Auger Nr.	OEM Nr.	Description	Model	Picture
20035	03.320.09.34.0	Flange, Air Spring M16x2/ø17xø199,5x17		
20031	03.084.46.31.0	Bolt, Air Spring M16x2/128		
20033	03.084.46.28.0	Bolt, Air Spring M16x2/174		
20029	03.139.39.48.0 S	Repair Kit, Air Spring, for AU 344881-K <i>Piston: 20002</i> <i>Flange: 20030</i> <i>Bolt: 20031</i> ø247x143		
20034	03.139.39.49.0 S	Repair Kit, Air Spring, for AU 34940-K <i>Piston: 20004</i> <i>Flange: 20035</i> <i>Bolt: 20031</i> ø197x141,5		
20036	03.139.39.42.0 S	Repair Kit, Air Spring, for AU 34941-K <i>Piston: 20005</i> <i>Flange: 20035</i> <i>Bolt: 20033</i> ø197x193		
20114	03.139.39.43.0 S	Repair Kit, Air Spring, for AU 34881-K <i>Piston: 20032</i> <i>Flange: 20030</i> <i>Bolt: 20033</i> ø247x187,6		

Auger Nr.	OEM Nr.	Description	Model	Picture
20271	05.801.09.73.0	Repair Kit, Air Spring ø203x194	Air bag BPW 30	
20272	05.801.09.74.0	Repair Kit, Air Spring for AU 34940-KP ø202x149	Air bag BPW 30 K	
20273	05.801.21.28.0	Repair Kit, Air Spring ø252x143	Air bag BPW 30 K	
20274	05.801.21.29.0	Repair Kit, Air Spring ø252x143	Air bag BPW 30 K	
20275	05.801.21.30.0	Repair Kit, Air Spring ø252x143	Air bag BPW 30 K	
20276	05.801.21.31.0	Repair Kit, Air Spring ø254x188	Air bag BPW 30	
20256	05.801.21.32.0	Repair Kit, Air Spring for AU 34881-KP ø254x188		

Auger Nr.	OEM Nr.	Description	Model	Picture
20277	05.801.21.33.0	Repair Kit, Air Spring ø254x188	Air bag BPW 30	
75866	03.224.19.03.1	Bogie Bearing ø198	W Series	
67897	03.112.99.04.0	Bushing, Bogie Suspension ø185xø200x243		
67898	03.112.99.02.0	Bushing, Bogie Suspension ø130xø145x214		
70818	03.310.38.01.0	Wear Ring, Bogie Suspension ø130xø165x10		
70645	03.310.39.02.0	Thrust Washer, Bogie Suspension ø185xø219,5x10		
70650	03.264.19.03.0	Nut, Bogie Suspension M180x4/46		

Auger Nr.	OEM Nr.	Description	Model	Picture
52107	05.113.96.06.0 05.113.93.02.0	Rubber Bushing, Stabilizer Bar ø30xø52,5x68	VBU, VBQ Series	
52102	05.113.96.05.0 02.0316.01.00	Rubber Bushing, Stabilizer Bar ø30xø60x68		
54435	05.113.96.05.0 S1 02.0316.01.00 S1	Bushing, Stabilizer Bar ø30xø60x68		
52116	03.113.98.06.0 03.113.96.04.0	Bearing, Stabilizer Bar ø45,5/ø50x94,5		
54789	03.340.15.22.0	Bolt, Stabilizer Bar 120/M30x3,5	Trailing Arm (width 100 mm)	
54042	03.340.15.20.0 03.340.15.27.0 03.340.15.10.0 03.340.15.08.0	Bolt, Stabilizer Bar 190/M30x3,5	Trailing Arm (width 100 mm)	
54051	02.5220.81.26 02.5220.81.82 03.260.15.01.0	Nut, Stabilizer Bar, Self-Locking M30x3,5	Trailing Arm (width 100 mm)	

Auger Nr.	OEM Nr.	Description	Model	Picture
53541	05.113.96.05.0 S 02.0316.01.00 S	Repair Kit, Stabilizer Bar ø36xø60x68		
52119	-	Repair Kit, Stabilizer Bar ø30xø52,5x68/ø45,5x94,5		
52100	05.3536.70.90 03.3536.70.90	Grip Head, Connecting Rod ø30x198 M36x2 LHT		
52101	05.3536.70.80 03.3536.70.80	Grip Head, Connecting Rod ø30x198 M36x2 RHT		
70660	03.340.16.03.0	Connecting Bolt, Connecting Rod M36x4/155		
70661	03.340.16.04.0	Connecting Bolt, Connecting Rod M36x4/185		
70662	03.340.16.05.0	Connecting Bolt, Connecting Rod M36x4/225		

Auger Nr.	OEM Nr.	Description	Model	Picture
20205	02.3722.14.00	Shock Absorber, Rear&Front		
	02.3702.36.00			
	02.3702.16.00	ø24x329/494		
	02.3702.19.00			
20206	02.3702.14.00	Shock Absorber, Front		
		ø20/ø22x413/679		
20207	02.3702.70.00	Shock Absorber, Rear		
20208	02.3702.67.00	Shock Absorber, Rear		
	02.3702.18.00			
20209	02.3702.83.00	Shock Absorber		
	02.3722.12.00			
68125	02.2805.01.00	Rubber Bushing, Shock Absorber		
		ø19xø49,5x30		

Auger Nr.	OEM Nr.	Description	Model	Picture
57015	03.320.64.01.0	Lock Washer, Axle ø53xø76x5,8	K Series (SN 36..) N Series (SN 30..) SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..)	
57018	03.320.73.13.0	Lock Washer, Axle ø43xø61x5,8	K Series (SN 36..) N Series (SN 30..) SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..)	
70644	03.310.75.12.0	Lock Washer, Axle ø61xø88x5,8	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..) N..L Series (SN 30..)	
52175	03.262.16.03.0	Axle Nut M42x2/42xSW65	K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..) N..L Series (SN 30..)	
52176	03.262.16.02.0	Axle Nut M42x3/42xSW65		
52177	03.262.17.08.0	Axle Nut M52x2/52xSW80	EH Series	
52178	03.262.17.03.0 03.262.17.11.0	Axle Nut M60x2/55xSW85	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..) N..L Series (SN 30..)	
57026	03.262.17.13.0	Axle Nut M70x2/43xSW100		

Auger Nr.	OEM Nr.	Description	Model	Picture
59345	02.520.73.20.4	Axle Nut M30x1,5/18xSW46		
75787	03.262.15.06.0	Axle Nut M30x2/36xSW46	NRS/NRZ 5506-1 axle type NMS/NMZ 5506/5508 axle type	
74780	03.262.16.15.0	Axle Nut M42x2/42xSW65	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN42..) K..L Series (SN 36..)	
74781	03.262.17.18.0	Axle Nut M52x2/41xSW80	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN42..) K..L Series (SN 36..)	
74782	03.262.17.19.0	Axle Nut M60x2/50xSW85	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) N..LL Series (SN 30..) H (M)..L Series (SN42..) K..L Series (SN 36..) N..L Series (SN 30..)	
70649	03.188.07.04.0	Spring Clip, Axle ø165x3,2		
68114	03.112.76.08.0	Bushing, Axle Steering Knuckle ø60xø65x90	H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) SH..LL Series (SB 4309 /SB 4345) SKH..LL Series (SN SB 3745) H (M)..L Series (SN 42..) K..L Series (SN 36..) N..L Series (SN 30..)	
57306	09.801.02.35.0	King Pin Kit, Axle Steering Knuckle ø60x330,5	K..LL Series (SN 36..) N..LL Series (SN 30..) H..LL Series (SN 42..) SKH..LL Series (SN SB 3745)	

Auger Nr.	OEM Nr.	Description	Model	Picture	
57307	09.801.02.36.0	King Pin Kit, Axle Steering Knuckle ø60x330,5	K Series (SN 36..) N Series (SN 30..)		
55993	03.272.30.87.0 03.272.30.81.0 09.801.06.03.0 S	Wheel Hub, Only Casting Body, 6,5-9 Tons M125x2/ø130/ø140x193	H Series (SN 42..) H..LL Series (SN 42..) H (M)..L Series (SN 42..)		
75265	03.272.30.87.0 S 03.272.30.81.0 S 09.801.06.03.0 S1	Wheel Hub, With Bearing, 6,5-9 Tons M125x2/193	H Series (SN 42..) H..LL Series (SN 42..) H (M)..L Series (SN 42..)		Sample
55994	03.272.30.97.0 03.272.30.95.0 09.801.06.05.0 S	Wheel Hub, Only Casting Body, 6,5-9 Tons M125x2/ø110/ø112x193	SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) H (M)..L Series (SN 42..) SKH..LL Series (SB 3745)		
75267	03.272.30.97.0 S 03.272.30.95.0 S 09.801.06.05.0 S1	Wheel Hub, With Bearing, 6,5-9 Tons M125x2/193	H Series (SN 42..) SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) H (M)..L Series (SN 42..) SKH..LL Series (SB 3745)		Sample
68123	03.272.43.14.2 03.272.43.14.1 03.272.43.14.0 09.801.06.58.0 S	Wheel Hub Only Casting Body M136x2.5/ø122/ø155,5/ ø150x224	SKH Series (SB 3745) SH..LL Series (SB 4309 /SB 4345) SKH..LL Series (SB 3745)		
75271	03.272.43.14.2 S 03.272.43.14.1 S 03.272.43.14.0 S 09.801.06.58.0 S1	Wheel Hub, With Bearing M136x2.5/224	SKH Series (SB 3745) SH..LL Series (SB 4309 /SB 4345) SKH..LL Series (SB 3745)		Sample

Auger Nr.	OEM Nr.	Description	Model	Picture	
68116	03.272.62.27.0 03.272.62.19.0 03.272.62.20.0	Wheel Hub, Only Casting Body, 13-14 Tons M135x3/ø170/ø183/ ø188x223	H Series (SN 42..) H (M)..L Series (SN 42..)		
68118	03.272.48.33.0 03.272.48.17.0 03.272.48.35.0	Wheel Hub, Only Casting Body M125x3/ø137/ø150/ ø167x220			
68117	03.272.43.20.0 03.272.48.78.0 09.801.06.72.0 S 09.801.06.04.0 S	Wheel Hub, Only Casting Body, 10-12 Tons M136x2.5/ø120/ø122/ ø150x206	H Series (SN 42..) H..LL Series (SN 42..) H (M)..L Series (SN 42..)		
68119	03.272.30.41.0 03.272.30.34.0 03.272.30.62.0 03.272.30.35.0	Wheel Hub, Only Casting Body, 6,5-9 Tons M115x2/ø130/ø138/ ø143x191	H Series (SN 42..) H..LL Series (SN 42..) H (M)..L Series (SN 42..)		
75268	03.272.30.41.0 S 03.272.30.34.0 S 03.272.30.62.0 S 03.272.30.35.0 S	Wheel Hub, With Bearing, 6,5-9 Tons M115x2/191	H Series (SN 42..) H..LL Series (SN 42..) H (M)..L Series (SN 42..)		NEW Sample
68122	03.272.43.10.0 09.801.06.07.0 S 03.272.43.10.2 S	Wheel Hub, Only Casting Body, 6-9 Tons ø120/ø150/ø155,5x180	H Series (SN 42..) K Series (SN 36..) SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) SH..LL Series (SB 4309 /SB 4345) SKH..LL Series (SB 3745)		
75270	03.272.43.10.0 S 09.801.06.07.0 S1 03.272.43.10.2 S1	Wheel Hub, With Bearing, 6-9 Tons	H Series (SN 42..) K Series (SN 36..) SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) SH..LL Series (SB 4309 /SB 4345) SKH..LL Series (SB 3745)		NEW Sample

Auger Nr.	OEM Nr.	Description	Model	Picture
68124	03.272.48.46.0	Wheel Hub,	H Series (SN 42..)	
	03.272.48.40.0	Only Casting Body,	H..LL Series (SN 42..)	
	03.272.48.62.0	10-12 Tons	H (M)..L Series (SN 42..)	
	03.272.48.45.0	M125x2/ø148/ø150/ ø167x206		
75272	03.272.48.46.0 S	Wheel Hub,	H Series (SN 42..)	 NEW
	03.272.48.40.0 S	With Bearing,	H..LL Series (SN 42..)	
	03.272.48.62.0 S	10-12 Tons	H (M)..L Series (SN 42..)	
	03.272.48.45.0 S	M125x2/206		
68120	03.272.44.24.0	Wheel Hub,	K Series (SN 36..)	
		Only Casting Body, 10-12 Tons	K..L Series (SN 36..) K..LL Series (SN 36..)	
		M125x2/ø105/ø150/ ø167x205		
75269	03.272.44.24.0 S	Wheel Hub,	K Series (SN 36..)	 NEW
		With Bearing, 10-12 Tons	K..L Series (SN 36..) K..LL Series (SN 36..)	
		M125x2/205		
68121	03.272.27.20.0	Wheel Hub,	N Series (SN 30..)	
		Only Casting Body, 6-9 Tons	N..L Series (SN 30..) N..LL Series (SN 30..)	
		M115x2/ø95/ø130/ ø143x191		
75266	03.272.44.40.0	Wheel Hub,	H Series (SN 42..)	 NEW
	09.801.06.56.0 S	Only Casting Body	N Series (SN 30..) K..LL Series (SN 36..) N..LL Series (SN 30..) K..L Series (SN 36..) N..L Series (SN 30..)	
75273	03.272.27.41.0	Wheel Hub,	K Series (SN 36..)	 NEW
	09.801.06.50.0 S	Only Casting Body	N Series (SN 30..) K..LL Series (SN 36..) N..LL Series (SN 30..) K..L Series (SN 36..) N..L Series (SN 30..)	

Auger Nr.	OEM Nr.	Description	Model	Picture	
75274	03.272.27.41.0 S 09.801.06.50.0 S1	Wheel Hub, With Bearing	K Series (SN 36..) N Series (SN 30..) K..LL Series (SN 36..) N..LL Series (SN 30..) K..L Series (SN 36..) N..L Series (SN 30..)	 	Sample
75275	03.272.27.48.0 09.801.06.54.0 S	Wheel Hub, Only Casting Body	K Series (SN 36..) N Series (SN 30..) K..LL Series (SN 36..) N..LL Series (SN 30..) N..L Series (SN 30..)	 	
75276	03.272.44.30.0 03.272.44.21.0	Wheel Hub, Only Casting Body	N Series (SN 30..) N..LL Series (SN 30..) N..L Series (SN 30..)	 	
75277	03.272.44.30.0 S 03.272.44.21.0 S	Wheel Hub, With Bearing	N Series (SN 30..) N..LL Series (SN 30..) N..L Series (SN 30..)	 	Sample
75278	03.272.44.34.0 09.801.06.52.0 S	Wheel Hub, Only Casting Body	K Series (SN 36..) N Series (SN 30..) K..LL Series (SN 36..) N..LL Series (SN 30..) K..L Series (SN 36..) N..L Series (SN 30..)	 	
75279	03.272.46.28.0 09.801.06.69.0 S	Wheel Hub, Only Casting Body	K Series (SN 36..) SKH Series (SB 3745) SKH..LL Series (SB 3745)	 	Sample
75280	03.272.47.33.0 09.801.06.13.0 S 09.801.06.14.0 S	Wheel Hub, Only Casting Body	H Series (SN 42..)	 	Sample

Auger Nr.	OEM Nr.	Description	Model	Picture
75281	03.272.30.99.0	Wheel Hub, Only Casting Body	SKH Series (SB 3745) SKH..LL Series (SB 3745)	 
75282	03.272.30.99.0 S	Wheel Hub, With Bearing	SKH Series (SB 3745) SKH..LL Series (SB 3745)	  Sample
75283	03.272.43.28.0 09.801.07.32.0 S	Wheel Hub, Only Casting Body	SH..LL Series (SB 4309 / SB 4345) SKH..LL Series (SB 3745)	 
75284	03.272.43.28.0 S 09.801.07.32.0 S1	Wheel Hub, With Bearing	SH..LL Series (SB 4309 / SB 4345) SKH..LL Series (SB 3745)	  Sample
75285	03.272.28.35.0	Wheel Hub, Only Casting Body	K Series (SN 36..)	 
75286	03.272.46.11.0	Wheel Hub, Only Casting Body	K Series (SN 36..) K..LL Series (SN 36..) K..L Series (SN 36..)	 
75287	03.272.30.31.0 03.272.30.19.0	Wheel Hub, Only Casting Body		 

Auger Nr.	OEM Nr.	Description	Model	Picture	
75288	03.272.30.30.0	Wheel Hub,			
	03.272.30.07.0	Only Casting Body			
	03.272.30.05.0				
	03.272.30.38.0				
75289	03.272.48.32.0	Wheel Hub,			
	03.272.48.07.0	Only Casting Body			
	03.272.48.10.0				
	03.272.48.12.0				
75290	03.272.32.05.0	Wheel Hub, Only Casting Body	H Series (SN 42..) K Series (SN 36..) H..LL Series (SN 42..) SKH..LL Series (SB 3745)		
75291	03.272.32.05.0 S	Wheel Hub, With Bearing	H Series (SN 42..) K Series (SN 36..) H..LL Series (SN 42..) SKH..LL Series (SB 3745)		Sample
75292	03.272.43.12.0	Wheel Hub,	H Series (SN 42..)		
	03.272.43.23.2 S	Only Casting Body	H..LL Series (SN 42..)		
	09.801.06.06.0 S		H (M)..L Series (SN 42..)		
	09.801.06.08.2 S				
75293	03.272.48.52.0	Wheel Hub, Only Casting Body	H Series (SN 42..) H..LL Series (SN 42..) H (M)..L Series (SN 42..)		
75294	03.272.48.97.0	Wheel Hub, Only Casting Body	H Series (SN 42..) H..LL Series (SN 42..) H (M)..L Series (SN 42..)		

Auger Nr.	OEM Nr.	Description	Model	Picture
75295	03.272.63.12.0 03.272.63.06.0 03.272.63.08.0	Wheel Hub, Only Casting Body	N Series (SN 30..) N..LL Series (SN 30..) N..L Series (SN 30..)	 
75296	03.272.62.35.0	Wheel Hub, Only Casting Body		 
75297	03.272.80.14.0 03.272.80.10.0 03.272.80.07.0 03.272.80.18.0	Wheel Hub, Only Casting Body	H Series (SN 42..)	 
75298	03.272.80.14.0 S 03.272.80.10.0 S 03.272.80.07.0 S 03.272.80.18.0 S	Wheel Hub, With Bearing	H Series (SN 42..)	  Sample
75299	03.328.86.05.0 02.3910.82.06	Wheel Hub, Only Casting Body	H Series (SN 42..)	 
75300	03.328.86.05.0 S 02.3910.82.06 S	Wheel Hub, With Bearing	H Series (SN 42..)	  Sample
52066	03.310.96.05.0	Seal Ring, Wheel Hub ø78xø113x2,5		

Auger Nr.	OEM Nr.	Description	Model	Picture
52067	03.310.96.06.0	Seal Ring, Wheel Hub ø83xø118x2,5		
52068	03.310.97.07.0	Seal Ring, Wheel Hub ø84xø134x3		
52069	03.310.97.08.0	Seal Ring, Wheel Hub ø88xø140x3		
52070	03.310.96.04.0	Seal Ring, Wheel Hub ø89xø124x2,5		
52071	03.310.97.04.0	Seal Ring, Wheel Hub ø93xø144x2,5		
52072	03.310.97.16.0	Seal Ring, Wheel Hub ø94xø131x2,5		
52073	03.310.97.03.0	Seal Ring, Wheel Hub ø98xø150x2,5		

Auger Nr.	OEM Nr.	Description	Model	Picture
52074	03.310.97.13.0 03.310.97.28.0	Seal Ring, Wheel Hub ø100xø134x2,5	K Series (SN 36..)	
52075	03.310.98.07.0	Seal Ring, Wheel Hub ø100xø165x2,5		
52076	03.310.97.32.0	Seal Ring, Wheel Hub ø104xø136x2,5	K Series (SN 36..) H..LL Series (SN 42..) K..LL Series (SN 36..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
52077	03.310.97.14.0 03.310.97.29.0	Seal Ring, Wheel Hub ø105xø141x2,5	K Series (SN 36..)	
52078	03.310.98.06.0	Seal Ring, Wheel Hub ø105xø172x2,5		
52079	03.310.97.31.0	Seal Ring, Wheel Hub ø110xø141x2,5	K Series (SN 36..) H..LL Series (SN 42..) K..LL Series (SN 36..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
52092	03.310.97.22.0	Seal Ring, Wheel Hub ø110xø144x7		
52080	03.310.97.15.0 03.310.97.27.0	Seal Ring, Wheel Hub ø113xø155x3,5		

Auger Nr.	OEM Nr.	Description	Model	Picture
52081	03.310.98.14.0	Seal Ring, Wheel Hub		
	03.310.98.19.0	ø118xø165x3,5		
52082	03.310.98.04.0	Seal Ring, Wheel Hub ø118xø165x3,5		
52083	03.310.97.30.0	Seal Ring, Wheel Hub ø120xø157x2,5	K Series (SN 36..) H..LL Series (SN 42..) K..LL Series (SN 36..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
52084	03.310.98.13.0	Seal Ring, Wheel Hub ø123xø171x3,5		
52085	03.310.98.02.0	Seal Ring, Wheel Hub ø123xø192x3,5		
52086	03.310.38.20.0	Seal Ring, Wheel Hub ø124xø181x4	H Series (SN 42..) K Series (SN 36..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
52093	03.310.98.18.0	Seal Ring, Wheel Hub ø125xø168x7		
52087	03.310.98.21.0	Seal Ring, Wheel Hub ø128xø165x2,5	H Series (SN 42..) K Series (SN 36..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	

Auger Nr.	OEM Nr.	Description	Model	Picture
52088	03.310.38.21.0	Seal Ring, Wheel Hub ø130xø186x4	H Series (SN 42..) K Series (SN 36..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
52089	03.310.99.02.0 03.310.99.15.0	Seal Ring, Wheel Hub ø144xø205x3,5	H Series (SN 42..)	
52091	03.310.98.24.0	Seal Ring, Wheel Hub ø145xø173x3,5/10		
52090	03.310.99.01.0 03.310.99.16.0	Seal Ring, Wheel Hub ø149xø212x3,5	H Series (SN 42..)	
68322	03.310.99.09.0	Seal Ring, Wheel Hub ø156,5xø220x3,5		
68323	03.310.99.10.0	Seal Ring, Wheel Hub ø163,5ø227x3,5		
68321	03.310.89.08.0	Seal Ring, Wheel Hub ø214xø250x3,5		
57012	02.5664.74.00	Seal Ring, Wheel Hub ø99,5/ø117,5xø158x17,5		









Auger Nr.	OEM Nr.	Description	Model	Picture
57019	02.5664.46.57	Seal Ring, Wheel Hub ø143xø167x13		
57022	02.5664.26.57	Seal Ring, Wheel Hub ø122xø143x13	N..LL Series (SN 30..) N..L Series (SN 30..)	
57023	02.5664.55.64 02.5664.57.00	Seal Ring, Wheel Hub ø114,5xø138,7x11,5	K Series (SN 36..) N Series (SN 30..) SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..)	
57304	02.5664.58.00 02.5664.56.64	Seal Ring, Wheel Hub ø135xø156,7x8/10,5	K Series (SN 36..) N Series (SN 30..) SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..)	
53060	03.310.88.03.0	Seal Ring, Wheel Hub ø160xø190x3.5		
69285	02.5664.51.00	Seal Ring, Wheel Hub ø100xø120x12 / NBR	NRS/NRZ 5506-1 axle type	
69357	02.5664.68.00	Seal Ring, Wheel Hub ø120xø157,5x26 / NBR		
70647	03.370.08.18.0	Thrust Ring, Wheel Hub ø97,5xø130/ø179x34	H Series (SN 42..) H (M)..L Series (SN 42..)	

Auger Nr.	OEM Nr.	Description	Model	Picture
53517	03.370.07.62.0	Thrust Ring, Wheel Hub, 10-12 Tons ø96,5xø159x22	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..)	
53996	03.370.07.45.0	Thrust Ring, Wheel Hub, 6,5-9 Tons ø86xø125x22	N Series (SN 30..) N ..LL Series (SN 30..) N ..L Series (SN 30..)	
54000	03.370.07.44.0	Thrust Ring, Wheel Hub, 10-12 Tons ø96xø145x22	N Series (SN 30..) N ..L Series (SN 30..)	
53518	03.370.07.60.0	Thrust Ring, Wheel Hub, 6,5-9 Tons ø86,25xø139x22	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..)	
55504	03.370.07.60.0 TS	Thrust Ring, Wheel Hub, 6,5-9 Tons ø86,25xø139x22	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..)	
53966	05.370.07.43.0	Thrust Ring, Wheel Hub, 10-12 Tons ø96xø136x22	H Series (SN 42..) K Series (SN 36..) H..LL Series (SN 42..) K..LL Series (SN 36..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
55593	05.370.07.20.0	Thrust Ring, Wheel Hub, 13-14 Tons ø96xø136/ø187x34	K Series (SN 36..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
55753	05.370.06.48.0	Thrust Ring, Wheel Hub, 6,5-9 Tons ø86xø114,75/ø142,5x22	K Series (SN 36..) H..LL Series (SN 42..) K..LL Series (SN 36..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	

Auger Nr.	OEM Nr.	Description	Model	Picture
55754	05.370.07.04.0	Thrust Ring, Wheel Hub, 16-18 Tons ø112xø153,75/ø213x35	H Series (SN 42..)	
57016	02.5677.90.40 05.370.07.67.0	Thrust Ring, Wheel Hub, 6,5-9 Tons ø86,25xø139x22	SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..) N..L Series (SN 30..)	
57020	02.5678.00.00 05.370.07.65.0	Thrust Ring, Wheel Hub, 10-12 Tons ø96,5xø158x25,5	SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..) N..L Series (SN 30..)	
70817	05.370.06.59.0	Thrust Ring, Wheel Hub ø77xø110x22		
75350	05.370.07.13.0	Thrust Ring, Wheel Hub ø87xø125/ø166x30		
75788	03.370.06.36.0	Thrust Ring, Wheel Hub ø62xø105/ø78x24	NMS/NMZ 5506/5508 axle type	
75789	03.370.06.53.0	Thrust Ring, Wheel Hub ø62xø100/ø78x24	NRS/NRZ 5506-1 axle type	
56618	02.6407.75.00 02.6408.29.00 02.6410.29.00	Bearing, Wheel Hub ø75xø130x41		








Auger Nr.	OEM Nr.	Description	Model	Picture
57013	02.6410.23.00	Bearing, Wheel Hub	N Series (SN 30..)	
	02.6408.92.00	ø90xø150x45	SH Series (SB 4345)	
	02.6408.90.00		SKH Series (SB 3745) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..)	
57014	02.6410.22.00	Bearing, Wheel Hub	N Series (SN 30..)	
	02.6407.67.00	ø65xø120x41	SH Series (SB 4345)	
	02.6407.65.00		SKH Series (SB 3745) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..)	
57148	02.6408.80.00	Bearing, Wheel Hub	K Series (SN 36..)	
	02.6410.24.00	ø80xø130x37	N Series (SN 30..)	
			SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..)	
57149	02.6410.25.00	Bearing, Wheel Hub	K Series (SN 36..)	
	02.6406.50.00	ø50xø110x42,25	N Series (SN 30..)	
			SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..)	
54589	02.6405.35.00	Bearing, Wheel Hub		
		ø35xø72x24,25		
69667	02.6405.95.00	Bearing, Wheel Hub		
	02.6410.28.00	ø95xø170x45,5		
69669	02.6406.60.00	Bearing, Wheel Hub		
		ø60xø130x48,5		
69671	02.6406.70.00	Bearing, Wheel Hub		
	02.6410.27.00	ø70xø150x54		






Auger Nr.	OEM Nr.	Description	Model	Picture
69689	02.6407.40.00	Bearing, Wheel Hub ø40xø80x32		
69690	02.6406.03.00	Bearing, Wheel Hub ø30xø72x29		
69699	02.6407.45.01 02.6407.45.00	Bearing, Wheel Hub ø45xø85x32		
69706	02.6407.85.00	Bearing, Wheel Hub ø85xø150x49		
69707	02.6405.60.00	Bearing, Wheel Hub ø60xø110x29,75		
69712	02.6410.11.00 02.6410.26.00	Bearing, Wheel Hub ø110xø200x56	H (drum brakes SN42..)	
69714	02.6402.65.00	Bearing, Wheel Hub ø65xø140x36		
70785	02.6401.30.00	Bearing, Wheel Hub ø30xø62x17,5		

Auger Nr.	OEM Nr.	Description	Model	Picture
52201	03.010.93.33.0	Dust Cover, Wheel Hub ø84xø128x8,5	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..)	
52202	03.010.93.34.0	Dust Cover, Wheel Hub ø94xø148x8,5	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..)	
52203	03.370.25.16.0	Dust Cover, Wheel Hub ø53,5xø98x8	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..)	
52204	03.370.26.24.0 03.370.26.22.0	Dust Cover, Wheel Hub ø71xø108x8	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..)	
53059	03.010.04.15.0	Dust Cover, Wheel Hub ø84,5xø128,5x5	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
53967	03.010.05.22.0	Dust Cover, Wheel Hub ø95,5xø148,5x5,5	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
53998	03.010.05.21.0	Dust Cover, Wheel Hub ø99xø169x5,5	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..) N..L Series (SN 30..)	
53999	03.010.06.12.0	Dust Cover, Wheel Hub ø114,5xø199x5,5	H Series (SN 42..)	

Auger Nr.	OEM Nr.	Description	Model	Picture
55755	03.120.48.15.0	Dust Cover, Wheel Hub ø122xø160x8	H Series (SN 42..) K Series (SN 36..) SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..)	
57017	02.5681.98.00	Dust Cover, Wheel Hub ø103xø147x15	K Series (SN 36..) N Series (SN 30..) SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..)	
57024	03.010.04.09.0	Dust Cover, Wheel Hub ø80xø128x5,5	K Series (SN 36..)	
57025	03.010.05.17.0	Dust Cover, Wheel Hub ø90xø148x5		
57021	03.120.48.13.0	Dust Cover, Wheel Hub ø115/ø130xø168,5x15	K Series (SN 36..) N Series (SN 30..) SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..)	
57030	09.801.06.26.0	Repair Kit, Wheel Hub, 8-9 Tons ø90xø150x45	H Series (SN 42..) K Series (SN 36..) SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..)	
57031	09.801.02.17.0	Repair Kit, Wheel Hub, 6,5-9 Tons ø80xø130x37	K Series (SN 36..) H..LL Series (SN 42..) K..LL Series (SN 36..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
57033	09.801.02.24.0	Repair Kit, Wheel Hub, 6,5-9 Tons ø80xø130x37	K Series (SN 36..) H..LL Series (SN 42..) K..LL Series (SN 36..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	



Auger Nr.	OEM Nr.	Description	Model	Picture
57034	09.801.02.72.0	Repair Kit, Wheel Hub, 6,5-9 Tons ø80xø130x37	K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..) N..L Series (SN 30..)	
57035	09.801.02.18.0	Repair Kit, Wheel Hub, 10-12 Tons ø90xø150x45	K Series (SN 36..) H..LL Series (SN 42..) K..LL Series (SN 36..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
57036	09.801.02.20.0	Repair Kit, Wheel Hub, 10-12 Tons ø90xø150x45	N..L Series (SN 30..) N..LL Series (SN 30..)	
57038	09.801.02.98.0	Repair Kit, Wheel Hub, 10-12 Tons ø90xø150x45	K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
57043	09.801.02.19.0	Repair Kit, Wheel Hub, 6,5-9 Tons ø80xø130x37	N Series (SN 30..) N..L Series (SN 30..) N..LL Series (SN 30..)	
57044	09.801.06.27.0	Repair Kit, Wheel Hub, 10-12 Tons ø90xø150x45	SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) K..LL Series (SN 36..) SH..LL Series (SB 4309 /SB 4345) SKH..LL Series (SB 3745)	
75790	09.801.07.85.0	Repair Kit, Wheel Hub	NMS/NMZ 5506/5508 axle type	

Auger Nr.	OEM Nr.	Description	Model	Picture
75791	09.801.07.86.0	Repair Kit, Wheel Hub	NRS/NRZ 5506-1 axle type	
52120	03.212.24.25.0	Hub Cap, 6,5-9 Tons M125x2/SW110/500Nm	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
52121	03.212.25.08.0	Hub Cap, 10-12 Tons M135x2/SW110/800Nm	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
52122	03.212.23.09.0	Hub Cap, 6,5-9 Tons M115x2/SW95/500Nm	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..) N..L Series (SN 30..)	
52123	03.212.23.02.0	Hub Cap M115x3/SW95/700Nm		
52124	03.212.24.07.0	Hub Cap, 10-12 Tons M125x2/SW110/500Nm	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..) N..L Series (SN 30..)	
52125	03.212.24.02.0	Hub Cap, 10-12 Tons M125x3/SW110/700Nm	NH / NR	




Auger Nr.	OEM Nr.	Description	Model	Picture
52126	03.212.25.02.0 03.212.05.01.0	Hub Cap, 13-14 Tons M135x3/SW120/700Nm	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..) N..L Series (SN 30..)	
52127	03.212.26.01.0	Hub Cap, 16-18 Tons M155x3/SW120/700Nm	H Series (SN 42..)	
52128	03.212.22.01.0	Hub Cap M56x2/SW50		
52129	03.212.22.04.0	Hub Cap M84x2/SW70		
52130	03.212.22.05.0	Hub Cap M95x2/SW85		
52131	03.212.23.01.0	Hub Cap M105x3/SW90		
53946	03.212.25.31.0	Hub Cap M136x2,5/SW110/800Nm	H Series (SN 42..) K Series (SN 36..) SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) K..LL Series (SN 36..) SH..LL Series (SB 4309 / SB 4345) SKH..LL Series (SB 3745)	
53975	03.212.26.14.0	Hub Cap, 13-14 Tons M150x2/SW120/800Nm	H Series (SN 42..) H (M)..L Series (SN 42..)	

Auger Nr.	OEM Nr.	Description	Model	Picture
52132	03.212.27.01.0 03.212.07.01.0	Hub Cap, 14-20 Tons M230x3/SW120		
65707	03.296.33.11.1 03.296.33.11.0	Stud 80/M22x1,5	K Series (SN 36..) N Series (SN 30..) SKH Series (SB 3745) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..)	
65164	03.296.33.14.1	Stud 90/M22x1,5	K Series (SN 36..) N Series (SN 30..) SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..)	
65244	02.5070.89.00	Stud 57/M20x2	H..LL Series (SN 42..) H (M)..L Series (SN 42..)	
65543	02.5070.22.00 02.5070.41.00	Stud 125/M18x2	H..LL Series (SN 42..) H (M)..L Series (SN 42..)	
65544	02.5070.44.00 02.5070.21.00	Stud 110/M18x2	H..LL Series (SN 42..) H (M)..L Series (SN 42..)	
65551	02.5070.37.00 02.5070.32.00	Stud 115/M20x2	H..LL Series (SN 42..) H (M)..L Series (SN 42..)	
69161	03.296.33.12.1 03.296.33.12.0	Stud M22x1,5/97	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	

Auger Nr.	OEM Nr.	Description	Model	Picture
65630	03.296.23.05.0	Stud 100/M22x2/M22x2	K Series (SN 36..) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
65621	03.296.13.09.0	Stud 111/M22x2/M22x2	K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
69162	03.296.23.15.0	Stud 100/M22x2/M22x1,5	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
75128	03.296.23.17.0	Stud 114/M22x2/M22x1,5	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
75059	03.296.13.17.0	Stud 132/M22x2/M22x2	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
65581	03.260.04.10.0	Nut, Stud, Self-Locking M22x1,5		
65625	03.260.04.14.0	Nut, Stud M22x1,5/25		
65623	03.260.04.06.0	Nut, Stud, Self-Locking M22x2	K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..) N..L Series (SN 30..)	

Auger Nr.	OEM Nr.	Description	Model	Picture
65622	03.260.04.01.0	Nut, Stud M22x2	K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..) N..L Series (SN 30..)	
65568	02.5213.12.10	Nut, Stud M18x1,5	K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
65542	02.5270.03.00	Nut, Stud M18x2	H Series (SN 42..) H..LL Series (SN 42..) H (M)..L Series (SN 42..)	
65566	02.5219.20.10	Nut, Stud M20x1,5	K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..)	
65573	02.5213.14.10 02.5213.14.62	Nut, Stud M20x1,5	K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..) N..L Series (SN 30..)	
65567	02.5270.04.00	Nut, Stud M20x2	H..LL Series (SN 42..) H (M)..L Series (SN 42..)	
65561	03.260.54.03.0	Nut, Stud M22x1,5		
65564	02.5219.23.10 05.260.54.09.0 05.260.54.10.0	Nut, Stud M22x1,5	K Series (SN 36..) N Series (SN 30..) SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..)	

Auger Nr.	OEM Nr.	Description	Model	Picture
65559	02.5219.33.10	Nut, Stud M22x1,5		
65628	03.260.03.05.0	Nut, Stud, Self-Locking M20x1,5	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	
70813	02.5270.77.10	Nut, Stud M22x1,5		
75472	03.260.04.02.0	Nut, Stud M22x2/30		
65717	02.5615.18.90	Rondela, Stud ø18,5	K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..) N..L Series (SN 30..)	
65570	02.5615.20.90	Rondela, Stud ø20,5	K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..) N..L Series (SN 30..)	
65571	02.5615.22.90 03.143.00.02.0	Rondela, Stud ø22,5	K Series (SN 36..) N Series (SN 30..) SH Series (SB 4345) SKH Series (SB 3745) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..)	
70845	09.806.13.02.0	Repair Kit, Stud M22x2/M22x2/111	H Series (SN 42..) K Series (SN 36..) N Series (SN 30..) H..LL Series (SN 42..) K..LL Series (SN 36..) N..LL Series (SN 30..) H (M)..L Series (SN 42..) K..L Series (SN 36..)	

Auger Nr.	OEM Nr.	Description	Model	Picture
21904	10.309.77.42.4 02.2004.13.00	Air Tank ø246x702/M22x1,5 / Capacity:30 lt		
21905	02.2004.17.00	Air Tank ø276x747/M22x1,5 / Capacity:40 lt		
21906	02.2004.15.00	Air Tank ø276x1102/M22x1,5 / Capacity:60 lt		

**SPARE PARTS FOR
COMMERCIAL VEHICLES**

FRUEHAUF



we keep your business
ON THE MOVE










www.augerautotechnik.de

Auger
GERMANY







Auger Nr.	OEM Nr.	Description	Model	Picture
31218	AJB-0465-002	Brake Drum		
31220	AJA-0490-001	Brake Drum		
31221	AJA-0489-001 AJA-0489-002	Brake Drum		
31222	AJB-0335-001 AJB-0026-001	Brake Drum		
31223	86960	Brake Drum		
31224	M068445	Brake Drum		
65422	M006204	Brake Shoe, Brake Drum, Unlined ø406x178mm		

Auger Nr.	OEM Nr.	Description	Model	Picture
65423	M006093	Brake Shoe, Brake Drum, Unlined ø406x203mm		
52919	AJA-0507-001	Pin, Brake Shoe ø31,7x62,5		
52921	M002866	Pin, Brake Shoe ø31,7x70		
52918	AJA-0558-001	Bushing, Brake Shoe ø32xø35x37		
54909	-	Bushing, Brake Shoe ø41,2xø50,9/ø54x51		
52368	AJA-0504-001 M002971	Roller, Brake Shoe ø19/ø31,7x55,5		
53848	AJA-0504-002	Roller, Brake Shoe ø19/ø25x57		
53210	-	Lock Plate, Brake Shoe ø19,5x37x55		

Auger Nr.	OEM Nr.	Description	Model	Picture
54831	AJA-0506-001 M002693	Lock Plate, Brake Shoe ø19,5x52,5		
52920	AJB-0119-001 M002874	Spring, Brake Shoe ø32x204		
53849	AJA-0487-001	Spring, Brake Shoe ø28x176		
52369	M003001	Spring Pin, Brake Shoe ø6,3x70		
52782	M009279	Repair Kit, Brake Shoe ø19/ø31,75x55,5/70		
53167	ARJA-0199-703	Repair Kit, Brake Shoe ø19/ø31,75x55,5/62,5		
53854	-	Repair Kit, Brake Shoe ø19/ø31.75x55.5/62.5		
53855	-	Repair Kit, Brake Shoe ø19/ø31.75x55.5/62.5		

Auger Nr.	OEM Nr.	Description	Model	Picture
53857	-	Repair Kit, Brake Shoe ø19/ø25x57/70		
53858	-	Repair Kit, Brake Shoe ø19/ø25x57/62.5		
52216	-	Retainer, Brake Cam Shaft for 53841 ø70x13		
52367	M003060	Retainer, Brake Cam Shaft ø70x13		
53842	AJB-0001-001 AJB-0002-001	Retainer, Brake Cam Shaft ø10,5/69,5xø64x20		
52210	CF-1001312	Spherical Bearing, Brake Cam Shaft ø38xø70x63		
52283	AEJA-0442-001	Spherical Bearing, Brake Cam Shaft ø40xø64x38		

Auger Nr.	OEM Nr.	Description	Model	Picture
52278	AEJA-0441-002A	Bushing, Brake Cam Shaft ø40,7/ø47,5xø51,5x22		
52281	AEJA-0441-001	Bushing, Brake Cam Shaft ø40,7/ø47,5xø51,5x22		
53162	AJA-0753-002	Bushing, Brake Cam Shaft ø41xø50,7x19		
53163	AJA-0753-001	Bushing, Brake Cam Shaft ø41,5xø51x23		
52288	CF-1014969	Repair Kit, Brake Cam Shaft, Single Set ø40xø64x38		
52289	-	Repair Kit, Brake Cam Shaft, Double Set ø40xø64x38		
52290	CF-100149	Repair Kit, Brake Cam Shaft ø38xø70x63		

Auger Nr.	OEM Nr.	Description	Model	Picture
53164	AEJA-0442-001 S	Repair Kit, Brake Cam Shaft ø40xø64x38		
53165	M010676	Repair Kit, Brake Cam Shaft ø37,5/ø40xø70x509		
53841	M050147	Repair Kit, Brake Cam Shaft ø38/ø40xø70x456		
53851	AEJB-0003-002	Repair Kit, Brake Cam Shaft, Single Set ø40xø64x38		
53852	AEJB-0003-001	Repair Kit, Brake Cam Shaft, Double Set ø40xø64x38		
53853	ARJA-0199-702	Repair Kit, Brake Cam Shaft ø40xø64x38		

Auger Nr.	OEM Nr.	Description	Model	Picture
58142	CF 352283	Brake Slack Adjuster Automatic		
		ø14x250/180/165/150/135/ 120x50° / Saddle Type		
58145	CF 252122 CF 352122	Brake Slack Adjuster Automatic		
		ø14x250/180/165/150/135/ 120x110° / Saddle Type		
58168	CF 352434 CF 352282	Brake Slack Adjuster Automatic		
		ø14x250/180/155/140/125/ 105x130° / Saddle Type		
58177	CF 351827	Brake Slack Adjuster Automatic		
		ø14x250/210/180/150/125x 130° / Saddle Type		
58289	M068593	Brake Slack Adjuster Automatic		
		ø14x210/180/150/125x130° / Saddle Type		
58326	CF 352279 CF 352557 CF 352236 M042128 M070970	Brake Slack Adjuster Automatic		
		ø14x205/153/140/127/115x 60° / Saddle Type		

Auger Nr.	OEM Nr.	Description	Model	Picture
58336	CF 352196	Brake Slack Adjuster Manuel		
58370	M023565 M002416	Brake Slack Adjuster Automatic ø14x215/153/129/105x130° / Saddle Type		
58377	CF 351148	Brake Slack Adjuster Automatic ø14x200/142/118x0° / Bent		
68909	Haldex : 80032C	Brake Slack Adjuster Automatic ø12,7x125/150 / S-ABA		
31217	M200135	Brake Disc		
52277	AJA-0483-001 AJA-0483-002	Brake Dust Cover ø197xø463x72		
52280	AJB-0006-001 AJB-0006-002	Brake Dust Cover ø178xø460x38		

Auger Nr.	OEM Nr.	Description	Model	Picture
52917	ARJB-0006-701	Brake Dust Cover ø178xø460x38		
21004	-	Service Brake Chamber, for Disc Brake M16/120,7x97,5/140,5x164 T16 STR 57		
21005	AJV-4526	Service Brake Chamber, for Disc Brake, with Repair Kit M16/120,7x97,5/140,5x164 T16 STR 57		
21010	-	Service Brake Chamber, for Drum Brake M16/120,7x112,5/297,5x164 T16 STR 75		
21011	AFA-9104-001 ASX-0014-018	Service Brake Chamber, for Drum Brake, with Repair Kit M16/120,7x112,5/339,5x164 T16 STR 75		
21012	-	Service Brake Chamber, for Drum Brake M16/120,7x113/298x174 T20 STR 75		
21013	ASX-0014-019	Service Brake Chamber, for Drum Brake, with Repair Kit M16/120,7x113/340x174 T20 STR 75		

Auger Nr.	OEM Nr.	Description	Model	Picture
21014	-	Service Brake Chamber, for Drum Brake	M16/120,7x112,5/297,5x186 T24 STR 75	
21016	-	Service Brake Chamber, for Drum Brake	M16/120,7x117,5/302,5x208 T30 STR 75	
21017	ASX-0014-021 M020272-03	Service Brake Chamber, for Drum Brake, with Repair Kit	M16/120,7x117,5/344,5x208 T30 STR 75	
71932	CF 102959	Sensor, ABS		
74966	CF 104083	Sensor, ABS L: 350 mm		
74982	1H312779603	Sensor, ABS L: 3800 mm		

Diaphragms - Normal Stroke

Auger Nr.: 52576

OEM Nr. —

Type 9"

Auger Nr.: 52578

OEM Nr. —

Type 12"

Auger Nr.: 52580

OEM Nr. —

Type 16"

Auger Nr.: 52581

OEM Nr. —

Type 20"

Auger Nr.: 52582

OEM Nr. —

Type 24"

Auger Nr.: 52583

OEM Nr. —

Type 30"

Auger Nr.: 52584

OEM Nr. —

Type 36"



Diaphragms - Long Stroke

Auger Nr.: 52585

OEM Nr. —

Type 16"

Auger Nr.: 52586

OEM Nr. —

Type 20"

Auger Nr.: 52587

OEM Nr. —

Type 24"







Auger Nr.: 52588

OEM Nr. —

Type 30"



Auger Nr.	OEM Nr.	Description	Model	Picture
52217	M001502	Rubber Bushing, Spring ø30xø68x104		
52279	UJA-0033-001	Rubber Bushing, Spring ø32xø55,5x58,5		
52282	UJA-0030-001	Rubber Bushing, Spring ø52xø90x111,5		
68150	UJA-0033-001 S	Bushing, Spring Pu Type ø32xø55,5x58,5		
68152	UJA-0030-001 S	Bushing, Spring Pu Type ø54xø90x108,5		
54021	UJA-0324-001	Bolt, Spring 272,5/M24x1,5		

Auger Nr.	OEM Nr.	Description	Model	Picture
54022	UJA-0034-001	Bolt, Spring 154/M24x1,5		
54041	-	Bolt, Spring, for 53856 210/M30x3,5		
54053	-	Nut, Spring, for 53856 M30x3,5		
52286	100114	Repair Kit, Spring ø52xø90x111,5		
52287	100113	Repair Kit, Spring ø32xø55,5x58,5		
53204	100114 S	Repair Kit, Spring Single ø52xø90x111,5		

Auger Nr.	OEM Nr.	Description	Model	Picture
53205	100113 S	Repair Kit, Spring Single ø32xø55.5x58.5		
53856	M008949	Repair Kit, Spring 210/M30x3,5		
65640	M009007	U Bolt, Spring, M22x1,5/101x366		
65641	UJA-0020-007	U Bolt, Spring, M24x2/152x307		
72063	M008957	U Bolt, Spring M24x2/153,5x325		
72064	M001685	U Bolt, Spring M24x2/152x288		




Auger Nr.	OEM Nr.	Description	Model	Picture
72065	M009015	U Bolt, Spring M24x2/152x327		
AU 344156-KP	UJB-0207-001	Air Spring ø300x380		
AU 344156-K05	M001472	Air Spring ø300x380		
AU 344157-KP08	M078580	Air Spring ø270x400		
AU 344157-KP10	M060924 UJB-0975	Air Spring ø270x400		
AU 344159-KP	UJA-0894-001	Air Spring ø300x400		


Auger Nr.	OEM Nr.	Description	Model	Picture
AU 344159K05	M001782 UJB-0203-001	Air Spring ø300x400		
AU 344159K09	M001774 UJB-0358-001	Air Spring ø280x400		
20123	003615E S	Piston, Air Spring ø260x178		
20205	M001022 UJB-0350	Shock Absorber, Rear&Front ø24x329/494		
20215	UJB-0364 UJB-0563 UJB-0565 1526855 M001537 M007950	Shock Absorber, Rear ø20x320/470		

Auger Nr.	OEM Nr.	Description	Model	Picture	
53843	AJA-0407-001	Lock Washer, Axle ø89xø128,5x6			
57158	AJA-0755-001 AJA-0620-001	Axle Nut ø86 W12G/29xSW122			
68151	CF 1030367 CF 1031007	Wheel Hub, Only Casting Body			
75336	CF 1030367 S CF 1031007 S	Wheel Hub, With Bearing			Sample
75337	CF 103079	Wheel Hub, Only Casting Body			
75338	CF 103079 S	Wheel Hub, With Bearing			Sample

Auger Nr.	OEM Nr.	Description	Model	Picture
75339	CF 103694	Wheel Hub, Only Casting Body		
75340	AJB-0038-001 CF 1014228	Wheel Hub, Only Casting Body		
74688	AJA-0813-001	Bearing, Wheel Hub ø89xø152,5x40		
53847	M008892	Seal Ring, Wheel Hub ø108xø153x30		
69385	M003125	Seal Ring, Wheel Hub ø108xø152,6/ø185x19 / NBR		
70843	-	Hub Cap, Plastic ø158-W8G/78xSW122		
53845	AJA-0492-001	Hub Cap, Plastic ø158-W8G/76,5xSW122		

Auger Nr.	OEM Nr.	Description	Model	Picture
53846	AJA-0492-001 S	Hub Cap ø158-W8G/76,5xSW122		
53844	AJA-0577-001	Hub Cap ø158-W8G/67xSW110		
57159	M044554	Hub Cap M155x2,5/62xSW110		
65170	AJA-0491-002 M003133	Stud 74/M22x1,5		
65714	AJA-0491-001 AJB-11623 A	Stud 89/M22x1,5		
68153	M069123 M069131	Stud M22x1,5/88		
65708	AJA-0495-001 M003141	Nut, Stud M22x1,5		

Auger Nr.	OEM Nr.	Description	Model	Picture
75044	A 2131600	Relay Valve		 <p>NEW</p>
75045	99701042905	Relay Valve		 <p>NEW</p>
75755	A 3A4233	Levelling Valve		 <p>NEW</p>

Auger Nr.	OEM Nr.	Description	Model	Picture
54414	CR-26722-01	Repair Kit, Fifth Wheel ø31x54/60x89		

**SPARE PARTS FOR
COMMERCIAL VEHICLES**

KASSBOHRER

we keep your business
ON THE MOVE




www.augerautotechnik.de

Auger
GERMANY

Auger Nr.	OEM Nr.	Description	Model	Picture
31203	010-24.21.949-43	Brake Drum		
31204	015-26.21.112-34	Brake Drum		
31205	015-26.85.111-15 B	Brake Drum		
31206	179-25.20.114-11	Brake Drum		
31207	016-26.52.312-01	Brake Drum		
31208	179-24.11.113-06	Brake Drum		

Auger Nr.	OEM Nr.	Description	Model	Picture
52325	8.241.999.330	Pin, Brake Shoe ø36x135		
52330	8.241.129.634	Pin, Brake Shoe ø22/ø25x77		
52322	8.241.999.331	Bushing, Brake Shoe ø36xø40x59		
52323	8.241.000.443	Bushing, Brake Shoe ø36xø40x28		
52333	8.241.000.894	Bushing, Brake Shoe ø32xø36x54		
75882	6.694.030.300	Bushing, Brake Shoe ø30xø34x30		
52329	8.241.129.641	Roller, Brake Shoe ø25,7xø35/ø42x51		
75349	010-24.21.928-15	Roller, Brake Shoe ø19,6/ø36x57		

Auger Nr.	OEM Nr.	Description	Model	Picture
52332	8.241.999.222	Roller, Brake Shoe ø22xø42x59		
75885	015-26.21.116-40	Lock Plate, Brake Shoe		
52311	8.241.021.355	Spring, Brake Shoe ø22x155		
52313	8.241.999.333	Spring, Brake Shoe ø21x105		
52764	8.900.020.184	Spring, Brake Shoe ø23,5x216		
53506	8.241.129.654	Spring, Brake Shoe ø21x178		
75875	6.128.113.017.0 6.128.113.019	Spring, Brake Shoe ø30x162		
75876	010-24.21.994-03	Spring, Brake Shoe ø22x170		

Auger Nr.	OEM Nr.	Description	Model	Picture
52306	8.241.092.582	Spring Pin, Brake Shoe ø12x70		
52307	8.241.129.630	Spring Pin, Brake Shoe ø12x120		
75878	6.125.451.102	Spring Pin, Brake Shoe ø30x148		
52133	8.241.999.300	Retainer, Brake Cam Shaft ø10/ø90xø59,6x21,5		
52134	8.241.016.214	Retainer, Brake Cam Shaft ø8,5/ø90xø59,6x17		
52135	8.241.000.618	Retainer, Brake Cam Shaft ø8,5/ø90xø59,6x17		
52136	8.241.999.301	Retainer, Brake Cam Shaft ø10/ø90xø59,6x21,5		
52143	8.241.016.213	Spherical Bearing, Brake Cam Shaft ø42xø59,6x37		

Auger Nr.	OEM Nr.	Description	Model	Picture
53064	015-26.22.103-51	Bushing, Brake Cam Shaft ø45xø50x62		
53065	015-26.22.101-51	Bushing, Brake Cam Shaft ø45xø50x45		
75874	6.696.089.000	Bushing, Brake Cam Shaft ø45,5xø50,5x55		
75886	8.951.038.200	Repair Kit, Brake Cam Shaft		
75887	8.951.038.200 S	Repair Kit, Brake Cam Shaft		
52162	8.241.000.622	Repair Kit, Brake Cam Shaft		
57806	8.241.037.367	Brake Slack Adjuster Manuel		
58299	8.285.000.090.0 8.285.000.538.0	Brake Slack Adjuster Automatic ø14x175x140° / Bent		





Auger Nr.	OEM Nr.	Description	Model	Picture
58301	8.285.000.213.0	Brake Slack Adjuster Automatic ø14x150x145° / Bent		
58302	8.285.000.089.0 8.285.000.537.0 8.285.000.539.0	Brake Slack Adjuster Automatic ø14x175x140° / Bent		
58311	8.238.000.835.0 8.283.000.648.0 8.285.000.415.0	Brake Slack Adjuster Automatic ø14x250/180/165/150/135x 120x110° / Bent		
52765	8.241.024.267	Spring, Brake Slack Adjuster ø22,5x233		
31202	179-24.11.111-31	Brake Disc		
56019	8.285.388.441	Repair Kit, Brake Caliper, Ror Type		
71481	015-26.21.181-36	Brake Dust Cover ø137xø415x11		

Auger Nr.	OEM Nr.	Description	Model	Picture
71482	015-26.21.191-36	Brake Dust Cover ø137xø415x11		
75871	014-26.52.150-24	Brake Dust Cover ø142xø295		
21017	8.283.050.000.0 8.283.673.000.0	Service Brake Chamber, for Drum Brake, with Repair Kit M16/120,7x117,5/344,5x208 T30 STR 75		
71932	7.788.075.000 7.788.047.000 7.788.005.000	Sensor, ABS		
71934	7.788.075.034.0	Sensor, ABS L: 1000 mm		
75869	015-26.21.115-76	Ring, ABS ø170xø190x12,5		

Auger Nr.	OEM Nr.	Description	Model	Picture
52105	8.241.202.905	Rubber Bushing, Spring ø30xø60x102		
52108	8.241.000.421	Rubber Bushing, Spring ø50xø100,5x130		
70680	8.231.200.030.0	Rubber Bushing, Spring ø30xø65,5x82		
52641	4.771.389.000	Silent Block, Spring ø68x77/170		
52703	4.771.388.000	Silent Block, Spring ø69x97/190		
52168	8.241.000.430	Mounting, Spring 112x158x64		

Auger Nr.	OEM Nr.	Description	Model	Picture
52169	8.241.000.422	Mounting, Spring ø24x69/74x110		
65646	8.241.000.487	U Bolt, Spring M24x3/152x351		
75870	6.125.203.435	U Bolt, Spring M24x3/81x350		
A 34644	4.771.143.000 4.771.170.000 4.771.441.000	Air Spring ø130,8xø210x395		
A 34661	4.731.012.000 4.731.031.000 4.771.427.000 4.771.440.000	Air Spring ø150,8xø240x390		
A 34719	4.731.032.000	Air Spring ø198,1xø300x530		

Auger Nr.	OEM Nr.	Description	Model	Picture
A 34762	4.731.013.000	Air Spring		 
AU 34811-03	4.731.029.000	Air Spring ø156,5xø286x511		
AU 34813-K	4.731.030.000 4.731.033.000	Air Spring ø305x420		
20123	4.731.033.000 S	Piston, Air Spring, for AU 34813-K ø260x178		
20278	-	Repair Kit, Air Spring		 
20279	-	Repair Kit, Air Spring		 

Auger Nr.	OEM Nr.	Description	Model	Picture
15105	82 2629 3000 B	Torque Rod L: 658 <i>Repair Kit: 51137</i>		
51137	8.226.232.066.0	Repair Kit, Axle Rod $\varnothing 85 \times \varnothing 19 / 130$		
51972	8.226.296.069.0	Repair Kit, Axle Rod $\varnothing 75 \times \varnothing 21 / 130$		
20205	8.241.999.135	Shock Absorber, Rear&Front $\varnothing 24 \times 329 / 494$		

Auger Nr.	OEM Nr.	Description	Model	Picture
52175	8.241.021.348	Axle Nut M42x2/42xSW65		
52177	8.241.037.363	Axle Nut M52x2/52xSW80		
57133	016-26.22.119-40	Axle Nut M80x2/30xSW94		
74805	015-26.21.911-40	Wheel Hub, Only Casting Body M145x3/ø22xø335ø280,5		
75288	8.241.000.482	Wheel Hub, Only Casting Body		
75289	8.241.999.058	Wheel Hub, Only Casting Body		
54870	-	Seal Ring, Wheel Hub ø140xø160x13		






Auger Nr.	OEM Nr.	Description	Model	Picture
68104	4.753.656.000.0	Seal Ring, Wheel Hub ø100xø140x14/17		
52074	8.241.021.350	Seal Ring, Wheel Hub ø100xø134x2,5		
52076	8.241.999.460	Seal Ring, Wheel Hub ø104xø136x2,5		
52077	8.241.021.349	Seal Ring, Wheel Hub ø105xø141x2,5		
52079	8.241.999.459	Seal Ring, Wheel Hub ø110xø141x2,5		
52080	8.241.037.365	Seal Ring, Wheel Hub ø113xø155x3,5		
52081	8.241.037.364	Seal Ring, Wheel Hub ø118xø165x3.5		

Auger Nr.	OEM Nr.	Description	Model	Picture
52083	8.241.999.546	Seal Ring, Wheel Hub ø120xø157x2,5		
52087	8.241.999.547 8.241.999.447	Seal Ring, Wheel Hub ø128xø165x2,5		
57022	4.753.054.000	Seal Ring, Wheel Hub ø122xø143x13		
75350	8.241.037.361	Thrust Ring, Wheel Hub ø87xø125/ø166x30		
75877	016-26.22.210-40 016-26.22.118-32	Thrust Ring, Wheel Hub ø96/ø100xø160x24		
53996	8.241.999.299	Thrust Ring, Wheel Hub 6,5-9 Tons ø86xø125x22		
55753	8.241.999.461	Thrust Ring, Wheel Hub 6,5-9 Tons ø86xø114,75/ø142,5x22		
68105	6.691.168.000	Bearing, Wheel Hub ø45xø100x38,5		

Auger Nr.	OEM Nr.	Description	Model	Picture
56616	6.691.159.000	Bearing, Wheel Hub ø80xø140x35,25		
56618	6.691.299.000	Bearing, Wheel Hub ø75xø130x41		
57145	6.691.161.000	Bearing, Wheel Hub ø90xø160x42,5		
69664	6.691.128.000	Bearing, Wheel Hub ø80xø140x28,5		
69672	6.691.453.000	Bearing, Wheel Hub ø105xø160x35		
53059	8.241.999.293	Dust Cover, Wheel Hub ø84,5xø128,5x5		
75872	6.691.161.004	Dust Cover, Wheel Hub ø95xø156x12,5		
75873	6.691.130.003	Dust Cover, Wheel Hub ø90xø156x7,6		


Auger Nr.	OEM Nr.	Description	Model	Picture
52122	8.241.999.292	Hub Cap 6,5-9 Tons M115x2/SW95/500Nm		
52123	8.241.016.244	Hub Cap M115x3/SW95/700Nm		
52124	8.241.999.464	Hub Cap 10-12 Tons M125x2/SW110/500Nm		
52125	8.241.037.372	Hub Cap 10-12 Tons M125x3/SW110/700Nm		
52126	8.241.030.286	Hub Cap 13-14 Tons M135x3/SW120/700Nm		
54395	010-24.21.789-31	Hub Cap M145x3/SW95		
65621	8.241.016.242	Stud 111/M22x2/M22x2		

Auger Nr.	OEM Nr.	Description	Model	Picture
69162	8.241.999.113	Stud 100/M22x2/M22x1,5		
75128	8.241.000.989	Stud 114/M22x2/M22x1,5		
75867	6.125.312.232	Stud M22x1,5/75		
75868	6.125.312.231	Stud M22x1,5/94		
65573	0.174.361.056	Nut, Stud M20x1,5		
75472	8.241.016.243	Nut, Stud M22x2/30		
65564	8.241.999.726	Nut, Stud M22x1,5		

Auger Nr.	OEM Nr.	Description	Model	Picture
65568	0.174.361.058	Nut, Stud M18x1,5		
65623	8.241.000.483	Nut, Stud, Self-Locking M22x2		
65628	8.241.021.358	Nut, Stud, Self-Locking M20x1,5		
65570	0.174.361.105	Rondela, Stud ø20,5		
65571	0.274.361.104	Rondela, Stud ø22,5		

Auger Nr.	OEM Nr.	Description	Model	Picture
10650	8.226.368.000	Drag Link, Right L: 148		
10651	8.226.369.000	Drag Link, Left L: 148		
10001	6.851.531.000 6.851.484.000 6.851.475.000 6.851.480.000 8.226.236.059	Ball Joint L: 125 M30x1,5 RHT		
10002	6.851.485.000 8.226.236.058 6.851.481.000 6.851.476.000	Ball Joint L: 125 M30x1,5 LHT		
10003	6.851.512.000 6.851.517.000	Ball Joint L: 115 M30x1,5 RHT		
10004	6.851.516.000	Ball Joint L: 115 M30x1,5 LHT		

Auger Nr.	OEM Nr.	Description	Model	Picture
10029	6.851.513.000	Ball Joint		
		L: 115 M28x1,5 RHT		
10030	6.851.478.000	Ball Joint		
	6.851.486.000			
	6.851.533.000	L: 125		
	6.851.523.000	M30x1,5 RHT		
	6.851.447.000			
	6.851.488.000			
10065	6.851.491.000	Ball Joint		
		L: 135 M38x1,5 RHT		
10088	6.851.489.000	Ball Joint		
		L: 105 M24x1,5 LHT		
10520	6.851.532.000	Ball Joint		
	6.851.446.000			
	6.851.459.000	L: 125		
	6.851.479.000	M30x1,5 LHT		
	6.851.487.000			

Auger Nr.	OEM Nr.	Description	Model	Picture
21904	8.285.417.000	Air Tank ø246x702/M22x1,5 / Capacity:30 lt		
75044	8.283.421.000.0	Relay Valve		
75045	8.283.609.100.0	Relay Valve		
71552	8.300.100.272	Overflow Valve		

Auger Nr.	OEM Nr.	Description	Model	Picture
75881	6.694.030.400	Bushing, Trailer Coupling ø30xø34x40		 
75883	010-16.12.110-32 010-16.21.103-02	Bushing, Trailer Coupling ø30xø45x28		 
75884	010-16.21.102-02 010-16.12.110-22	Bushing, Trailer Coupling ø30xø45x26,5		 
75879	418-16.21.121-52	Towing Hook Pin, Trailer Coupling ø30x192		 
75880	418-16.21.111-52	Towing Hook Pin, Trailer Coupling ø30x184		 

**SPARE PARTS FOR
COMMERCIAL VEHICLES**

ROR

we keep your business
ON THE MOVE



www.augerautotechnik.de

Auger
GERMANY

Auger Nr.	OEM Nr.	Description	Model	Picture
31209	210 21 114	Brake Drum	TM Series TA / TC Series	
31210	210 18 986	Brake Drum	TM Series TA / TC Series	
31211	210 18 963	Brake Drum	TAMBOURS MOYEUX 310x190 - 15"	
31212	212 11 030	Brake Drum	TM Series	
31213	212 11 966	Brake Drum	TM Series	
31215	210 20 448	Brake Drum	TM Series TAMBOURS MOYEUX 310x190 - 15"	
31216	212 09 723	Brake Drum	TM Series	

Auger Nr.	OEM Nr.	Description	Model	Picture
55843	683 71 524	Brake Shoe, Brake Drum, Unlined, Thick 8mm, Left ø410x7"/175mm		
55844	683 71 525	Brake Shoe, Brake Drum, Unlined, Thick 8mm, Right ø410x7"/175mm		
55845	683 71 526	Brake Shoe, Brake Drum, Unlined, Thick 8mm, Left ø410x8"/200mm		
55846	683 71 527	Brake Shoe, Brake Drum, Unlined, Thick 8mm, Right ø410x8"/200mm		
65430	683 70 733	Brake Shoe, Brake Drum, Unlined, Thin 5mm, Left ø410x7"/175mm		
65336	683 70 734	Brake Shoe, Brake Drum, Unlined, Thin 5mm, Right ø410x7"/175mm		
65337	683 70 735	Brake Shoe, Brake Drum, Unlined, Thin 5mm, Left ø410x8"/200mm		






Auger Nr.	OEM Nr.	Description	Model	Picture
65338	683 70 736	Brake Shoe, Brake Drum, Unlined, Thin 5mm, Right ø410x8"/200mm		
65339	683 70 737	Brake Shoe, Brake Drum, Unlined, Thin 5mm, Left ø410x9"/225mm		
65431	683 70 738	Brake Shoe, Brake Drum, Unlined, Thin 5mm, Right ø410x9"/225mm		
65332	-	Brake Shoe, Brake Drum, Unlined ø410x7"/175mm		
65432	683 71 528	Brake Shoe, Brake Drum, Unlined, Thick 8mm, Left ø410x9"/225mm		
65433	683 71 529	Brake Shoe, Brake Drum, Unlined, Thick 8mm, Right ø410x9"/225mm		
65340	683 71 520	Brake Shoe, Brake Drum, Unlined, Thick 8mm, Left ø410x5"/125mm		









Auger Nr.	OEM Nr.	Description	Model	Picture
65445	683 71 521	Brake Shoe, Brake Drum, Unlined, Thick 8mm, Right ø410x5"/125mm		
65435	683 71 522	Brake Shoe, Brake Drum, Unlined, Thick 8mm, Left ø410x6"/150mm		
65446	683 71 523	Brake Shoe, Brake Drum, Unlined, Thick 8mm, Right ø410x6"/150mm		
65434	683 70 729	Brake Shoe, Brake Drum, Unlined, Thin 5mm, Left ø410x5"/125mm		
65444	683 70 730	Brake Shoe, Brake Drum, Unlined, Thin 5mm, Right ø410x5"/125mm		
65334	683 70 731	Brake Shoe, Brake Drum, Unlined, Thin 5mm, Left ø410x6"/150mm		
65443	683 70 732	Brake Shoe, Brake Drum, Unlined, Thin 5mm, Right ø410x6"/150mm		

Auger Nr.	OEM Nr.	Description	Model	Picture
65441	-	Brake Shoe, Brake Drum, Unlined ø410x8"/200mm		
65421	152 06 005	Brake Shoe, Brake Drum, Unlined ø300x190mm		
65425	152 05 191	Brake Shoe, Brake Drum, Unlined ø420x220mm		
66580	152 05 533	Brake Shoe, Brake Drum, Unlined, Thin 5mm ø420x180mm		
65429	RBSK1493	Brake Shoe Kit, Brake Drum, Unlined ø410x8"/200mm		
65342	RBSK1496	Brake Shoe Kit, Brake Drum, Unlined ø410x7"/175mm		
53039	212 05 204	Pin, Brake Shoe ø31,7x67,5	T, U, TH & TM Series	

Auger Nr.	OEM Nr.	Description	Model	Picture
52921	210 20 039	Pin, Brake Shoe ø31,7x70	U, TM Series	
53777	-	Pin, Brake Shoe, for 52916, 53790, 53791 and 53802 ø25,5xø28x57	TE 9000/9300, TM Series LM & LC Series TA, TC Series	
53784	-	Pin, Brake Shoe, for 53790, 53791 and 53803 ø19/ø19,7x56	TE 9000/9300, TM Series LM, LC, LMC Series	
52904	1259N274 212 05 193 G	Pin, Brake Shoe ø25,5xø31,7x56,5	T, TE, TA, TC, U, TH & TM Series Series III	
53775	212 05 193 S	Pin, Brake Shoe, Without O-Ring Seat ø25,5xø31,7x56,5	T, TE, TA, TC, U, TH & TM Series Series III	
54405	212 05 193 S1	Pin, Brake Shoe, With O-Rings ø25,5xø31,7x56,5	T, TE, TA, TC, U, TH & TM Series Series III	
68427	1259W205	Pin, Brake Shoe 14G 7/16 x ø31.6x149,5		
68663	1259K1181	Pin, Brake Shoe		

Auger Nr.	OEM Nr.	Description	Model	Picture
70746	1259X76	Pin, Brake Shoe ø31,7x111,5		
53776	-	Bushing, Brake Shoe, for 52916, 53790, 53791 and 53802 ø28xø35x38	TE 9000/9300, TM Series LM & LC Series TA, TC Series	
53783	-	Bushing, Brake Shoe, for 53790, 53791 and 53803 ø20xø31,7x32,5	TE 9000/9300, TM Series LM, LC, LMC Series	
52910	210 16 666 A	Bushing, Brake Shoe ø32xø35x36,5	Series III TE 9000, TE 9300 Series T, U, TH, TM Series	
68664	1225U827	Bushing, Brake Shoe		
52368	210 06 610	Roller, Brake Shoe ø19/ø31,7x55,5	T, U, TH, TM Series TA & TC Series	
68428	1779X180	Roller, Brake Shoe ø19/ø38x63		
68665	2297Q8233	Roller, Brake Shoe		








Auger Nr.	OEM Nr.	Description	Model	Picture
53210	210 23 758	Lock Plate, Brake Shoe ø19,5x37x55	TE 9000/9300 Series T, U, TH, TM Series Series III	
54831	-	Lock Plate, Brake Shoe, for 53799 and 53800 ø19,5x52,5	TM Series All axles with 420mm brakes	
52906	212 20 859	Spring, Brake Shoe ø36x169,5	TM Series Series III	
53788	210 22 348	Spring, Brake Shoe ø30x155	TM Series	
52785	212 21 224	Spring, Brake Shoe ø34x220	TE 9000 / 9300 Series T, U, TH & TM Series LM & LMC Series TA Series	
52784	212 05 194 2258H1230 2258Q615	Spring, Brake Shoe ø19x140	Series III TE 9000/9300, T, TA, U, TH , TM Series LM & LMC Series	
53487	2258H580	Spring, Brake Shoe ø24x216	"12-1/4" "RD brakes" "15" "RD brakes"	
53779	210 23 389	Spring, Brake Shoe ø29,5x201	TM Series , INDAIR	



Auger Nr.	OEM Nr.	Description	Model	Picture
57146	167069	Spring, Brake Shoe ø31x213		
68317	2258U619	Spring, Brake Shoe ø27,5x212,5	Q plus brakes.	
68329	2258Y1507 6C462L371AA	Spring, Brake Shoe ø30,5x235		
68666	2258Y1273	Spring, Brake Shoe		
52369	210 06 614	Spring Pin, Brake Shoe ø6,3x70		
53802	152 26 632	Repair Kit, Brake Shoe ø25,5/ø27,7x57	TE 9000 / 9300, TM Series LM, LC, LMC Series	
53803	152 26 262	Repair Kit, Brake Shoe ø19/ø19,7x56	LM, LC, LMC Series	
53790	AXL-LM4	Repair Kit, Brake Shoe ø25,5/ø27,7x57	LM & LMC Series	








Auger Nr.	OEM Nr.	Description	Model	Picture
53791	AXL-LM1	Repair Kit, Brake Shoe ø38,5/ø42	1_2 Axle set suitable for: LM & LMC axles	
53798	152 05 204	Repair Kit, Brake Shoe, Double Set ø31,7x67,5	T, U, TH & TM Series	
52916	AXL-125	Repair Kit, Brake Shoe ø19/ø31,7x55,5	TE 9000/9300, TM Series	
53799	AXL-7	Repair Kit, Brake Shoe ø19/ø31,7x55,5	TM Series	
53800	AXL-14	Repair Kit, Brake Shoe ø25,5xø31,7x57	All axles with 420mm brakes	
53801	-	Repair Kit, Brake Shoe ø19/ø31,7x55,5 <i>Pin: 52904</i> <i>Spring: 52784-52785</i> <i>Bushing: 52910</i> <i>Lock Plate: 53210</i>	T, U, TH, TM Series	
52661	AXL-126	Repair Kit, Brake Shoe ø19/ø31,7x55,5	T, U, TH, TM Series	








Auger Nr.	OEM Nr.	Description	Model	Picture
53807	212 21 224 S	Repair Kit, Brake Shoe ø34x220 <i>Spring: 52785</i>	TE 9000 / 9300 Series T, U, TH & TM Series LM & LMC Series TA Series	
53810	-	Repair Kit, Brake Shoe ø19/ø31.7x55.5 <i>Roller: 52368-53775 Spring: 52784-53779 Bushing: 52910 Lock Plate: 53210 Spring Pin: 54916</i>		
53811	-	Repair Kit, Brake Shoe ø19/ø31.7x55.5 <i>Roller: 52368 Spring: 53788 Bushing: 52910 Pin: 53039 Spring Pin: 54916</i>		
53812	-	Repair Kit, Brake Shoe ø25.5/ø31.7x57 <i>Roller: 53775 Spring: 52784-53779 Bushing: 52910 Lock Plate: 53210 Spring Pin: 54916</i>		
53813	-	Repair Kit, Brake Shoe ø19/ø31.7x55.5 <i>Roller: 52368 Spring: 53779 Bushing: 52910 Pin: 52921 Spring Pin: 54916</i>		
68667	KIT8846HDS	Repair Kit, Brake Shoe		
53797	AXL-6	Repair Kit, Brake Shoe, Single Set ø31,7x67,5	T, U, TH & TM Series	

Auger Nr.	OEM Nr.	Description	Model	Picture
52662	AXL-106	Repair Kit, Brake Shoe ø19/ø31,7x55,5	T, U, TH, TM Series	
52915	AXL-117	Repair Kit, Brake Shoe ø19/ø31,7x55,5	Series III	
53778	210 06 563	Retainer, Brake Cam Shaft ø70x12,5	TM Series	
52257	152 13 430	Spherical Bearing, Brake Cam Shaft ø12,5/63xø38x45	TE , TH, TM Series LM & LMC Series	
52258	152 20 224 152 24 821	Spherical Bearing, Brake Cam Shaft ø42x40	TE, TM Series LM & LMC Series	
53040	A 23105Q1213	Spherical Bearing, Brake Cam Shaft ø40/ø41,5x46	TA, TM, TC Series LM, LC, LMC Series	
52259	152 04 595	Spherical Bearing, Brake Cam Shaft ø12,5/63xø36,5x61	TM Series	

Auger Nr.	OEM Nr.	Description	Model	Picture
52210	210 06 585	Spherical Bearing, Brake Cam Shaft ø38xø70x63	T, U, TH, TM Series	
52211	212 04 602 210 16 723	Bushing, Brake Cam Shaft ø38xø48x22,5	T, U, TH, TM Series	
52212	212 04 601 210 16 722	Bushing, Brake Cam Shaft ø38xø48x22,5	T, U, TH, TM Series	
52247	212 04 703	Bushing, Brake Cam Shaft ø38,5xø48x50,5	TM Self Steer Axle Universal Self Steer Axle	
52249	212 09 990	Bushing, Brake Cam Shaft ø43,5xø48x50	T, U, TH & TM Series Universal Self Steer Axle	
52248	212 04 849	Dust Cover, Brake Cam Shaft ø36,5x26	TE & TM Series TA & TC Series LM & LMC Series	
52250	212 05 667	Dust Cover, Brake Cam Shaft ø36,5/ø48x10	TA & TC Series TE, TM Series LM, LC, LMC Series	





Auger Nr.	OEM Nr.	Description	Model	Picture
54872	1229 K4795	Seal Ring, Brake Cam Shaft ø40,5xø67,5x8	All axles with 420 mm brakes	
53066	AXL-124	Repair Kit, Brake Cam Shaft ø36,5/ø48x10/26	All axles with 310/350 mm brakes	
53789	AXL-123	Repair Kit, Brake Cam Shaft ø36,5/ø48x10/26	All axles with 420 mm brakes	
52260	AXL-132	Repair Kit, Brake Cam Shaft ø38/ø43,5xø48x50	T, U, TH und TM Series	
52716	AXL-112	Repair Kit, Brake Cam Shaft ø36,5/ø37,2xø48x22,5	TE, TM Series	
52717	AXL-111	Repair Kit, Brake Cam Shaft ø36,5/ø37,2xø48x22,5	T, U, TH, TM Series	
53067	AXL-131	Repair Kit, Brake Cam Shaft ø38xø70x63,5	T, U, TH, TM Series	

Auger Nr.	OEM Nr.	Description	Model	Picture
53796	-	Repair Kit, Brake Cam Shaft ø36,5/ø37,2xø48x22,5 <i>Bushing: 52211-52212</i> <i>Spherical Bearing: 52210</i> <i>Retainer: 53778</i>	TM Series	
52262	106 90 588	Repair Kit, Brake Cam Shaft ø36,5/ø37,2xø48x22,5	TM Series	
52261	AXL-122	Repair Kit, Brake Cam Shaft ø38,5/ø42	TE 9000/9300, TM Series	
53041	AXL-140	Repair Kit, Brake Cam Shaft ø38/ø40/ø41,5	All axles with 420 mm brakes	
53808	-	Repair Kit, Brake Cam Shaft ø36.5x61/ø43.5xø48x50 <i>Spherical Bearing: 52259</i> <i>Bushing: 529249</i>		
53809	-	Repair Kit, Brake Cam Shaft ø37.2xø48x22.5 <i>Bushing: 52211-52212</i>		
58326	212 29 249 212 23 694 MAS-9249	Brake Slack Adjuster Automatic ø14x205/153/140/127/115x 60° / Saddle Type		

Auger Nr.	OEM Nr.	Description	Model	Picture
58337	212 27 325 212 29 289 MAS-9289	Brake Slack Adjuster Automatic ø14x250/180/155/140/125/ 105x130° / Bent		
58336	212 19 681	Brake Slack Adjuster Manual		
54915	212 10 215	Spring, Brake Slack Adjuster ø23x145	TM, TE, TA Series LM, LC Series	
55198	681 91 518 165018	Bushing, Brake Adjuster ø38,3xø43x26	FCSS/A DRUM BRAKE ASSEMBLY 410x125 410x150 410x175 410x200 410x225	
68318	1225L1208	Bushing, Brake Adjuster ø38,5xø48x30		
65357	2258D1122	Spring, Brake Adjuster, for 55847 and 65359 ø28x247		
65358	2258F1306	Spring, Brake Adjuster, for 55847 and 65359 ø21,5x220		

Auger Nr.	OEM Nr.	Description	Model	Picture
51711	681 92 115 167090	Spring, Brake Adjuster 73x295	FCSS/A DRUM BRAKE ASSEMBLY 410x125 410x150 410x175 410x200 410x225	
55709	681 92 487 137075	Spring Pin, Brake Adjuster ø17x72		
56928	1205C1667 1205B2004	Dust Cover, Brake Adjuster ø14,5xø52,5x17	"12-1/4" RD brakes" "15" RD brakes"	
57263	1205E2683 6C462B024AB	Dust Cover, Brake Adjuster ø25x11		
65324	-	Dust Cover, Brake Adjuster ø25xø57x10,5		
53961	681 92 410	Dust Cover, Brake Adjuster ø36xø63x19	FCSS/A DRUM BRAKE ASSEMBLY 410x125 410x150 410x175 410x200 410x225	
70587	1205Y2001	Dust Cover, Brake Adjuster		

Auger Nr.	OEM Nr.	Description	Model	Picture
56994	RBSK2030	Repair Kit, Brake Adjuster ø16xø57,5x32		
70611	RBSK1625-1	Repair Kit, Brake Adjuster		
70612	RBSK0251-1B	Repair Kit, Brake Adjuster		
70605	RBSK2031-1	Repair Kit, Brake Adjuster		
55218	681 92 565 ST1222 ST4014 A164061	Repair Kit, Brake Adjuster, Left ø55x112	FCSS/A DRUM BRAKE ASSEMBLY 410x125 410x150 410x175 410x200 410x225	
55219	ST4013 681 92 566 A164062	Repair Kit, Brake Adjuster, Right ø55x112	FCSS/A DRUM BRAKE ASSEMBLY 410x125 410x150 410x175 410x200 410x225	
55223	SP7984	Repair Kit, Brake Adjuster ø30x40	FCSS/A DRUM BRAKE ASSEMBLY 410x125 410x150 410x175 410x200 410x225	

Auger Nr.	OEM Nr.	Description	Model	Picture
55716	ST1038	Repair Kit, Brake Adjuster, Left	FCSS/A DRUM BRAKE ASSEMBLY 410x125 410x150 410x175 410x200 410x225	
55717	ST1039	Repair Kit, Brake Adjuster, Right	FCSS/A DRUM BRAKE ASSEMBLY 410x125 410x150 410x175 410x200 410x225	
55718	SP8540	Repair Kit, Brake Adjuster	FCSS/A DRUM BRAKE ASSEMBLY 410x125 410x150 410x175 410x200 410x225	
55722	ST1053	Repair Kit, Brake Adjuster		
55220	ST1037	Repair Kit, Brake Adjuster, Right	FCSS/A DRUM BRAKE ASSEMBLY 410x125 410x150 410x175 410x200 410x225	
55222	ST1036	Repair Kit, Brake Adjuster, Left	FCSS/A DRUM BRAKE ASSEMBLY 410x125 410x150 410x175 410x200 410x225	

Auger Nr.	OEM Nr.	Description	Model	Picture
55713	ST1035	Repair Kit, Brake Adjuster	FCSS/A DRUM BRAKE ASSEMBLY 410x125 410x150 410x175 410x200 410x225	
55714	ST1034	Repair Kit, Brake Adjuster	FCSS/A DRUM BRAKE SIMPLEX AIR CAM OR Z CAM	
55715	ST1033	Repair Kit, Brake Adjuster	FCSS/A DRUM BRAKE ASSEMBLY 410x125 410x150 410x175 410x200 410x225	
55849	RBSK1407	Repair Kit, Brake Adjuster		
70609	RBSK1557-1	Repair Kit, Brake Adjuster		
56996	RBSK1606 RBSK1599-1	Repair Kit, Brake Adjuster		
56997	RBSK1607 RBSK1600-1	Repair Kit, Brake Adjuster		

Auger Nr.	OEM Nr.	Description	Model	Picture
70590	RBSK0248-1B	Repair Kit, Brake Adjuster Right		
70591	RBSK0249-1B	Repair Kit, Brake Adjuster Left		
70592	RBSK1584-1 RBSK1595-1	Repair Kit, Brake Adjuster Right		
70593	RBSK1585-1 RBSK1596-1	Repair Kit, Brake Adjuster Left		
70596	RBSK1546-1	Repair Kit, Brake Adjuster Left		
70597	RBSK1547-1	Repair Kit, Brake Adjuster Right		
70604	RBSK2012-1	Repair Kit, Brake Adjuster		

Auger Nr.	OEM Nr.	Description	Model	Picture
54273	RBSK0502	Repair Kit, Brake Adjuster		
56993	RBSK1560	Repair Kit, Brake Adjuster		
55847	RBSK1408	Repair Kit, Brake Adjuster		
55072	SP8586	Repair Kit, Brake Adjuster ø30x233/ø19,5x205	SIMPLEX ALT/AW DRUM BRAKE 360x140 360x160 360x170	
55123	SP7972	Repair Kit, Brake Adjuster ø29,5x224/ø25x190	SIMPLEX ALT/AW DRUM BRAKE 360x140 360x160 360x170	
55124	SP8994 ST1190	Repair Kit, Brake Adjuster ø29,5x212/ø19,5x197	SIMPLEX ALT/AW DRUM BRAKE 325x100 325x150	
65359	RBSK2128	Repair Kit, Brake Adjuster ø21,5x220/ø28x245		

Auger Nr.	OEM Nr.	Description	Model	Picture
70613	RBSK1561-1	Repair Kit, Brake Adjuster		
57000	RBSK1558	Repair Kit, Brake Adjuster 26,5x28,5x45		
57001	RBSK1409	Repair Kit, Brake Adjuster 26,5x28,5x45		
70608	RBSK0343-1B	Repair Kit, Brake Adjuster		
54276	RBSK0250 RBSK1314-1	Repair Kit, Brake Adjuster ø34/ø38x120		
55848	RBSK2051 RBSK1255	Repair Kit, Brake Adjuster ø34/ø42x150x12°		
65347	-	Repair Kit, Brake Adjuster ø34/ø42x150x14°		

Auger Nr.	OEM Nr.	Description	Model	Picture
56157	SP9662	Repair Kit, Brake Caliper	C DUCO TYPE CALIPER Le DUCO TYPE CALIPER	
70594	RBSK1533-1	Repair Kit, Brake Adjuster Right		
70595	RBSK1534-1	Repair Kit, Brake Adjuster Left		
70598	RBSK1481-1	Repair Kit, Brake Adjuster Left		
70599	RBSK1482-1	Repair Kit, Brake Adjuster Right		
56998	RBSK1428	Repair Kit, Brake Adjuster		
56999	RBSK1563	Repair Kit, Brake Adjuster		

Auger Nr.	OEM Nr.	Description	Model	Picture
55706	681 91 510 A164052	Adjusting Device, Brake Adjuster, Left ø36x58	FCSS/A DRUM BRAKE ASSEMBLY 410x125 410x150 410x175 410x200 410x225	
55707	681 91 511 A164055	Adjusting Device, Brake Adjuster, Right ø36x58	FCSS/A DRUM BRAKE ASSEMBLY 410x125 410x150 410x175 410x200 410x225	
68330	A164040	Cross Shaft, Brake Adjuster ø22,3x100,5		
55208	642 25 252 137074	Pin, Brake Adjuster ø12,6x59,9	FCSS/A DRUM BRAKE ASSEMBLY "15½ x 4¼" ¹⁴ "15½ x 5" ¹⁴ "15½ x 6" ¹⁴ "15½ x 7" ¹⁴ "15½ x 8" ¹⁴	
55708	681 91 065 166062	Cover, Brake Adjuster 82x118x24	FCSS/A DRUM BRAKE ASSEMBLY 410x125 410x150 410x175 410x200 410x225	
60331	682 00 114	Seal Ring, Brake Adjuster ø37xø47,5x5,5	FCSS/A DRUM BRAKE ASSEMBLY 410x125 410x150 410x175 410x200 410x225	
65353	A3280K8435 6C462045AA	Guide Screw, Brake Adjuster 26,5/M16x1,5		

Auger Nr.	OEM Nr.	Description	Model	Picture
65352	A1779M195	Guide Screw, Brake Adjuster 26,5/M14x2	15 in. brakes	
57002	R801700 A12297M6461	Guide Pawl, Brake Adjuster Thin Gear M14x2/29,5		
60239	A22297U4597	Guide Pawl, Brake Adjuster Thin Gear M14x2/35		
65350	A2297N6358 6C462L380AA	Guide Pawl, Brake Adjuster, Thin Gear 36/M16x1,5		
65351	A2297U4597	Guide Pawl, Brake Adjuster, Large Gear 36/M16x1,5		
65348	3280T8964 6C462B003AA	Actuator Sleeve, Brake Adjuster, Large Gear ø30,5x48,7/M22x1,5		
65349	3280V8368	Actuator Sleeve, Brake Adjuster, Thin Gear ø30,5x48,7/M22x1,5		

Auger Nr.	OEM Nr.	Description	Model	Picture
57654	2297W2857	Actuator Sleeve, Brake Adjuster, Thin Gear ø11xø23,3x55,5		
60216	3280S8131	Actuator Sleeve, Brake Adjuster, Thin Gear W 14G 7/16" /ø30,5x36,75		
65314	2297H8354 6C462A170BA	Adjuster Plunger, Brake Adjuster, Left ø38,5x71,3		
65315	2297J8356 6C462A170AA	Adjuster Plunger, Brake Adjuster, Right ø38,5x71,3		
65313	2297J4820	Adjuster Plunger, Brake Adjuster, Left ø34,9x70		
65450	2297K4821	Adjuster Plunger, Brake Adjuster, Right ø34,9x70		

Auger Nr.	OEM Nr.	Description	Model	Picture
68331	173007 3280W8369 6C462A170CA	Adjuster Plunger, Brake Adjuster ø30.5xø38.5x55.5		
60215	3280Y8163	Adjuster Plunger, Brake Adjuster ø30,5xø34x49,25	"15 in. RD, RDA and RDH rear brakes"	
65316	1259A1015	Adjuster Plunger, Brake Adjuster, Left ø35x38		
65412	1259Z1014	Adjuster Plunger, Brake Adjuster, Right ø35x38		
60231	A22297E5907 A2297S8287 6C462A105AA	Adjusting Screw, Brake Adjuster M22x1,5/60		
60238	A164002 A2297L3158	Adjusting Screw, Brake Adjuster W 14G 7/16"		
65344	A12247U47	Wedge, Brake Adjuster ø34/ø38x135		
65345	A2247L1000 6C462B024AA	Wedge, Brake Adjuster ø34/ø42x150x14°		

Auger Nr.	OEM Nr.	Description	Model	Picture
65346	A2247M1001	Wedge, Brake Adjuster ø34/ø42x150x12°		
60346	A2247U47	Wedge, Brake Adjuster 16,25x120		
65306	681 92 612 137076	Spring Clamp, Brake Adjuster 37x75x25	FCSS/A DRUM BRAKE ASSEMBLY 410x125 410x150 410x175 410x200 410x225	
65355	2257M1001 1718D134 2257D108	Clamp, Brake Adjuster 8/10x28,5x27x41	15 in. RD brakes	
65354	2257P1004 2257Y1143 6C462D160AA	Clamp, Brake Adjuster ø9x25x30x38		
60545	166065 681 92 411	Plug, Brake Adjuster ø14,3xø36,5x31,7		
31000	212 24 263	Brake Disc	TM Series TM DX 195 TM Elsa 195 LM DX 195 19.5 Wheel Dia.	
31001	212 25 115	Brake Disc	LM DX 195 LM/LC Series	

Auger Nr.	OEM Nr.	Description	Model	Picture
31002	212 12 670	Brake Disc	TM SERIES	 
31003	212 27 349	Brake Disc	LM/LMC Series LM DX 195 19.5 Wheel Dia. LM/LC Series	
31214	683 23 825	Brake Disc	LM D Duco Axial (M18) TA D Duco Axial (M18) LM D Duco Axial (M20) TA D Duco Axial (M20)	
73632	SJ4093	Spring Clamp, Brake Disc Pad	D DUCO RADIAL D DUCO AXIAL	 
70705	-	Sensor, Brake Disc Pad, Left, Rear	ELSA2 TYPE CALIPER ELSA2 RADIAL TYPE CALIPER ELSA195 TYPE CALIPER ELSA225 TYPE CALIPER	 
70706	-	Sensor, Brake Disc Pad, Right, Rear	ELSA2 TYPE CALIPER ELSA2 RADIAL TYPE CALIPER ELSA195 TYPE CALIPER ELSA225 TYPE CALIPER	 
70707	-	Sensor, Brake Disc Pad, Front	ELSA2 TYPE CALIPER ELSA2 RADIAL TYPE CALIPER ELSA195 TYPE CALIPER ELSA225 TYPE CALIPER	 
70708	-	Sensor, Brake Disc Pad, Rear	ELSA2 TYPE CALIPER ELSA2 RADIAL TYPE CALIPER ELSA195 TYPE CALIPER ELSA225 TYPE CALIPER	 

Auger Nr.	OEM Nr.	Description	Model	Picture
70709	-	Sensor, Brake Disc Pad, Right, Front	ELSA2 TYPE CALIPER ELSA2 RADIAL TYPE CALIPER ELSA195 TYPE CALIPER ELSA225 TYPE CALIPER	
70710	-	Sensor, Brake Disc Pad, Right, Rear	ELSA2 TYPE CALIPER ELSA2 RADIAL TYPE CALIPER ELSA195 TYPE CALIPER ELSA225 TYPE CALIPER	
70711	-	Sensor, Brake Disc Pad, Left, Front	ELSA2 TYPE CALIPER ELSA2 RADIAL TYPE CALIPER ELSA195 TYPE CALIPER ELSA225 TYPE CALIPER	
70712	-	Sensor, Brake Disc Pad, Left, Rear	ELSA2 TYPE CALIPER ELSA2 RADIAL TYPE CALIPER ELSA195 TYPE CALIPER ELSA225 TYPE CALIPER	
70713	-	Sensor, Brake Disc Pad, Right, Front	ELSA2 TYPE CALIPER ELSA2 RADIAL TYPE CALIPER ELSA195 TYPE CALIPER ELSA225 TYPE CALIPER	
70714	-	Sensor, Brake Disc Pad, Right, Rear	ELSA2 TYPE CALIPER ELSA2 RADIAL TYPE CALIPER ELSA195 TYPE CALIPER ELSA225 TYPE CALIPER	
70715	-	Sensor, Brake Disc Pad, Left, Front	ELSA2 TYPE CALIPER ELSA2 RADIAL TYPE CALIPER ELSA195 TYPE CALIPER ELSA225 TYPE CALIPER	
70716	-	Sensor, Brake Disc Pad, Left, Rear	ELSA2 TYPE CALIPER ELSA2 RADIAL TYPE CALIPER ELSA195 TYPE CALIPER ELSA225 TYPE CALIPER	

Auger Nr.	OEM Nr.	Description	Model	Picture
74450	-	Sensor, Brake Disc Pad, Left		
74451	-	Sensor, Brake Disc Pad, Right		
74452	-	Sensor, Brake Disc Pad, Right		
74453	-	Sensor, Brake Disc Pad, Left		
74454	-	Sensor, Brake Disc Pad, Right		 Sample
74455	-	Sensor, Brake Disc Pad, Left		
74456	-	Sensor, Brake Disc Pad, Right		 Sample
74457	-	Sensor, Brake Disc Pad, Left		 Sample

Auger Nr.	OEM Nr.	Description	Model	Picture
70700	-	Bushing, Brake Caliper ø10xø12/ø18x7		
70697	68320507PK10	Dust Cover, Brake Caliper ø42,5xø81,5x9,5		
56004	-	Bearing, Brake Caliper ø70,5xø94,5x4	D3 TYPE CALIPER	
56006	-	Bearing, Brake Caliper ø45x52x20	DX195 TYPE CALIPER	
56005	683 21 678 PK10 683 21 678	Lock Plate, Brake Caliper ø67x110x12,5	ELSA1 TYPE CALIPER ELSA1 RADIAL TYPE CALIPER	
57174	-	Piston Housing Assembly, Brake Caliper 110x68,5	ELSA2 TYPE CALIPER	
57161	683 22 900 PK10	Lock Plate, Brake Caliper 58x120x5	D DUCO RADIAL TYPE CALIPER	
70698	68322485PK10	Lock Plate, Brake Caliper 58x98x5		

Auger Nr.	OEM Nr.	Description	Model	Picture
70701	-	Shaft, Brake Caliper ø45xø68x102,50		
70699	-	Adjusting Mechanism, Brake Caliper ø47/110x66/173,5x68		
70688	-	Repair Kit, Brake Caliper, Right		
70689	-	Repair Kit, Brake Caliper, Left		
76246	-	Repair Kit, Brake Caliper		
71444	MCK1024	Repair Kit, Brake Caliper, Right	D LISA TYPE CALIPER	
70691	MCK1023	Repair Kit, Brake Caliper, Left	D LISA TYPE CALIPER	

Auger Nr.	OEM Nr.	Description	Model	Picture
57586	-	Repair Kit, Brake Caliper, Left ø45x83	C LISA TYPE CALIPER D LISA TYPE CALIPER	
57587	-	Repair Kit, Brake Caliper, Right ø45x83	C LISA TYPE CALIPER D LISA TYPE CALIPER	
56029	MCK1151 MCK1021	Repair Kit, Brake Caliper, Left	C LISA TYPE CALIPER D LISA TYPE CALIPER	
56030	MCK1152 MCK1022	Repair Kit, Brake Caliper, Right	C LISA TYPE CALIPER D LISA TYPE CALIPER	
57597	-	Repair Kit, Brake Caliper, Left	ELSA1 TYPE CALIPER ELSA1 RADIAL TYPE CALIPER	
57598	-	Repair Kit, Brake Caliper, Right	ELSA1 TYPE CALIPER ELSA1 RADIAL TYPE CALIPER	
56047	SJ4102	Repair Kit, Brake Caliper, Left	C DUCO TYPE CALIPER D DUCO RADIAL TYPE CALIPER D DUCO AXIAL TYPE CALIPER LE DUCO TYPE CALIPER	

Auger Nr.	OEM Nr.	Description	Model	Picture
56048	SJ4103	Repair Kit, Brake Caliper, Right	C DUCO TYPE CALIPER D DUCO RADIAL TYPE CALIPER D DUCO AXIAL TYPE CALIPER LE DUCO TYPE CALIPER	
55720	MCK1111	Repair Kit, Brake Caliper	C DUCO TYPE CALIPER D DUCO TYPE CALIPER Le DUCO TYPE CALIPER	
55721	MCK1112	Repair Kit, Brake Caliper	C DUCO TYPE CALIPER D DUCO TYPE CALIPER Le DUCO TYPE CALIPER	
55719	MCK1113	Repair Kit, Brake Caliper	D DUCO TYPE CALIPER	
70696	SJ4110	Repair Kit, Brake Caliper	D DUCO RADIAL TYPE CALIPER	
57591	-	Repair Kit, Brake Caliper, Right	D3 TYPE CALIPER	
73416	-	Repair Kit, Brake Caliper, Left	D3 TYPE CALIPER	

Auger Nr.	OEM Nr.	Description	Model	Picture
56122	-	Repair Kit, Brake Caliper, Left 48 Teeth	D3 TYPE CALIPER	
56123	-	Repair Kit, Brake Caliper, Right 48 Teeth	D3 TYPE CALIPER	
56124	-	Repair Kit, Brake Caliper, Left 26 Teeth	D3 TYPE CALIPER	
56125	-	Repair Kit, Brake Caliper, Right 26 Teeth	D3 TYPE CALIPER	
56018	SJ4114	Repair Kit, Brake Caliper, Right	C LISA TYPE CALIPER D LISA TYPE CALIPER	
56040	SJ4113 MCK4113	Repair Kit, Brake Caliper, Left	C LISA TYPE CALIPER D LISA TYPE CALIPER	
56033	SJ4073	Repair Kit, Brake Caliper, Left M27x3 L	DX195 TYPE CALIPER C LISA TYPE CALIPER	

Auger Nr.	OEM Nr.	Description	Model	Picture
56034	SJ4074	Repair Kit, Brake Caliper, Right M27x3 R	C LISA TYPE CALIPER D LISA TYPE CALIPER	
56037	SJ1091	Repair Kit, Brake Caliper	LRG600 LRG601 LRG608 LRG609 LRG610 LRG611 LRG620 LRG621	
56038	SJ1092	Repair Kit, Brake Caliper	LRG602 LRG603 LRG608 LRG609 LRG610 LRG611 LRG628 LRG629 LRG634	
56039	SJ1215	Repair Kit, Brake Caliper	LRG612 LRG613	
57596	SJ1214	Repair Kit, Brake Caliper	LRG614 LRG615	
56139	-	Repair Kit, Brake Caliper, Left	ELSA1 TYPE CALIPER	
56140	-	Repair Kit, Brake Caliper, Right	ELSA1 TYPE CALIPER	

Auger Nr.	OEM Nr.	Description	Model	Picture
56131	-	Repair Kit, Brake Caliper	D3 TYPE CALIPER	
56132	-	Repair Kit, Brake Caliper	D3 TYPE CALIPER	
56114	-	Repair Kit, Brake Caliper	D LISA TYPE CALIPER C LISA TYPE CALIPER	
56115	-	Repair Kit, Brake Caliper	D LISA TYPE CALIPER C LISA TYPE CALIPER	
56116	-	Repair Kit, Brake Caliper	D LISA TYPE CALIPER C LISA TYPE CALIPER	
56117	-	Repair Kit, Brake Caliper	DX195 TYPE CALIPER	
56143	-	Repair Kit, Brake Caliper	DX195 TYPE CALIPER	

Auger Nr.	OEM Nr.	Description	Model	Picture
56142	-	Repair Kit, Brake Caliper	ELSA1 TYPE CALIPER	
56137	-	Repair Kit, Brake Caliper	ELSA2 TYPE CALIPER ELSA195 TYPE CALIPER ELSA225 TYPE CALIPER	
56136	-	Repair Kit, Brake Caliper	ELSA2 TYPE CALIPER ELSA195 TYPE CALIPER ELSA225 TYPE CALIPER	
56128	-	Repair Kit, Brake Caliper, Left	D3 TYPE CALIPER	
56129	-	Repair Kit, Brake Caliper, Right	D3 TYPE CALIPER	
56076	MCK1295 MCK1167	Repair Kit, Brake Caliper	DX175 TYPE CALIPER	
56041	MCK1294 MCK1168 MCK1169	Repair Kit, Brake Caliper	DX175 TYPE CALIPER	

Auger Nr.	OEM Nr.	Description	Model	Picture
57594	SP8570	Repair Kit, Brake Caliper	LRG600 LRG601 LRG602 LRG603 LRG608 LRG609 LRG610 LRG611 LRG620	LRG621 LRG628 LRG629 LRG634 LRG635 
57595	SJ1032	Repair Kit, Brake Caliper	LRG612 LRG613 LRG614 LRG615	
56046	MCK1129	Repair Kit, Brake Caliper	C DUCO TYPE CALIPER LE DUCO TYPE CALIPER	
55820	MCK1067	Repair Kit, Brake Caliper	C DUCO TYPE CALIPER D DUCO RADIAL TYPE CALIPER D DUCO AXIAL TYPE CALIPER	
57589	-	Repair Kit, Brake Caliper, Right	ELSA1 TYPE CALIPER ELSA1 RADIAL TYPE CALIPER	
57590	-	Repair Kit, Brake Caliper, Left	ELSA1 TYPE CALIPER ELSA1 RADIAL TYPE CALIPER	
57592	MCK1107	Repair Kit, Brake Caliper	B DUCO TYPE CALIPER	

Auger Nr.	OEM Nr.	Description	Model	Picture
57593	MCK1050	Repair Kit, Brake Caliper	B DUCO TYPE CALIPER	
56051	MCK1239	Repair Kit, Brake Caliper	B DUCO TYPE CALIPER	
55816	MCK1236	Repair Kit, Brake Caliper, Left	C DUCO TYPE CALIPER D DUCO TYPE CALIPER D DUCO RADIAL TYPE CALIPER D DUCO AXIAL TYPE CALIPER LE DUCO TYPE CALIPER	
55817	MCK1237	Repair Kit, Brake Caliper, Right	C DUCO TYPE CALIPER D DUCO TYPE CALIPER D DUCO RADIAL TYPE CALIPER D DUCO AXIAL TYPE CALIPER LE DUCO TYPE CALIPER	
55819	SJ4112	Repair Kit, Brake Caliper	ELSA1 TYPE CALIPER ELSA2 TYPE CALIPER B DUCO TYPE CALIPER C DUCO TYPE CALIPER D DUCO TYPE CALIPER D DUCO RADIAL TYPE CALIPER D DUCO AXIAL TYPE CALIPER LE DUCO TYPE CALIPER	
57581	SJ4098	Repair Kit, Brake Caliper	D DUCO RADIAL TYPE CALIPER	
56110	-	Repair Kit, Brake Caliper	DX195 TYPE CALIPER	

Auger Nr.	OEM Nr.	Description	Model	Picture
56111	-	Repair Kit, Brake Caliper	DX195 TYPE CALIPER	
56108	-	Repair Kit, Brake Caliper	DX195 TYPE CALIPER	
56109	-	Repair Kit, Brake Caliper	DX195 TYPE CALIPER	
56031	MCK1292	Repair Kit, Brake Caliper, Left	DX195 TYPE CALIPER	
56032	MCK1293	Repair Kit, Brake Caliper, Right	DX195 TYPE CALIPER	
56053	SJ4108	Repair Kit, Brake Caliper	B DUCO TYPE CALIPER C DUCO TYPE CALIPER D DUCO AXIAL TYPE CALIPER LE DUCO TYPE CALIPER ELSA1 RADIAL TYPE CALIPER ELSA2 RADIAL TYPE CALIPER	
57345	MCK1048	Repair Kit, Brake Caliper	B DUCO TYPE CALIPER	

Auger Nr.	OEM Nr.	Description	Model	Picture
56071	SJ4096	Repair Kit, Brake Caliper, Left	LM D DUCO AXIAL TYPE CALIPER TA D DUCO AXIAL TYPE CALIPER D DUCO RADIAL TYPE CALIPER	
56072	SJ4097	Repair Kit, Brake Caliper, Right	LM D DUCO AXIAL TYPE CALIPER TA D DUCO AXIAL TYPE CALIPER D DUCO RADIAL TYPE CALIPER	
57343	MCK1127	Repair Kit, Brake Caliper, Left	C DUCO TYPE CALIPER LE DUCO TYPE CALIPER	
57344	MCK1128	Repair Kit, Brake Caliper, Right	C DUCO TYPE CALIPER LE DUCO TYPE CALIPER	
56043	MCK1290	Repair Kit, Brake Caliper, Left	DX195 TYPE CALIPER	
56073	MCK1291	Repair Kit, Brake Caliper, Right	DX195 TYPE CALIPER	
56059	MCK1075	Repair Kit, Brake Caliper, Left	C LISA TYPE CALIPER D LISA TYPE CALIPER	

Auger Nr.	OEM Nr.	Description	Model	Picture
56060	MCK1076	Repair Kit, Brake Caliper, Right	C LISA TYPE CALIPER D LISA TYPE CALIPER	
56061	MCK1144	Repair Kit, Brake Caliper, Left	LRG592 LRG593	
56062	MCK1145	Repair Kit, Brake Caliper, Right	LRG592 LRG593	
55822	SJ4109	Repair Kit, Brake Caliper	D DUCO RADIAL TYPE CALIPER D DUCO AXIAL TYPE CALIPER	
55823	SJ4105	Repair Kit, Brake Caliper	D DUCO RADIAL TYPE CALIPER D DUCO AXIAL TYPE CALIPER	
55821	MCK1041	Repair Kit, Brake Caliper	C DUCO TYPE CALIPER Le DUCO TYPE CALIPER	
56019	SJ1212	Repair Kit, Brake Caliper	D3 TYPE CALIPER	

Auger Nr.	OEM Nr.	Description	Model	Picture
55176	-	Repair Kit, Brake Caliper	D3 TYPE CALIPER	
55180	SJ1018	Repair Kit, Brake Caliper	D2 TYPE CALIPER	
56028	SJ4031	Repair Kit, Brake Caliper	C LISA TYPE CALIPER D LISA TYPE CALIPER	
56042	MCK1154	Repair Kit, Brake Caliper	DX195 TYPE CALIPER	
56075	MCK1153	Repair Kit, Brake Caliper	DX175 TYPE CALIPER	
56074	MCK1155	Repair Kit, Brake Caliper	DX225 TYPE CALIPER	
70690	MCK1159	Repair Kit, Brake Caliper	DX225 TYPE CALIPER	

Auger Nr.	OEM Nr.	Description	Model	Picture
56126	-	Repair Kit, Brake Caliper	DX195 TYPE CALIPER D3 TYPE CALIPER	
56127	-	Repair Kit, Brake Caliper	D3 TYPE CALIPER	
56141	-	Repair Kit, Brake Caliper	ELSA2 TYPE CALIPER ELSA195 TYPE CALIPER ELSA225 TYPE CALIPER	
55857	ST1156	Repair Kit, Brake Caliper ø33,5xø84x13	ELSA1 TYPE CALIPER ELSA1 RADIAL TYPE CALIPER	
53870	MCK1139	Repair Kit, Brake Caliper	TA & TC Series LM & LC Series DUCO TYPE CALIPER ELSA2 TYPE CALIPER ELSA195 TYPE CALIPER	
53871	MCK1238	Repair Kit, Brake Caliper	TA & TC Series B DUCO TYPE CALIPER C DUCO TYPE CALIPER D DUCO RADIAL TYPE CALIPER D DUCO AXIAL TYPE CALIPER LE DUCO TYPE CALIPER	
54174	MCK1309	Repair Kit, Brake Caliper		

Auger Nr.	OEM Nr.	Description	Model	Picture
54555	SJ4053	Repair Kit, Brake Caliper	C LISA TYPE CALIPER	
54531	SJ4077	Repair Kit, Brake Caliper	D LISA TYPE CALIPER	
56016	MCK1088	Repair Kit, Brake Caliper	ELSA2 TYPE CALIPER ELSA2 RADIAL TYPE CALIPER ELSA195 TYPE CALIPER ELSA225 TYPE CALIPER	
54547	SJ4078	Repair Kit, Brake Caliper	D LISA TYPE CALIPER	
56045	SJ4061	Repair Kit, Brake Caliper	C LISA TYPE CALIPER	
56017	SJ4032	Repair Kit, Brake Caliper	D LISA TYPE CALIPER	
56014	-	Repair Kit, Brake Caliper, Left	D LISA TYPE CALIPER	

Auger Nr.	OEM Nr.	Description	Model	Picture
56015	-	Repair Kit, Brake Caliper, Right	D LISA TYPE CALIPER	
53868	MCK1253	Repair Kit, Brake Caliper	ELSA195 TYPE CALIPER	
56009	ST1157 ST1192	Repair Kit, Brake Caliper	ELSA1 TYPE CALIPER	
56010	MCK1317	Repair Kit, Brake Caliper	ELSA195 TYPE CALIPER ELSA225 TYPE CALIPER	
56070	MCK1170	Repair Kit, Brake Caliper	DX175 TYPE CALIPER	
56035	MCK1172	Repair Kit, Brake Caliper	DX225 TYPE CALIPER	
56036	MCK1191	Repair Kit, Brake Caliper	DX225 TYPE CALIPER	

Auger Nr.	OEM Nr.	Description	Model	Picture
56020	DSB1	Repair Kit, Brake Caliper	DX195 TYPE CALIPER	
56044	MCK1193	Repair Kit, Brake Caliper	DX195 TYPE CALIPER	
70687	MCK1173	Repair Kit, Brake Caliper	DX225 TYPE CALIPER	
53872	MCK1171	Repair Kit, Brake Caliper	TM, LM, LC Series DX195 TYPE CALIPER	
53866	MCK1171/N	Repair Kit, Brake Caliper	DX195 TYPE CALIPER	
53867	MCK1102/N	Repair Kit, Brake Caliper	ELSA1 TYPE CALIPER	
53869	MCK1254	Repair Kit, Brake Caliper	TM, LM, LC Series ELSA195 TYPE CALIPER	

Auger Nr.	OEM Nr.	Description	Model	Picture
53873	MCK1192	Repair Kit, Brake Caliper	TM, LM, LC Series DX195 TYPE CALIPER	
54170	MCK1086	Repair Kit, Brake Caliper	ELSA2 TYPE CALIPER	
54171	MCK1243 MCK1140	Repair Kit, Brake Caliper	ELSA2 TYPE CALIPER	
54529	MCK1103	Repair Kit, Brake Caliper	ELSA1 TYPE CALIPER	
54530	MCK1134 SJ4094	Repair Kit, Brake Caliper	B DUCO TYPE CALIPER C DUCO TYPE CALIPER D DUCO AXIAL TYPE CALIPER LE DUCO TYPE CALIPER TA&TC SERIES	
54532	SJ4052	Repair Kit, Brake Caliper	C LISA TYPE CALIPER	
54546	SJ1213	Repair Kit, Brake Caliper	D3 TYPE CALIPER	

Auger Nr.	OEM Nr.	Description	Model	Picture
54548	SJ4076 MCK1104	Repair Kit, Brake Caliper	D LISA TYPE CALIPER	
54549	MCK1213 SJ4011 SJ1228	Repair Kit, Brake Caliper	D3 TYPE CALIPER	
54550	MCK1102	Repair Kit, Brake Caliper	ELSA1 TYPE CALIPER ELSA1 RADIAL TYPE CALIPER	
54551	MCK1116	Repair Kit, Brake Caliper	B DUCO TYPE CALIPER C DUCO TYPE CALIPER D DUCO AXIAL TYPE CALIPER LE DUCO TYPE CALIPER TA&TC SERIES	
54552	SJ4021	Repair Kit, Brake Caliper	D LISA TYPE CALIPER	
54553	MCK1135	Repair Kit, Brake Caliper	D DUCO RADIAL TYPE CALIPER	
54554	MCK1299 MCK1066	Repair Kit, Brake Caliper	B DUCO TYPE CALIPER C DUCO TYPE CALIPER D DUCO RADIAL TYPE CALIPER D DUCO AXIAL TYPE CALIPER LE DUCO TYPE CALIPER	

Auger Nr.	OEM Nr.	Description	Model	Picture
54556	MCK1118	Repair Kit, Brake Caliper	D DUCO RADIAL TYPE CALIPER D DUCO AXIAL TYPE CALIPER	
54169	MCK1298	Repair Kit, Brake Caliper	ELSA225 TYPE CALIPER	
54172	MCK1310	Repair Kit, Brake Caliper	ELSA225 TYPE CALIPER	
54175	SJ4001	Repair Kit, Brake Caliper	D3 TYPE CALIPER	
54557	SP8999	Repair Kit, Brake Caliper	LRG522 LRG523 LRG530 LRG531 LRG538 LRG539	
54540	SP8565	Repair Kit, Brake Caliper	LRG500 LRG513 LRG602 LRG501 LRG514 LRG603 LRG502 LRG515 LRG608 LRG503 LRG518 LRG609 LRG504 LRG519 LRG610 LRG505 LRG568 LRG611 LRG508 LRG569 LRG620 LRG509 LRG600 LRG621 LRG512 LRG601 LRG628	
54542	SP8566	Repair Kit, Brake Caliper	LRG500 LRG510 LRG520 LRG501 LRG511 LRG521 LRG502 LRG512 LRG566 LRG503 LRG513 LRG567 LRG504 LRG514 LRG568 LRG505 LRG515 LRG569 LRG506 LRG516 LRG600 LRG507 LRG517 LRG601 LRG508 LRG518 LRG602 LRG509 LRG519 LRG603	

Auger Nr.	OEM Nr.	Description	Model		Picture
54534	SP9670	Repair Kit, Brake Caliper	LRG602 LRG603 LRG608 LRG610 LRG609 LRG611 LRG628 LRG629 LRG634	LRG635	
54535	SP8567	Repair Kit, Brake Caliper	LRG502 LRG503 LRG504 LRG505		
54536	SP9669	Repair Kit, Brake Caliper	LRG600 LRG601 LRG608 LRG609 LRG610 LRG611 LRG620 LRG621		
54537	SP8564	Repair Kit, Brake Caliper	LRG500 LRG501 LRG502 LRG503 LRG504 LRG505 LRG508 LRG509 LRG518	LRG519	
54538	SJ1034	Repair Kit, Brake Caliper	LRG612 LRG613		
54544	SP8902	Repair Kit, Brake Caliper	LRG510 LRG511 LRG516 LRG517 LRG520 LRG521 LRG566 LRG567		
55813	ST1154	Repair Kit, Brake Caliper	LRG612 LRG613		

Auger Nr.	OEM Nr.	Description	Model	Picture
54541	SJ1022	Repair Kit, Brake Caliper	LRG614 LRG615	
54533	SP8597	Repair Kit, Brake Caliper	LRG510 LRG511 LRG516 LRG517 LRG520 LRG521 LRG566 LRG567	
54543	SJ1035 ST1153	Repair Kit, Brake Caliper	LRG506 LRG507 LRG624 LRG625 LRG626 LRG627	
54545	SJ1037	Repair Kit, Brake Caliper	D3 TYPE CALIPER	
54539	SJ1030	Repair Kit, Brake Caliper	LRG612 LRG613	
55179	SJ1033	Repair Kit, Brake Caliper	LRG614 LRG615	
56049	SJ4111	Repair Kit, Brake Caliper	B DUCO TYPE CALIPER C DUCO TYPE CALIPER D DUCO RADIAL TYPE CALIPER D DUCO AXIAL TYPE CALIPER LE DUCO TYPE CALIPER	

Auger Nr.	OEM Nr.	Description	Model	Picture
56050	MCK1240	Repair Kit, Brake Caliper	LM ELSA2 TYPE CALIPER TM ELSA2 TYPE CALIPER	
56011	MCK1296	Repair Kit, Brake Caliper	ELSA225 TYPE CALIPER	
56086	SJ4051	Repair Kit, Brake Caliper	LRG554 LRG555	
56087	SJ4022	Repair Kit, Brake Caliper	LRG548 LRG549 LRG550 LRG551 LRG592 LRG593 LRG630 LRG631	
56012	SP8563	Repair Kit, Brake Caliper	LRG500 LRG514 LRG608 LRG501 LRG515 LRG609 LRG502 LRG518 LRG610 LRG503 LRG519 LRG611 LRG504 LRG568 LRG614 LRG505 LRG569 LRG615 LRG508 LRG600 LRG620 LRG509 LRG601 LRG621 LRG512 LRG602 LRG628 LRG513 LRG603 LRG629	
56013	-	Repair Kit, Brake Caliper	58B58 TYPE CALIPER 60B60 TYPE CALIPER 68B68 TYPE CALIPER	
56147	ST1206	Repair Kit, Brake Caliper	LRG522 LRG523 LRG530 LRG531 LRG538 LRG539	









Auger Nr.	OEM Nr.	Description	Model	Picture	
56148	SJ4000	Repair Kit, Brake Caliper	LRG526 LRG527 LRG528 LRG529		
56081	MCK1262	Repair Kit, Brake Caliper	LRG574 LRG575 LRG588 LRG589 LRG590 LRG591 LRG632 LRG633 LRG642	LRG643 LRG704 LRG705	
56082	MCK1263	Repair Kit, Brake Caliper	B DUCO TYPE CALIPER		
56083	MCK1264	Repair Kit, Brake Caliper	ELSA2 TYPE CALIPER		
56107	MCK1174	Repair Kit, Brake Caliper	LM ELSA2 TYPE CALIPER TA ELSA2 TYPE CALIPER TM ELSA195 TYPE CALIPER LM ELSA195 TYPE CALIPER		
56077	MCK1158	Repair Kit, Brake Caliper	DX195 TYPE CALIPER		
56078	MCK1156	Repair Kit, Brake Caliper	DX175 TYPE CALIPER		

Auger Nr.	OEM Nr.	Description	Model	Picture
56079	MCK1160	Repair Kit, Brake Caliper	TM SERIES LM/LC SERIES DX195 TYPE CALIPER	
56080	MCK1165	Repair Kit, Brake Caliper	DX225 TYPE CALIPER	
57588	MCK1164	Repair Kit, Brake Caliper	DX 225 TYPE CALIPER	
56052	MCK1161 MCK1175	Repair Kit, Brake Caliper	D3 TYPE CALIPER DX195 TYPE CALIPER DX225 TYPE CALIPER	
70692	-	Repair Kit, Brake Caliper		
70693	-	Repair Kit, Brake Caliper		
70694	-	Repair Kit, Brake Caliper		

Auger Nr.	OEM Nr.	Description	Model	Picture
70695	-	Repair Kit, Brake Caliper		
71870	-	Repair Kit, Brake Caliper	ELSA2 CALIPER ELSA2 RADIAL CALIPER	
54173	MCK1244	Repair Kit, Brake Caliper	ELSA2 TYPE CALIPER ELSA2 RADIAL TYPE CALIPER	
71657	SJ4056	Repair Kit, Brake Caliper, Left M27x3 L	C LISA TYPE CALIPER	
71658	SJ4057	Repair Kit, Brake Caliper, Right M27x3 R	C LISA TYPE CALIPER	
71855	-	Repair Kit, Brake Caliper ø76,8xø114,5x12	D3 TYPE CALIPER	
73417	68322562PK4	Repair Kit, Brake Caliper	ELSA1 CALIPER ELSA1 RADIAL CALIPER C DUCO CALIPER LE DUCO CALIPER D DUCO AXIAL CALIPER	

Auger Nr.	OEM Nr.	Description	Model	Picture
52911	212 00 920 212 00 921	Brake Dust Cover ø196xø465x94	TM Series	
52912	212 21 567 152 21 568	Brake Dust Cover ø463x86	TM Series TA, TC Series	
53156	212 09 705 212 09 706	Brake Dust Cover ø164xø385x74	TM Series	
65325	-	Brake Dust Cover ø237xø438x57		
65326	-	Brake Dust Cover ø237xø438x70		
65405	-	Brake Dust Cover ø250xø450x50		
65407	-	Brake Dust Cover ø238xø438x70		

Auger Nr.	OEM Nr.	Description	Model	Picture
52267	212 02 329	Brake Dust Cover	TM Series	
	212 02 330	ø152,5xø350x62,5		
52268	210 08 062	Brake Dust Cover	TM Series	
	210 08 063	ø196xø465x76		
52269	212 20 647	Brake Dust Cover	TE, TM Series	
	152 20 648	ø463x62		
52270	Dust Cover 212 24 522	Brake Dust Cover	LM/LC Series TA, TC, TM Series	
	Cover Plate 152 24 518	ø464x63		
57557	Dust Cover 212 24 522	Brake Dust Cover	LM/LC Series TA, TC, TM Series	
	Cover Plate 152 25 842	ø464x63		
65317	-	Rubber Plug, Brake Dust Cover		
		ø28/ø35x8		
65453	-	Rubber Plug, Brake Dust Cover		
		ø25x8		

Auger Nr.	OEM Nr.	Description	Model	Picture
73635	68200273	Plug, Brake Dust Cover	FCSS/A DRUM BRAKE ASSEMBLY	
65321	-	Rubber Plug, Brake Dust Cover ø5xø27x8		
65452	-	Rubber Plug, Brake Dust Cover 27x55x8,5		
65318	-	Rubber Plug, Brake Dust Cover 13,5/17x38/45x8		
65309	165005	Collet Nut, Brake Chamber ø58xø69x63xW12G		
65310	165017	Collet Nut, Brake Chamber ø58xø67x40xW12G		
65311	165062 6C462B021BA	Collet Nut, Brake Chamber ø58xø69x40xW12G		
65312	165004 6C462B021AA	Collet Nut, Brake Chamber ø58xø69x55xW12G		

Auger Nr.	OEM Nr.	Description	Model	Picture
52118	212 15 601 R	Rubber Bushing, Spring ø30xø57x102		
52105	212 22 609	Rubber Bushing, Spring ø30xø60x102	FL 9000 FL 9000 L/ M FL 11000 FL 11000/150 FL 11000 L/D/B/LB / CS	
52108	212 08 093	Rubber Bushing, Spring ø50xø100,5x130	Indair	
52251	210 11 746	Rubber Bushing, Spring ø51xø79x106	M series suspensions	
52253	210 20 676	Rubber Bushing, Spring ø41,5xø70/ø89x112,5	SMT, SM and T series suspensions	
52279	212 02 104	Rubber Bushing, Spring ø32xø55,5x58,5	SMT Series	
52256	210 11 745	Rubber Bushing, Spring ø22xø48,5x75	M & SM series suspensions	
52255	212 24 754	Rubber Bushing, Spring ø24xø48,5x58	TE , TH, TM, TA , TC Series LM / LC / LMC Series T-, U- Series	

Auger Nr.	OEM Nr.	Description	Model	Picture
53786	212 23 742	Rubber Bushing, Spring ø30xø60x45	FL9000M FL11000	
53787	212 27 205	Rubber Bushing, Spring ø24xø60x45	FL9000M FL11000	
54681	212 24 663	Rubber Bushing, Spring ø24xø60x102	FL9000 FL9000NB FL9000L FL9000HLL FL9000M	
54032	210 15 626	Bolt, Spring 142/M22x2,5	M & SM Series	
54044	212 22 234	Bolt, Spring 200/M30x3,5	FL 9000 FL 9000 L/ M FL 11000 FL 11000/150 FL 11000 L/D/B/LB / CS	
54045	212 23 744	Bolt, Spring 290/M30x3,5	FL9000M FL11000	
54046	212 22 233	Bolt, Spring 300/M24x3	FL9000M FL11000	
54024	212 02 094	Bolt, Spring 162/M24x3	SMT Series	

Auger Nr.	OEM Nr.	Description	Model	Picture
54023	212 06 000	Bolt, Spring 288/M24x3	SMT, SM and T Series	
54050	212 06 001 995 27 004	Nut, Spring 24/M24x3	FL9000M FL11000	
54052	210 16 115	Nut, Spring 22/M22x2,5	M & SM Series	
54053	995 27 003	Nut, Spring 30/M30x3,5	FL 9000 FL 9000 L/ M FL 11000 FL 11000/150 FL 11000 L/D/B/LB / CS	
65638	212 22 327	U Bolt, Spring M22x1.5/152x452,5		
65639	212 06 225	U Bolt, Spring M24x2/153x268,5		
52266	SUS-4	Repair Kit, Spring ø51xø79x106	M Series	
52263	SUS-1	Repair Kit, Spring ø22xø48,5x75	M & SM Series	

Auger Nr.	OEM Nr.	Description	Model	Picture
52264	SUS-2	Repair Kit, Spring ø41,5xø70/ø89x112,5	SMT, SM and T Series	
52265	SUS-3	Repair Kit, Spring ø32xø55,5x58,5	SMT Series	
53804	212 22 609 S	Repair Kit, Spring ø30xø60x102 <i>Rubber Bushing: 52105</i> <i>Bolt: 54044</i> <i>Nut: 54053</i>		
53805	212 23 742 S	Repair Kit, Spring ø30xø60x45 <i>Rubber Bushing: 53786</i> <i>Bolt: 54045</i> <i>Nut: 54053</i>		
53806	212 27 205 S	Repair Kit, Spring ø24xø60x45 <i>Rubber Bushing: 53787</i> <i>Bolt: 54046</i> <i>Nut: 54050</i>		
A 34644	MLF7001	Air Spring ø130,8xø210x395		

Auger Nr.	OEM Nr.	Description	Model	Picture
A 34661	MLF7000	Air Spring ø150,8xø240x390		
A 34662	MLF7089	Air Spring ø198,1xø300x360		
A 34673	MLF7006	Air Spring ø130,8xø240x370		
A 34713	MLF7147	Air Spring ø130,8xø238x492		
A 34719	MLF7156	Air Spring ø198,1xø300x530		
A 34720	MLF7004	Air Spring ø130,8xø238x460		

Auger Nr.	OEM Nr.	Description	Model	Picture
A 34727	MLF7003	Air Spring ø198,1xø300x450		
A 34782	MLF7005	Air Spring ø130,8xø210x410		
A 34819	MLF7119	Air Spring ø100,8xø166x350		
A 34838	MLF7159	Air Spring ø130,8xø265x594		
A 34882	MLF7013	Air Spring ø100,8/130,8xø210x465		
A 34883	MLF7088	Air Spring ø130,8xø230x496		

Auger Nr.	OEM Nr.	Description	Model	Picture
A 34884	MLF7084	Air Spring ø130,8xø230x420		
A 34896	MLF7010	Air Spring ø120,6xø186x510		
A 341421	MLF7082	Air Spring ø130,8xø265x485		
A 341885	MLF7012	Air Spring ø130,8xø230x450		
A 34916	MLF7085	Air Spring ø130,8xø238x460		
A 34701	MLF7155	Air Spring ø179xø270x354		

Auger Nr.	OEM Nr.	Description	Model	Picture
A 34927	MLF7009	Air Spring ø120,6xø186x425		
A 34945	MLF7125	Air Spring ø130,8xø210x435		
A 34715	MLF7158	Air Spring ø130,8xø240x370		
A 34762	MLF8087	Air Spring		
A 34768	MLF8117	Air Spring		
A 34943	MLF8209	Air Spring		

Auger Nr.	OEM Nr.	Description	Model	Picture
A 3425019	MLF8204	Air Spring		 
A 3426032	MLF8205	Air Spring		 
A 3445025	MLF8090	Air Spring		 
AU 344023 -		Air Spring		 
AU 344028 -		Air Spring		 
AU 344915	MLF8149	Air Spring		 

Auger Nr.	OEM Nr.	Description	Model	Picture
AU 34881	MLF7066	Air Spring ø311x523		
AU 34940	MLF7045	Air Spring ø259x426		
AU 34941	MLF7047	Air Spring ø259x527		
AU 344705	MLF8217	Air Spring		
AU 344159	MLF7015	Air Spring ø240x522		
AU 34942	MLF7043	Air Spring ø311x595		

Auger Nr.	OEM Nr.	Description	Model	Picture
AU 344004	MLF7030	Air Spring ø259x449		
AU 344881	MLF7040	Air Spring ø311x420		
AU 34220	212 21 395 212 22 663	Air Spring ø216x200		
AU 34300-02	212 26 068	Air Spring ø300x200		
AU 34725-K02	MLF7103	Air Spring ø327x483		
AU 34725-K03	MLF7105	Air Spring ø327x483		

Auger Nr.	OEM Nr.	Description	Model	Picture
AU 34810-K	212 08 082 212 15 632	Air Spring ø305x340		
AU 34813-K	212 15 633 MLF7026	Air Spring ø305x420		
AU 34836-K01	MLF7060	Air Spring ø300x315		
AU 34836-K02	MLF7059	Air Spring ø300x315		
AU 34902-K	MLF7069	Air Spring ø346,5x393,4		
AU 34881-K	MLF7065	Air Spring ø340x470		

Auger Nr.	OEM Nr.	Description	Model	Picture
AU 34940KP	MLF7177	Air Spring ø275x355		
AU 34941-K	MLF7046	Air Spring ø275x445		
AU 34941-KP	MLF7093	Air Spring ø275x445		
AU 34942-K	MLF7107	Air Spring ø340x490		
AU 34881-KP	MLF7104	Air Spring ø340x470		
AU 34940-K	MLF7042	Air Spring ø275x355		

Auger Nr.	OEM Nr.	Description	Model	Picture
AU 340081-K	MLF7061	Air Spring ø290x410		
AU 340304-K	MLF7142	Air Spring ø270x350		
AU 344004-K	MLF7091	Air Spring ø280x330		
AU 344004-KP	MLF7094	Air Spring ø280x330		
AU 344022-KP	MLF7092	Air Spring ø280x348		
AU 344022-KP05	MLF7044	Air Spring ø280x380		

Auger Nr.	OEM Nr.	Description	Model	Picture
AU 344157-KP14	212 21 307	Air Spring ø280x400		
AU 344157-KP15	212 22 442	Air Spring ø280x400		
AU 344158-KP	MLF7179	Air Spring ø275x410		
AU 344159-K	MLF7127	Air Spring ø300x400		
AU 344023-K	MLF7028	Air Spring ø310x385		
AU 344156-KP	212 15 761	Air Spring ø300x380		

Auger Nr.	OEM Nr.	Description	Model	Picture
AU 344159-KP	MLF7035	Air Spring ø300x400		
AU 344159-K05	MLF7064	Air Spring ø300x400		
AU 344159-KP09	MLF7068	Air Spring ø280x400		
AU 344390-K01	MLF7108	Air Spring ø275x360		
AU 344420-K	MLF7171	Air Spring ø230x140		
AU 344713-K	MLF7098	Air Spring ø290x350		

Auger Nr.	OEM Nr.	Description	Model	Picture
AU 344718K	MLF7145	Air Spring ø290x400		
AU 344757K	MLF7164	Air Spring ø294,2x347,3		
AU 344810K05	MLF7025	Air Spring ø330x340		
AU 344813K	MLF7034	Air Spring ø345x385		
AU 344881-KP	MLF7106	Air Spring ø340x350		
AU 344911-K	MLF7099	Air Spring ø345x347		

Auger Nr.	OEM Nr.	Description	Model	Picture
AU 344912K	MLF7063	Air Spring ø310x347		
AU 344913K	MLF7081	Air Spring ø320x350		
AU 346199K	MLF7146	Air Spring ø332x320		
AU 346416K	MLF7151	Air Spring ø240x320		
AU 346418K	MLF7170	Air Spring ø240x320		
AU 347315KP	MLF7033	Air Spring ø240x440		

Auger Nr.	OEM Nr.	Description	Model	Picture
AU 347804-K	MLF7181	Air Spring ø270x270		
AU 34836-K04	MLF7056	Air Spring ø300x315		
AU 344881-K	MLF7041	Air Spring ø340x350		
AU 342144-K	MLF8215	Air Spring		
AU 344028-K	MLF8176	Air Spring		
AU 344705-K	MLF8218	Air Spring		

Sample

Auger Nr.	OEM Nr.	Description	Model	Picture
AU 346760-K	MLF8214	Air Spring		 
AU 344023-KP	-	Air Spring		  Sample
AU 344915-K	MLF8153	Air Spring		 
20122	212 08 082 S 212 15 632 S	Piston, Air Spring, for AU 34810-K	ø260x140	
20123	212 15 633 S	Piston, Air Spring	ø260x178	 
20006	-	Piston, Air Spring, for AU 346416-K	ø168x182	 

Auger Nr.	OEM Nr.	Description	Model	Picture
20007	-	Piston, Air Spring, for AU 346418-K ø168x168		 <p>NEW</p>
20009	-	Piston, Air Spring, for AU 347804-K ø198x169		 <p>NEW</p>
20010	-	Piston, Air Spring, for AU 344390-K01 and AU 344390-K02 ø200x165		 <p>NEW</p>
20012	-	Piston, Air Spring, for AU 344913-K ø226x210		 <p>NEW</p>
20013	-	Piston, Air Spring, for AU 34836-K01 and AU 34836-K02 ø230x135		 <p>NEW</p>
20014	-	Piston, Air Spring, for AU 344911-K ø228x210		 <p>NEW</p>

Auger Nr.	OEM Nr.	Description	Model	Picture
20255	-	Piston, Air Spring, for AU 34881-KP ø254x188		
20030	-	Flange, Air Spring, for AU 344881-K and AU 34881-K M16x2/ø17xø249,5x19		
20035	-	Flange, Air Spring, for AU 34940-K and for AU 344881-K M16x2/ø17xø199,5x17		
20031	-	Bolt, Air Spring, for AU 344881-K and AU 34940-K M16x2/128		
20033	-	Bolt, Air Spring, for AU 34881-K and AU 34941-K M16x2/174		
20029	-	Repair Kit, Air Spring, for AU 344881-K ø247x143 <i>Piston: 20002</i> <i>Flange: 20030</i> <i>Bolt: 20031</i>		
20034	-	Repair Kit, Air Spring, for AU 34940-K ø197x141,5 <i>Piston: 20004</i> <i>Flange: 20035</i> <i>Bolt: 20031</i>		

Auger Nr.	OEM Nr.	Description	Model	Picture	
20036	-	Repair Kit, Air Spring, for AU 34941-K ø197x193 <i>Piston: 20005</i> <i>Flange: 20035</i> <i>Bolt: 20033</i>			
20114	-	Repair Kit, Air Spring, for AU 34881-K ø247x187,6 <i>Piston: 20032</i> <i>Flange: 20030</i> <i>Bolt: 20033</i>			
20256	-	Repair Kit, Air Spring, for AU 34881-KP ø254x188			
20108	MLF9005	Air Spring, Bogie Suspension M12/M20/295			
20213	212 24 745 212 24 531 212 22 271	Shock Absorber, Rear & Front	FL9000 FL9000L FL9000H FL9000HL FL11000 FL11000L FL11000/150 FL11000B FL11000LB	FL11000CT FL11000CS FL11000LS FL11000S	
20214	212 24 778 212 26 989	Shock Absorber	FL9000NB		
53785	905 08 004	Rubber Bushing, Shock Absorber ø19xø44,5x23			

Auger Nr.	OEM Nr.	Description	Model	Picture
54808	212 20 726	Lock Washer, Axle ø36,5xø109,5x8	TE 9000 / 9300	
54809	212 21 061	Lock Washer, Axle ø36,7xø75x3,6	TE 9000 / 9300	
54410	212 26 090	Lock Washer, Axle ø89xø148x4	TA / TC Series	
54807	210 20 818	Lock Washer, Axle ø66xø98x5,5	TM 20000, TM 22500, TM 25000 Series	
57137	212 24 669	Lock Washer, Axle ø82xø138,3x4	LM/LC Series	
57138	210 14 992	Lock Washer, Axle ø87xø117x8	TM Series	
57139	212 26 088	Lock Washer, Axle ø89xø146,5x14	TA / TC Series	
54406	212 24 762	Axle Nut M82x2/18xSW112	LM/LC Series	

Auger Nr.	OEM Nr.	Description	Model	Picture
54407	212 26 003	Axle Nut ø86-W12G/18xSW120	TA / TC Series	
54805	212 20 759	Axle Nut 12/M36x2	TE 9000 / 9300	
54804	212 10 819	Axle Nut 10/M65x1,5	TM 20000, TM 22500, TM 25000 Series	
54806	212 05 571	Axle Nut 13/M65x1,5	TM 20000, TM 22500, TM 25000 Series	
57141	210 14 986	Axle Nut ø84-W12G/13xSW118	TM Series	
57142	210 14 988	Axle Nut ø84-W12G/12,3xSW107	TM Series	
57140	212 26 032	Axle Nut ø86-W12G/23xSW120	TA / TC Series	
57156	212 25 405	Axle Nut M82x2/20,3xSW105	LC Series	

Auger Nr.	OEM Nr.	Description	Model	Picture
52914	AXL-104	Repair Kit, Axle	TE 9000 / 9300	
52913	AXL-105	Repair Kit, Axle	TM 20000, TM 22500, TM 25000 Series	
57152	212 26 117 PK5	Spring Clip, Axle ø4xø160	TA/TC Series	
57153	212 24 865 PK5	Spring Clip, Axle ø4xø150	LM/LC Series	
57154	212 23 127	Spring Clip, Axle ø3,2xø123	TE Series	
69143	142 04 561	Wheel Hub, With Bearing, Hup Cap and Gasket	TM Series	
69144	142 04 561 S 142 04 562 S	Wheel Hub, Without Hub Cap and Gasket	TM Series	

Auger Nr.	OEM Nr.	Description	Model	Picture
69145	142 04 561 S1 142 04 562 S1	Wheel Hub, Only Casting Body	TM Series	
75319	212 03 219 S	Wheel Hub, Only Casting Body	U, TM Series	
75320	212 03 219 S1	Wheel Hub, With Bearing	U, TM Series	 Sample
75321	212 26 120 S	Wheel Hub, Only Casting Body		
75322	212 26 120 S1	Wheel Hub, With Bearing		 Sample
75323	212 28 120 S	Wheel Hub, Only Casting Body		
75324	212 28 120 S1	Wheel Hub, With Bearing		 Sample

Auger Nr.	OEM Nr.	Description	Model	Picture
75325	142 26 120 S	Wheel Hub, Only Casting Body	TA/TC Series	 
75326	142 26 120 S1	Wheel Hub, With Bearing	TA/TC Series	  Sample
75327	142 26 492 S	Wheel Hub, Only Casting Body	TA/TC Series TA Series	 
75328	142 26 492 S1	Wheel Hub, With Bearing	TA/TC Series TA Series	  Sample
75329	142 25 425 S	Wheel Hub, Only Casting Body	LM/LC Series	 
75330	142 25 425 S1	Wheel Hub, With Bearing	LM/LC Series	  Sample
75331	212 10 885 S	Wheel Hub, Only Casting Body	TM Series	 

Auger Nr.	OEM Nr.	Description	Model	Picture	
75332	142 27 483 S	Wheel Hub, Only Casting Body	LM/LC Series	 	
75333	142 27 483 S1	Wheel Hub, With Bearing	LM/LC Series	 	Sample
75334	142 24 748 S	Wheel Hub, Only Casting Body	LM/LC Series	 	
75335	142 19 784 S	Wheel Hub, Only Casting Body	TE Series	 	
75353	142 24 262	Wheel Hub, With Bearing, Hup Cap and Gasket ø65/ø90xø220/ø23x275	TM Series	 	
75354	142 24 262 S	Wheel Hub, Without Hub Cap and Gasket ø65/ø90xø220/ø23x275	TM Series	 	
75355	142 24 262 S1	Wheel Hub, Only Casting Body ø120xø220/ø23x275	TM Series	 	



Auger Nr.	OEM Nr.	Description	Model	Picture
53792	AXL-101	Repair Kit, Wheel Hub ø112xø146,5x22	U 20000, U 22500	
53793	AXL-102	Repair Kit, Wheel Hub ø119xø152,5x22	TM 20000, TM 22500, TM 25000	
53794	AXL-103	Repair Kit, Wheel Hub ø116,5xø152,5x25,5	TM 20000, TM 22500, TM 25000	
53795	AXL-114	Repair Kit, Wheel Hub ø99,5xø135x15	TE9000, TE9300	
54880	210 16 330	Seal Ring, Wheel Hub ø112xø146,5x22	U 20000, U 22500	
54881	210 20 663	Seal Ring, Wheel Hub ø119xø152,5x22	TM 20000, TM 22500, TM 25000	
54882	212 20 158	Seal Ring, Wheel Hub ø99,5xø135x15	TE9000, TE9300	


Auger Nr.	OEM Nr.	Description	Model	Picture
54883	212 00 321	Seal Ring, Wheel Hub ø116,5xø152,5x25,5	TM 20000, TM 22500, TM 25000	
57143	990 42 026	Seal Ring, Wheel Hub ø137,5xø184,3x16	TM Series	
57150	212 03 735	Thrust Ring, Wheel Hub ø109,9xø139,7x20,8	TM Series	
56381	990 41 022	Bearing, Wheel Hub ø82,5xø146x41,5	U Series 20,000 lb Axle	
57014	990 41 045	Bearing, Wheel Hub ø65xø120x41	TM Series	
57144	990 41 058	Bearing, Wheel Hub ø100xø180x49	TM Series	
57145	990 41 057	Bearing, Wheel Hub ø90xø160x42,5	TM Series	

Auger Nr.	OEM Nr.	Description	Model	Picture
57147	990 41 075	Bearing, Wheel Hub ø82xø140x36,5	LM/LC Series	
57148	990 41 067 B	Bearing, Wheel Hub ø80xø130x37	TE Series	
57149	990 41 068 B	Bearing, Wheel Hub ø50xø110x42,25	TE Series	
70800	A1228Q1317	Bearing, Wheel Hub ø82,55xø139,99x36,51		
57157	212 25 514	Thrust Washer, Wheel Hub ø82,5xø130x14	LC Series	
52900	212 24 673	Hub Cap ø9/ø162x15	LM/LC Series	
52907	212 20 727	Hub Cap ø9/ø130x8	TE Series	

Auger Nr.	OEM Nr.	Description	Model	Picture
53781	212 23 112	Hub Cap ø9/ø140x9	TM Series	
54408	212 26 038	Hub Cap ø8,5/ø188,5x24	TA / TC Series	
52908	212 02 627	Hub Cap ø9x139,5/ø156x49	TM Series	
57151	212 05 583	Hub Cap ø9xø181x52,5	TM Series	
54409	212 26 119	Gasket, Hub Cap ø8xø187,5x2	TA / TC Series	
57155	212 24 759	Gasket, Hub Cap ø8,5xø163x4	LM/LC Series	
69158	210 22 167	Stud M22x1,5/86,5	TM Series TA / TC Series	

Auger Nr.	OEM Nr.	Description	Model	Picture
69159	210 20 997	Stud M22x1,5/97	TM Series TA / TC Series	
75342	210 18 491	Stud 7/8" x 11 BSF / 94	TM Series	
75343	212 20 132	Stud M22x1,5/80	TE Series LM/LC Series LM Series	
75344	212 20 969	Stud M22x1,5/95	TE Series LM/LC Series	
65564	212 18 643	Nut, Stud M22x1,5	LC, LM, TA, TM Series	
69163	210 16 416	Nut, Stud 7/8x11"BSF	TM Series	
65571	210 06 512	Rondela, Stud ø22,5	TM Series	

Auger Nr.	OEM Nr.	Description	Model	Picture
75347	212 12 489	Bushing, Drag Link ø20xø63x72,5	TM Self Steer Axle Universal Self Steer Axle	 NEW
75348	212 12 426	Bushing, Drag Link ø22xø63x72,5	TM Self Steer Axle Universal Self Steer Axle	 NEW

Auger Nr.	OEM Nr.	Description	Model	Picture
54703	SZ1208	Cylinder, Compressor Stroke: 85 Con-Rod: M8 Max. Operating Pressure: 10 bar Port Threads: M12x1,5		

**SPARE PARTS FOR
COMMERCIAL VEHICLES**

SAE-GIGANT








we keep your business
ON THE MOVE



www.augerautotechnik.de






Auger
GERMANY

Auger Nr.	OEM Nr.	Description	Model	Picture
53827	08709045	Pin, Brake Shoe ø27x81		
53829	08804062	Pin, Brake Shoe ø20x48		
53830	08804086	Pin, Brake Shoe ø16x48		
53828	02001001	Bushing, Brake Shoe ø27xø30x20		
53831	06311046	Roller, Brake Shoe ø20xø45x23		
53832	05703006	Roller, Brake Shoe ø16xø45x23		
53837	08910060	Repair Kit, Brake Shoe ø27xø30x20/81		
53839	-	Repair Kit, Brake Shoe ø20xø45x23/48 <i>Pin: 53829</i> <i>Roller: 53831</i>		

Auger Nr.	OEM Nr.	Description	Model	Picture
53840	-	Repair Kit, Brake Shoe ø16xø45x23/48 <i>Pin: 53830</i> <i>Roller: 53832</i>		
53825	08307075	Spherical Bearing, Brake Cam Shaft ø36,5/ø37xø70x32		
53826	02001004	Bushing, Brake Cam Shaft ø37xø40x25		
53836	-	Repair Kit, Brake Cam Shaft ø36,5/ø37xø70x32		
53838	08902022	Repair Kit, Brake Cam Shaft ø36,5/ø37xø70x32		
57806	09319013	Brake Slack Adjuster Manuel		
58142	00885374	Brake Slack Adjuster Automatic ø14x250/180/165/150/135/ 120x50° / Saddle Type		




Auger Nr.	OEM Nr.	Description	Model	Picture
58145	09317026	Brake Slack Adjuster Automatic ø14x250/180/165/150/135/ 120x110° / Saddle Type		
58151	09319019	Brake Slack Adjuster Manuel		
58289	09002105	Brake Slack Adjuster Automatic ø14x210/180/150/125x130°/ Saddle Type		
58345	-	Brake Slack Adjuster Automatic ø14x210/180/150/125x130° / Bent		
53833	08803055	Brake Dust Cover ø153xø340x37,5		
53834	08612004	Brake Dust Cover ø147xø397x39		
53835	08206009	Brake Dust Cover ø198xø461x81		

Auger Nr.	OEM Nr.	Description	Model	Picture
A 34719	00196036	Air Spring ø198,1xø300x530		
A 34727	00196043	Air Spring ø198,1xø300x450		
A 34762	00196035	Air Spring		
AU 34725-K02	00166217	Air Spring ø327x483		
AU 34725-K03	00166252	Air Spring ø327x483		
AU 34813K	08403102	Air Spring ø305x420		

Auger Nr.	OEM Nr.	Description	Model	Picture
AU 34724-K	00166225	Air Spring		
20123	08403102 S	Piston, Air Spring, for AU 34813-K ø260x178		
71422	00199089	Bushing, Stabilizer Bar ø30,5xø44x25,5		
20205	-	Shock Absorber, Rear&Front ø24x329/494		
20207	00196119	Shock Absorber		

Auger Nr.	OEM Nr.	Description	Model	Picture
56618	10500858	Bearing, Wheel Hub ø75xø130x41		
57013	10500582	Bearing, Wheel Hub ø90xø150x45		
57014	10500558	Bearing, Wheel Hub ø65xø120x41		
57144	10500505	Bearing, Wheel Hub ø100xø180x49		
57148	10500572	Bearing, Wheel Hub ø80xø130x37		
57292	10500576	Bearing, Wheel Hub ø80xø140x46		

Auger Nr.	OEM Nr.	Description	Model	Picture
69667	10500859	Bearing, Wheel Hub ø95xø170x45,5		
69668	10500574	Bearing, Wheel Hub ø85xø140x41		
69671	10500873	Bearing, Wheel Hub ø70xø150x54		
69680	10500503	Bearing, Wheel Hub ø70xø125x33,25		
69689	10500799	Bearing, Wheel Hub ø40xø80x32		
70814	-	Bearing, Wheel Hub ø120xø180x48		 

Auger Nr.	OEM Nr.	Description	Model	Picture
57145	10500497	Bearing, Wheel Hub ø90xø160x42,5		
69707	10500481	Bearing, Wheel Hub ø60xø110x29,75		
69710	10500474	Bearing, Wheel Hub ø40xø80x24,75		

**SPARE PARTS FOR
COMMERCIAL VEHICLES**

SAUER ACHSEN

we keep your business
ON THE MOVE



www.augerautotechnik.de

auger
GERMANY

Auger Nr.	OEM Nr.	Description	Model	Picture
31169	1 064 0060 02	Brake Drum	RSM 9042	
	1 064 0236 00		RLSM 9042	
	1 064 0236 01			
31170	1 064 0059 04	Brake Drum	RSM 8442-8	
31171	1 064 0151 00	Brake Drum	RBM 8442 RLBM 8442	
31172	1 064 0104 01	Brake Drum	RZT 14242 RZT 16242	
31173	1 064 0108 01	Brake Drum	RSM 11242 RZM 8442 RZM 12242 WRZM 6242 RLSM 11242	
31174	1 064 0270 00	Brake Drum	KRS 12242	
	1 064 0270 01		KRS 12242/18	
	1 064 0270 02		SK RS 9042/20	
	1 064 0270 10		SK RS 11242	
			SK RZ 9042	
31175	1 064 0197 00	Brake Drum	SK RZ 11242	
			SK RZ 12242	
			S9-4220	
			S11-4220	
			WRZM 8130	
			WRZM 11030	
			WRLZM 8130	
WZRLZM 8130				
WZRLZM 11030				

Auger Nr.	OEM Nr.	Description	Model	Picture
31176	1 064 0223 00	Brake Drum	WRZM 8435-10 WRZM 11035-10 WRLZM 8435-10 WRLZM 11035-10	
31177	1 064 0292 00	Brake Drum	KRS 14242 KRZ 14242 KRZ 16242	
31178	1 064 0273 00	Brake Drum	SK RS 9030 SK RZ 9030 SK RZ 11030 SK RZ 12030 Z9-3020 Z11-3020 ZL9-3020 ZL11-3020	
31179	1 064 0277 00	Brake Drum	SK RZ 9037-8 SK RZ 11037-8 Z9-3720 -8L Z11-3720 -8L	
31180	1 064 0260 02 1 064 0260 01	Brake Drum	SK RS 9042 / SK 1000 SK RS 9042 INTRAAX SK RS 9042 SK 500 SK RS 9042 SK 500 plus S9-4218 S11-4218 Z9-4218 Z11-4218 SK RLS 9042	
31181	1 064 0280 01	Brake Drum	S9-3718 S11-3720 Z8-3718 Z8-3718 (TK275/8-ALU) SL9-3718 ZL8-3718 SK RS 9037-8	
31182	1 064 0278 00	Brake Drum	Z11-3720 -10L ZL9-3720 ZL11-3720 Z9-3720 -10L SK RZ 9037-10 SK RZ 11037-10	

Auger Nr.	OEM Nr.	Description	Model	Picture
31184	1 064 0109 01 1 064 0126 00	Brake Drum	RZM 14242 RZM 16242 WRZM 8442 WRZM 11242	
31185	1 064 0149 00	Brake Drum	-	
65424	3 054 0053 00 S ø410x200mm	Brake Shoe, Brake Drum, Unlined, Without Roller	RLSM 11242 RLSM 9042/20 RSM 11242 RSM 9042/20 RZM 11242 RZM 12242 WRZM 8442 WRZM 8442-8	
65533	3 054 0052 00 S ø410x180mm	Brake Shoe, Brake Drum, Unlined, Without Roller	RBM 8442 RSM 8442 RSM 9042 RZM 8442 WRZM 6242 RLBM 8442 RLSM 8442 RLSM 9042	
52373	1 214 0023 02 1 214 0023 01 ø31,7x73	Pin, Brake Shoe	RSM 6542 EBN 3130/12 / 4530 ESN 4030 / 5030 / 5542 / 6030 EZN 4030 /4030/12/5030 / 6030	
53752	1 214 0022 00 1 214 0022 01 ø31,7x88	Pin, Brake Shoe	EBN 4535 EBN 5535	
54795	1 214 0006 06 ø32x183	Pin, Brake Shoe		

Auger Nr.	OEM Nr.	Description	Model	Picture
52910	1 230 0084 01	Bushing, Brake Shoe		
	1 230 0084 00	ø32xø35x36,5		
54282	1 230 0032 00	Bushing, Brake Shoe		
		ø32xø36x32		
52363	1 230 0035 00	Bushing, Brake Shoe		
52368	1 265 0007 00	Roller, Brake Shoe	RSM 6542 EBN 3130/12/4530/4535 / 5535 ESN 4030 / 4030/12/5030 / 5542 EZN 4030 / 5030 / 6030 RBM 8442 / 8442-12 RLBM 8442 RLSM 8442 / 9042 / 9042/20 RSM 6242/12-8 / 6242/12-10	
		ø19/ø31,7x55,5		
53557	1 265 0019 00	Roller, Brake Shoe	KRS 12242 / 14242 / 12242/18 KRZ 16242 KRZT 14242 TRILEX SKRLS 9042 / 9042/20 / 11242 SKRS 6537-8 / 6537-10 / 9030 / 9037-8 / 9037-10 / 11242 / 12242 SKRS 9042 / 9042/20 / 9042 INTRAAX / 9042 SK 500 (PLUS)	
		ø20xø36x53		
52362	1 447 0021 01	Spring, Brake Shoe	RBM 8442 / 8442/12 RLBM 8442 RLSM 8442 / 9042 / 9042/20 RSM 8442 / 8442-8 / 9042 RZM 8442 / 8442-8 / 11242 SKRB 9019 K / 9019 W / 9022 H SKRLS 9037/9042/9042/20 / 11242	
	1 447 0031 00	ø26x190		
52774	1 447 0058 00	Spring, Brake Shoe	RBM 8442 / 8442/12 - RLBM 8442 RLSM 8442 / 9042 / 9042/20 11242 RSM 8442 / 8442-8 / 9042 / 9042/20 RZM 8442 / 8442-8 / 11242 SKRB 9019 K / 9019 W / 9022 H SKRLS 9037 / 9042 / 9042/20 /	
	1 447 0058 01	ø32,5x232		
52775	1 447 0033 00	Spring, Brake Shoe	EBN 3130/12 / 4530 ESN 4030 / 5030 / 6030 EZN 4030 / 4030/12/5030 / 6030 WESN 5030 / 6030 WEZN 5030 / 6030 / 6030/12 WRZM 8130 / WRLZM 8130 / 11030 WZRLZM 8130 / 11030	
		ø29x168		

Auger Nr.	OEM Nr.	Description	Model	Picture
52776	1 447 0050 00	Spring, Brake Shoe 29,5x220	EBN 4535 EBN 5535 WRZM 8435-8 WRZM 8435-10 WRZM 11035-8 WRZM 11035-10 WRLZM 8435-8 WRLZM 8435-10	
52779	1 447 0038 00	Spring, Brake Shoe ø25x227	RSM 6542 ESN 5542 RBM 8442 / 8442/12 RLBM 8442 RLSM 8442 9042 / 9042/20 RSM 6242-8 / 6242/12-8 RSM 8442 / 8442-8 / 9042/ 9042	
53558	1 447 0060 00	Spring, Brake Shoe ø32x186	SKRZ 6530 SKRS 9030 SKRZ 9030 SKRZ 11030 SKRZ 12030	
52369	1 395 1001 00	Spring Pin, Brake Shoe ø6,3x70	EBN 3130/12/4530-ESN 4030/ 5030 EZN 4030/12 / 5030 / 6030 RBM 8442 / 8442/12 - RLBM 8442 RLSM 8442 /9042 / 9042/20 11242 RSM 8442 / 8442-8/9042 / 9042/20	
52372	1 395 1013 00	Spring Pin, Brake Shoe ø12x64	EBN 3130/12 / 4530 / 4535 / 5535 ESN 4030 / 5030 / 6030 EZN 4030 / 4030/12 / 5030 / 6030 RZM 11030 / 13130 WESN 5030 / 6030 WEZN 5030 / 6030 / 6030/12	
53685	1 395 1005 00	Spring Pin, Brake Shoe ø12x64	RSM 6542 - ESN 5542 RBM 8442 / 8442/12 RLBM 8442 RLSM 9042 / 9042/20 / 11242 RSM 6242/12-8 / 6242/12- 10/8442 RZM 8442 / 8442/8 / 11242/12242	
54833	1 151 0013 00	Spring Clamp, Brake Shoe 35x156x39	SKRS 6530-11030 SKRZ 6530-11030	
54834	1 151 0008 00	Spring Clamp, Brake Shoe 35x175x55	SKRS 6537 - 11037 SKRZ 6537 - 11037	

Auger Nr.	OEM Nr.	Description	Model	Picture
52781	3 213 0023 01 3 213 0023 02	Repair Kit, Brake Shoe, Single ø31,7x73	EBN 3130/12/4530/ 4535 / 5535 ESN 4030 / 5030 / 5542 / 6030 EZN 4030 /4030/12 / 5030 / 6030 RBM 8442/8442/12 - RLBM 8442 RLSM 8442/ 9042/9042/20/ 11242 RSM 6242 /12-8/6242/12-10/ 6542 RZM 8442 / 8442-8 / 11030 / 11242 RZT 14242 / 16242 -	
53562	3 213 0023 01 S 3 213 0023 02 S	Repair Kit, Brake Shoe Double ø31.7x73	EBN 3130/12/ 4530/4535/5535 ESN 4030 / 5030 / 5542 /6030 EZN 4030 / 4030/12/5030 / 6030 RBM 8442 / 8442/12-RLBM 8442 RLSM 8442/9042/9042/20 / 11242 RSM 6242/12-8 /6242/12-10/ 6542 RZM 8442 / 8442-8 / 11030 / 11242 RZT 14242 / 16242 -	
57072	3 213 0022 01	Repair Kit, Brake Shoe ø31,7x88	EBN 4535 EBN 5535	
53997	3 213 0004 06	Repair Kit, Brake Shoe ø32x183		
53583	-	Repair Kit, Brake Shoe ø31,7 <i>Pin: 52373</i> <i>Roller: 52368</i> <i>Bushing: 52910</i> <i>Spring: 52775</i>		
53584	-	Repair Kit, Brake Shoe ø31,7 <i>Pin: 52373</i> <i>Roller: 52368</i> <i>Bushing: 52910</i> <i>Spring: 52779</i>		
53577	3 434 3608 00	Repair Kit, Brake Shoe ø20xø36x53	SKRS 6530-11030 SKRZ 6530-11030	

Auger Nr.	OEM Nr.	Description	Model	Picture
53582	3 434 3635 00	Repair Kit, Brake Shoe ø20xø36x53		
53578	3 434 3615 00	Repair Kit, Brake Shoe ø20xø36x53	SKRS 6537 - 11037 SKRZ 6537 - 11037	
53581	3 434 3612 00	Repair Kit, Brake Shoe ø20xø36x53	SK 500 SK 9042 / 11242 S-, Z-Series 3718 S-, Z-Series 3720 S-, Z-Series 4218 S-, Z-Series 4220 KRS(M) / KRZ(M) 14242	
52751	3 434 3602 00	Repair Kit, Brake Shoe ø19/ø31,75x55,5/73	AXLE TYPES 8442-11242	
70856	-	Repair Kit, Brake Shoe		
52214	1 350 2001 04	Retainer, Brake Cam Shaft ø8,5/ø90xø60x12,5	EBN 3130/12 /3140/ 4040 / 4535 EBN 4540 / 4540-6 / 5535 ESN 4030 / 4040 / 4540 / 5030 EZN 5030 / 6030 /8442 / 8442/12 RSM 8442-8/6542/12-8 / 6542/12 RZM 8442 / 8442-8 / 11242 RZT 14242 / 16242 SKRS 9030 / 9037-8 / 9037	
52215	1 350 2001 03 1 350 2001 02 1 350 2001 01	Retainer, Brake Cam Shaft ø8,5/ø90xø60x12	RSM 6542 EBN 3140 / 3140-6 / 4040 / 4540 ESN 4040 / 4540 / 5542 EZN 5030 RBM 8442 / 8442/12 RSM 11242 / 6242/12-10 RZM 8442	



Auger Nr.	OEM Nr.	Description	Model	Picture
52216	1 350 2002 01	Retainer, Brake Cam Shaft ø70x13	WRZM 8435-8 / 8435-10 WRZM 11035-8 / 11035-10	
52367	1 350 2005 00	Retainer, Brake Cam Shaft ø70x13	RZM 11030 RZM 13130 WRZM 11030 WRZM 11035-10 WRZM 11035-8 WRZM 8130 WRZM 8435-8 WRZM 8442	
52207	1 230 1002 04 3 230 1002 04	Spherical Bearing, Brake Cam Shaft ø38xø60x55	EBN 3130/12 / 3140/3140-6 / 4040 ES 5030 / RS 5030 ESN 4030 / 4040 / 4540 / 5030 EZN 4030 / 4030/12 / 5030 / 6030 RBM 8442 / 8442/12 RSM 11242 / 6542 / 6542/12-10 RZM 8442 / 8442-8 / 11242 /	
52208	1 230 1002 03	Spherical Bearing, Brake Cam Shaft ø39xø60x38	EBN 3130/12 - ES 5030 EBN 3140 / 3140-6 / 4040 / 4530 ESN 4030 / 4040 / 4540 / 5030 EZN 4030/12 / 5030 / 6030 RBM 8442/12 RSM 6242/12-8 / 6242/12-10	
52209	1 230 1001 01 1 230 1001 00	Spherical Bearing, Brake Cam Shaft ø42,5xø59,5x38		
52210	1 230 2001 01 3 230 2001 01	Spherical Bearing, Brake Cam Shaft ø38xø70x63	RZM 11030 / 13130 WRZM 8130 / 8435-8 / 8435	
52218	3 268 0046 00	Spherical Bearing, Brake Cam Shaft ø46x78	KRS 12242 KRZ 14242 SKRS 6537-8 / 6537-10 / 9037-8 SKRS 9042 INTRAAX / (INTRAAX) SK 1000 ET 0 / SK 500 (PLUS)	
52219	3 268 0045 00	Spherical Bearing, Brake Cam Shaft ø38x51,5	KRS 12242 / 12242/18 / 14242 KRZ 14242 KRZT 14242 TRILEX / 16242 SKRS 6537-8 / 6537-10 / 9030 SKRS 9042 SK 500 (PLUS) SKRZT 12242	

Auger Nr.	OEM Nr.	Description	Model	Picture
55225	3 268 0051 00	Spherical Bearing, Brake Cam Shaft ø48x78	KRS 12242 KRS 12242/18 S11-3720-S11-4218 SK RS 9042 INTRAAX SK RS 9042 SK 500 SK RS 9042 SK 500 plus SK RZ 12242 SK RZ 9037-10	
52211	1 072 0018 00 1 072 0018 01	Bushing, Brake Cam Shaft ø38xø48x22,5	RSM 6542 EBN 3130/12"/ 3140 / 3140-6 ES 5030 ESN 4030 /4040/4540 / 5030 EZN 4030 / 4030/12"/ 5030	
52212	1 072 0017 01	Bushing, Brake Cam Shaft ø38xø48x22,5	RSM 6542 EBN 3130/12"/ 3140 / 3140-6 ES 5030 ESN 4030 /4040/4540 / 5030 EZN 4030 / 4030/12"/ 5030	
52365	1 230 0144 00	Bushing, Brake Cam Shaft ø38xø42x30		
52206	1 230 0106 04 1 230 0106 02 1 230 0106 03	Bushing, Brake Cam Shaft ø38,2xø42x44,8	EBN 3130/12 / 3140 / 3140-6 ESN 4030 / 4040 / 4540 / 5030 EZN 4030 / 4030/12 / 5030 / 6030 RZT 14242 / 16242 RLSM 8442 / 9042 / 9042/20 RSM 6542 / 6542/12-8 / 6542/12 RZM 8442 / 8442-8 11030 /	
52366	4 230 0180 00	Bushing, Brake Cam Shaft ø46xø50x40	KRZ 14242 / 14242 TRILEX SKRLS 9037/9042/9042/20/ 11242 SKRLZ 9030 / 9037 / 11030/ 11037 SKRS 11242 / 9042 (INTRAAX) SKRS 6537-8/6537-10/9030 / 9037	
53556	4 230 0172 01	Bushing, Brake Cam Shaft ø55xø60x40	SKRS 9042 SKRS 9042/20	
52205	4 230 0176 00	Bushing, Brake Cam Shaft ø56xø60x33	SKRS 9037-8 / 9037-10 / 9042 SKRLS 9042 / 9042/20 / 11242 SKRZ 9037-8 / 9037-10 / 9042	








Auger Nr.	OEM Nr.	Description	Model	Picture
52213	4 131 0008 00	Dust Cover, Brake Cam Shaft ø36,5xø60x17	EBN 3130/12/3140 /3140-6 / 4040 ESN 4030/ 4040 /4540 /5030 /5542 EZN 4030 /4030/12 / 5030 / 6030 KRS 12242 KRZ 14242 RS 5030 RSM 11242	
54049	-	Nut, Brake Cam Shaft 16/M16x1,5		
54869	-	Seal Ring, Brake Cam Shaft ø116,5xø152,5x25,5		
52220	3 268 0048 00	Repair Kit, Brake Cam Shaft ø46x78	KRS 12242 / 12242/18 / 14242 KRZ 14242 SKRS 11242 / 12242 SKRS 6537-8 / 6537-10 / 9037-8 SKRS 9042 SK 1000 ET 0	
52221	3 268 0047 00	Repair Kit, Brake Cam Shaft ø38x51,5	KRS 12242 / 12242/18 / 14242 KRZ 14242 / 16242 SKRS 6537-8 / 6537-10 / 11242 SKRS 9030 / 9037-8 / 9037-10 SKRS 9042 INTRAAX SKRZ 11030 / 11037-8 / 11037-10	
52222	3 268 0007 01	Repair Kit, Brake Cam Shaft ø39xø60x38	EBN 3130/12 - ES 5030 EBN 3140 / 3140-6 / 4040 / 4530 ESN 4030 / 4040 / 4540 / 5030 EZN 4030/12 / 5030 / 6030 RBM 8442/12 RSM 6242/12-8 / 6242/12-10	
52223	3 317 0004 00	Repair Kit, Brake Cam Shaft	RSM 6542 EBN 3130/12 / 3140 / 3140-6 ESN 4030 / 4040 / 4540 / 5030 EZN 4030 / 4030/12 / 5030 / 6030 RBM 8442 / 8442/12 RLBM 8442 RLSM 8442 / 9042 / 9042/20 RS 5030	

Auger Nr.	OEM Nr.	Description	Model	Picture
52224	3 317 0006 00	Repair Kit, Brake Cam Shaft	EBN 3140-6 / 4040 EBN 4530 / 4540-6 ES 5030 ESN 4030 / 4040 ESN 4540 / 5030 EZN 5030 / 6030 RBM 8442/12 RS 5030 RSM 6242/12-8 / 6242/12-10 / 6542	
52225	3 317 0004 00 SMB ø38xø48x22,6	Repair Kit, Brake Cam Shaft	All axles with camshaft dia. 38 mm EBN 3130/12 / 3140 / 3140-6 RSM 6542 ESN 4030 /4040 /4540 /5030 /5542 EZN 4030 / 4030/12 / 5030 / 6030 RBM 8442 / 8442/12	
52226	3 434 3620 00 3 434 3618 00 ø38xø60x55	Repair Kit, Brake Cam Shaft	RBM 8442 RLBM 8442 RLSM 8442 / 9042 / 11242 RSM 8442 / 9042 / 11242 RZM 8442 / 11242 SKRLS 9042 / 11242 SKRS 9042 / 11242 SKRZ 9042 / 11242 WRZM 8442 / 11242	
52227	3 434 3622 00 ø38xø60x55	Repair Kit, Brake Cam Shaft	SK 9042 / 11242 SKRS 9042/11242	
52228	3 317 0011 00	Repair Kit, Brake Cam Shaft	SKRLS 11242 SKRLS 9037 / 9042 / 9042/20 SKRLZ 9037 / 11037 SKRS 9037-8 / 9037-10 / 9042 SKRZ 9037-8 / 9037-10 / 9042 SNK 637/420 WRZM 8442	
52229	- ø38xø70x63 <i>Bushing: 52211-52212</i> <i>Spherical Bearing: 52210</i>	Repair Kit, Brake Cam Shaft	RZM 11030 / 13130 WRZM 8130/8435-8/8435- 10/11030 /11035-8/11035-10	
52230	- ø38xø60x55 <i>Spherical Bearing: 52207</i> <i>Retainer: 52214</i> <i>Dust Cover: 52213</i>	Repair Kit, Brake Cam Shaft		

Auger Nr.	OEM Nr.	Description	Model	Picture
52231	-	Repair Kit, Brake Cam Shaft ø38xø70x63 <i>Spherical Bearing: 52210</i> <i>Retainer: 52215</i>		
52232	3 268 0007 02	Repair Kit, Brake Cam Shaft ø38xø60x55	EBN 3140 EBN 3140-6 EBN 4040 EBN 4540	
52233	3 434 3637 00	Repair Kit, Brake Cam Shaft ø38xø70x63	RZ 8130 / 11030 WRZ 8130 / 11030 WRZ 8435 / 11035	
52234	3 434 3638 00	Repair Kit, Brake Cam Shaft ø38xø60x55	SKRS/RZ 9042/11242	
52235	3 434 3636 00	Repair Kit, Brake Cam Shaft ø38xø60x55	RS/RZ/WRZ 8442-11242 EBN/ESN 3140 - 5542 EBN 3130 - WE2N 6030	
52236	3 268 0006 00	Repair Kit, Brake Cam Shaft ø38xø70x63	WRZM 8130 RZM 11030 WRZM 11030 RZM 13130 WRZM 8435-8 WRZM 8435-10 WRZM 11035-8	
52237	3 317 0010 00	Repair Kit, Brake Cam Shaft	SNK 420 SKRS 9042	

Auger Nr.	OEM Nr.	Description	Model	Picture
52238	3 317 0009 00	Repair Kit, Brake Cam Shaft	RSM 9042 RSM 9042/20	
52239	3 317 0016 00	Repair Kit, Brake Cam Shaft	KRS 12242 / 12242/18 / 14242 SKRLS 9042 / 9042/2011242 SKRLZ 9030 / 11030 SKRS 6530 / 6537-8 / 6537-10 SKRZ 11030 / 11037-8 / 11037-10	
52240	3 317 0036 00	Repair Kit, Brake Cam Shaft		
52357	3 434 3639 00	Repair Kit, Brake Cam Shaft ø38x51,5/ø46x78	SKRS 9042 / 11242 SKRZ 9042 / 11242	
52374	3 434 3604 00	Repair Kit, Brake Cam Shaft ø38xø70x63		
52375	3 434 3600 00	Repair Kit, Brake Cam Shaft ø39xø60x38		
52504	3 434 3601 00	Repair Kit, Brake Cam Shaft ø39xø60x38	RSM 8442 / 9042 / 11242 RBM 8442 RLBM 8442 RZM 8442 / 11242 RLSM 8442 / 9042 / 11242 SKRLS 9042 / 11242 SKRS 9042 / 11242 SKRZ 9042 / 11242 WRZM 8442 / 11242	








Auger Nr.	OEM Nr.	Description	Model	Picture
52704	3 268 0034 00	Repair Kit, Brake Cam Shaft ø38xø60x55	EBN 3130/12 / 3140 / 4040 / 4530 ES 5030 / RS 5030 ESN 4030 / 4040 / 4540 / 5030 ESN 5542 / 6030 EZN 4030 / 4030/12 / 4530 / 6030 RBM 8442 / 8442/12	
52752	3 317 0005 00	Repair Kit, Brake Cam Shaft	CAMSHAFT Ø 42 mm FOR AXLE-TYPE SN420	
53563	3 268 0008 01	Repair Kit, Brake Cam Shaft	RLBM 8442 RLSM 8442 RLSM 9042 RLSM 9042/20 RLSM 11242	
53566	3 268 0033 00	Repair Kit, Brake Cam Shaft	RLBM 8442 RLSM 11242 RLSM 8442 RLSM 9042 RLSM 9042/20 SKRLS 11242 SKRLS 9042 SKRLS 9042/20	
53568	3 268 0032 00	Repair Kit, Brake Cam Shaft	RLBM 8442 RLSM 8442 RLSM 9042 RLSM 9042/20 RLSM 11242 SKRLS 9042 SKRLS 9042/20 SKRLS 11242	
53567	3 268 0037 00	Repair Kit, Brake Cam Shaft ø38xø70x63	RZM 13130 WRZM 11030 WRZM 11035-10 WRZM 11035-8 WRZM 8130 WRZM 8435-10 WRZM 8435-8	
53569	3 434 3619 00	Repair Kit, Brake Cam Shaft ø38x51,5	KRS 14242 KRZ 14242	

Auger Nr.	OEM Nr.	Description	Model	Picture
53570	3 434 3652 00	Repair Kit, Brake Cam Shaft ø38x51,5/ø46x78	SK 500 SK 500 PLUS	
53571	3 434 3614 00	Repair Kit, Brake Cam Shaft ø38xø60x55	SK 6537 / 9037 / 11037	
53572	3 434 3613 00	Repair Kit, Brake Cam Shaft ø38xø60x55	SK 6537 / 9037 / 11037	
53573	3 434 3611 00	Repair Kit, Brake Cam Shaft ø38xø60x55	SK 9042 / 11242	
53574	3 434 3610 00	Repair Kit, Brake Cam Shaft ø38xø60x55	SKRS 6530-11030 SKRZ 6530-11030	
53575	3 434 3634 00	Repair Kit, Brake Cam Shaft ø38xø60x55	SKRS 6537-11037 SKRZ 6537-11037	
53576	3 434 3642 00	Repair Kit, Cam Shaft ø38x51,5/ø46x78	SK 6537 / 9037 / 11037	

Auger Nr.	OEM Nr.	Description	Model	Picture
53579	3 434 3640 00	Repair Kit, Brake Cam Shaft ø38x51,5	SKRS 6530 - 11030 SKRS 9037 / 11037 SKRZ 6530 - 11030 SKRZ 9037 / 11037	
53580	3 268 0035 00	Repair Kit, Brake Cam Shaft ø38xø60x55	RSM 6542 EBN 3130/12 / 3140 / 3140-6 ESN 4030 / 4040 / 4540 / 5030 EZN 4030 / 4030/12 / 5030 / 6030 RBM 8442 / 8442/12 RSM 11242 / 6242/12-10 RZM 11242 / 12242 / 14242	
55226	3 268 0050 00	Repair Kit, Brake Cam Shaft ø46x78	KRS 12242 KRS 12242/18 S11-3720-S11-4218 S11-4220-S9-3718 S9-4218-S9-4220 SK 500/SK 500 PLUS SK RS 12242 SK RS 6537-10	
58142	2 175 0169 00 4 175 0239 00	Brake Slack Adjuster Automatic ø14x250/180/165/150/135/ 120x50° / Saddle Type		
58145	4 175 0184 00	Brake Slack Adjuster Automatic ø14x250/180/165/150/135/ 120x110° / Saddle Type		
58156	4 175 0235 00	Brake Slack Adjuster Automatic ø14x179/152x144° / Double Bent	WZRLZM 8130 SKZRLZ 12030 SKZRLZ 11030	
58158	4 175 0236 00	Brake Slack Adjuster Automatic ø14x179/152x145° / Double Bent	WZRLZM 8130 SKZRLZ 12030 SKZRLZ 11030	
58168	3 434 3502 02 2 175 0168 00	Brake Slack Adjuster Automatic ø14x250/180/155/140/125/ 105x130° / Saddle Type	KRS 12242 KRS 12242/18 KRS 14242 KRZ 14242 KRZ 16242 KRZT 14242 TRILEX KRZT 16242 TRILEX RBM 8442	

Auger Nr.	OEM Nr.	Description	Model	Picture
58177	4 175 0085 01 3 434 3508 00	Brake Slack Adjuster Automatic ø14x250/210/180/150/125x 130° / Saddle Type		
58183	4 175 0262 00	Brake Slack Adjuster Automatic ø14x180/155/140/125 / S- ABA / Saddle Type		
75784	2 100 2000 12 2 175 0294 00	Brake Slack Adjuster, Manuel	KRZ 14242 KRZ 16242 KRZT 14242 TRILEX KRZT 16242 TRILEX SK RS 6537-8 SK RS 6537-10 SK RS 9037-8 SK RS 9037-10	
69136	-	Brake Slack Adjuster, Automatic ø12,7x140 / S-ABA / Bent		
69137	-	Brake Slack Adjuster, Automatic ø14x105/125/140/155/180/ 250 / S-ABA		
52760	1 447 0037 00	Spring, Brake Slack Adjuster ø25,5x146	EBN 3140 / 3140-6 / 4040 / 4535 RS 5030 RZM 13130 SKRLZ 9037 SKRS 6537-8/6537-10/9030 / 9037-8 SKRS 9037-10 / 9042(INTRAAX)/9042	
52780	1 447 0036 00	Spring, Brake Slack Adjuster ø22,5x180	EBN 3130/12 / 4530 / 4540 / 4540-6 ESN 4030/ 4040/ 4540/ 5030/ 5542 EZN 4030 / 4030/12 / 5030 / 6030 KRS 12242 / 12242/18 / 14242 KRZT 14242 TRILEX / 16242 /	
31029	4 079 0004 00	Brake Disc	SK RS 9019 K (SN 6) SK RS 9019 W SK RS 11019 K (SN 6) SK RS 11019 W SK RZ 9019 K (SN 6) SK RZ 9019 W SK RZ 11019 K (SN 6) SK RZ 11019 W	

Auger Nr.	OEM Nr.	Description	Model	Picture
31030	4 079 0005 01 4 079 0005 00 4 079 0005 02	Brake Disc	SK RB 9022 K (SN 7) SK RB 9022 K 01 (SK 7) SK RB 9022 H (MK II/III) SK RB 9022 H (MK IV) SK RB 9022 H (Modul X) SK RB 9022 W	
31183	4 079 0003 00	Brake Disc	SK RS 9022 K (SN 7) SK RS 9022 H (MK IV) SK RS 9022 W SK RS 11222 K (SN 7) SK RS 11222 K 01 (SK 7) SK RS 11222 W SK RZ 9022 K (SN 7) SK RZ 9022 W SK RZ 11222 K (SN 7)	
31306	4 079 0013 01 4 079 0013 00	Brake Disc		
70676	3 434 3656 00	Repair Kit, Brake Disc	SK RB 9019 K (SN 6) SK RB 9019 KI (SN 6) INTEGRAL SK RB 9019 W SK RB 9019 WI INTEGRAL SK RB 9022 K (SN 7) SK RB 9022 K 01 (SK 7) SK RB 9022 KI (SN 7) INTEGRAL SK RB 9022 KI 01 (SK 7) INTEGRAL	
70677	3 434 3662 00	Repair Kit, Brake Disc	SK RB 9019 KI (SN 6) INTEGRAL SK RB 9019 WI INTEGRAL SK RB 9022 KI (SN 7) INTEGRAL SK RB 9022 KI 01 (SK 7) INTEGRAL SK RB 9022 WI INTEGRAL BA9-22K01 BI9-22K01 BI9-19K	
70678	3 434 3660 00	Repair Kit, Brake Disc	B9-19K B9-19W B9-22K01 B9-22W BA9-22K01 BI9-22K01 BI9-19K BI9-19W BI9-22W	
70679	3 434 3663 00	Repair Kit, Brake Disc	B9-19K B9-19W B9-22K01 B9-22W SI9-19K SI9-19W SI9-22W SI9-22K01 SI11-19K	

Auger Nr.	OEM Nr.	Description	Model	Picture
55997	3 434 3851 00	Spring Clamp, Brake Disc Pad, Haldex Type ø9x260x91,5	SK RB 9022 H (MK II/III) 9022/11222 H (MK II) Brake SBH 2243-11 S (MK II) 9022/11222 H Brake SBH 2243- 11 S (MK II/III/IV)	
54069	3 434 3812 00	Repair Kit, Brake Caliper, Knorr Type	SK RB 9022 K (SN 7) SK RB 9022 KI (SN 7) INTEGRAL SK RS 9022 K (SN 7) SK RS 11222 K (SN 7) 1937-11 S (SN 6) 9022/11222 K (SN 7) Brake SBK 2243-11 S (SN 7)	
54526	3 434 3815 00	Repair Kit, Brake Caliper, Knorr Type	SK RB 9022 K (SN 7) SK RB 9022 K 01 (SK 7) SK RB 9022 KI (SN 7) INTEGRAL SK RB 9022 KI 01 (SK 7) INTE- GRAL SK RS 9022 K (SN 7) SK RZ 11222 K 01 (SK 7) B9-22K01	
54559	3 434 3827 01	Repair Kit, Brake Caliper, Wabco Type	SK RB 9022 W SK RB 9022 WI INTEGRAL SK RS 9019 W SK RS 9022 W SK RS 11019 W SK RZ 11222 W SK RB 9019 WI INTEGRAL BI9-22W-6 B9-22W	
56026	3 434 3829 00	Repair Kit, Brake Caliper	SK RB 9019 W SK RB 9019 WI INTEGRAL SK RB 9022 W SK RB 9022 WI INTEGRAL SK RS 9019 W SK RS 11019 W SK RS 9022 W SK RS 11222 W B9-19W	
56090	3 434 3852 00 3 434 3855 00	Repair Kit, Brake Caliper	SK RB 9022 H (MK II/III) 9022/11222 H (MK II) FREN SBH 2243-11 S 9022/11222 H (MK III) FREN SBH 2243-11 S	
56091	3 434 3852 02	Repair Kit, Brake Caliper	SK RB 9022 H (MK IV) SK RB 9022 H (Modül X) 9022/11222H(MODUL X) FREN SBH 2243-11 S (MODUL X)	

Auger Nr.	OEM Nr.	Description	Model	Picture
56095	3 434 3854 01 3 434 3858 00	Repair Kit, Brake Caliper	SK RB 9022 H (MK II/III) SK RB 9022 H (MK IV) 9022/11222 H (MK II) FREN SBH 2243-11 S 9022/11222 H FREN SBH 2243-11 S 9022/11222 H (MK III) FREN SBH 2243-11 S 9022/11222 H (MK IV) FREN SBH 2243-11 S	
56096	3 434 3854 02	Repair Kit, Brake Caliper	SK RB 9022 H (Modül X) 9022/11222H(MODUL X) FREN SBH 2243-11 S (MODUL X)	
70838	3 434 3828 00	Repair Kit, Brake Caliper		
52241	3 005 0147 00	Brake Dust Cover Kit ø150xø462x34	RSM 6542 RSM 9042	
52242	3 005 0173 00	Brake Dust Cover Kit ø145xø452x32	KRS 12242 / 12242/18 / 14242 KRZ 16242 KRZT 16242 TRILEX SKRS 9042 / 11242 / 12242 SKRS 9042 INTRAAX (SK 1000 ET 0) SKRS 9042 SK 1000 ET 0 SKRS 9042/20 / 9042 SK 500 (PLUS) SKRZ 9042 / 9042/20 / 11242	
52243	3 005 0117 01	Brake Dust Cover Kit ø149xø460x46	RSM 9042/20	

Auger Nr.	OEM Nr.	Description	Model	Picture
52244	3 005 0141 00	Brake Dust Cover Kit ø145xø452x31	SKRS 9042 SKRS 9042/20 SKRS 11242 SKRZ 9042 SKRZ 9042/20 SKRZ 11242	
52377	3 005 0108 00	Brake Dust Cover Kit ø127xø397x24	WRZM 11035-10 WRZM 11035-8 WRZM 8435-10 WRZM 8435-8	
52245	3 005 0055 00	Brake Dust Cover Kit ø149xø295x50	WRZM 8130 RZM 11030 WRZM 11030 RZM 13130	
52246	3 005 0009 02	Brake Dust Cover Kit ø230xø467x65	RLSM 11242 RSM 11242 RZM 8442 / 8442-8 / 11242 / 12242 / 13130 / 14242 / 16242 RZT 14242 / 16242 WRZM 6242/6242-8/8442/8442- 8	
53062	3 005 0037 03	Brake Dust Cover Kit ø230xø465x54	RBM 8442 RSM 8442 RSM 8442-8 RLBM 8442 RLSM 8442	
53171	-	Brake Dust Cover Kit ø230xø445x65		

Auger Nr.	OEM Nr.	Description	Model	Picture
53585	3 005 0177 00	Brake Dust Cover Kit ø155xø450x29	SKRZT 12242 SKRLS 9042 SKRLS 9042/20 SKRLS 11242	
53586	3 005 0135 00	Brake Dust Cover Kit ø150xø462x32	RLBM 8442 RLSM 9042	
53587	3 005 0139 00	Brake Dust Cover Kit ø150xø462x46	RLSM 9042/20 RLSM 11242	
53588	3 005 0149 00	Brake Dust Cover Kit ø155xø452x27	SKRLS 9042 SKRLS 9042/20 SKRLS 11242	
53589	3 005 0159 00	Brake Dust Cover Kit ø127xø400x29	SKRS 9037-8 SKRS 9037-10 SKRZ 9037-8 SKRZ 9037-10 SKRZ 11037-8 SKRZ 11037-10	
53590	3 005 0053 00	Brake Dust Cover Kit ø149xø295x23	EBN 3130/12 ESN 4030 EZN 4030 EZN 4030/12 EBN 4530 ESN 5030 EZN 5030 WESN 5030 WEZN 5030 ESN 6030 EZN 6030 WESN 6030 WEZN 6030 6030/12	

Auger Nr.	OEM Nr.	Description	Model	Picture
53591	3 005 0045 00	Brake Dust Cover Kit ø230xø413x21	ESN 5542 RSM 6242/12-8 RSM 6242/12-10 RBM 8442/12	
53592	3 005 0125 00	Brake Dust Cover Kit ø127xø397x31	WRZM 8435-8 WRZM 8435-10 WRZM 11035-8 WRZM 11035-10	
53593	3 005 0161 00	Brake Dust Cover Kit ø127xø331x37	SKRZ 6530 SKRS 9030 SKRZ 9030 SKRZ 11030 SKRZ 12030	
53594	3 005 0171 00	Brake Dust Cover Kit ø127xø400x25	SKRS 9037-8 SKRS 9037-10 SKRZ 9037-8 SKRZ 9037-10 SKRZ 11037-8 SKRZ 11037-10 SKRZ 12037	
53596	3 005 0183 00	Brake Dust Cover Kit ø155xø331x26	SKRLZ 9030 SKRLZ 11030	
53597	3 005 0057 00	Brake Dust Cover Kit ø140xø349x34	EBN 4535 EBN 5535	

Auger Nr.	OEM Nr.	Description	Model	Picture
53598	3 005 0079 00	Brake Dust Cover Kit ø151xø295x49,5	WRLZM 8130 WRLZM 11030	
53599	3 005 0209 01	Brake Dust Cover Kit ø155xø400x30	SKRLZ 9037 SKRLZ 11037	
70675	3 005 0210 00	Brake Dust Cover Kit		
21004	-	Service Brake Chamber, for Disc Brake M16/120,7x97,5/140,5x164 T16 STR 57		
21005	3 454 1081 60 3 454 1065 60	Service Brake Chamber, for Disc Brake, with Repair Kit M16/120,7x97,5/140,5x164 T16 STR 57		
21006	-	Service Brake Chamber, for Disc Brake M16/120,7x105/164x174 T20 STR 64		

Auger Nr.	OEM Nr.	Description	Model	Picture
21007	3 454 1067 60 3 454 1082 60	Service Brake Chamber, for Disc Brake, with Repair Kit	M16/120,7x105/164x174 T20 STR 64	
21008	-	Service Brake Chamber, for Disc Brake	M16/120,7x103/160x186 T24 STR 64	
21009	3 454 1069 60	Service Brake Chamber, for Disc Brake, with Repair Kit	M16/120,7x103/160x186 T24 STR 64	
21016	-	Service Brake Chamber, for Drum Brake	M16/120,7x117,5/302,5x208 T30 STR 75	
21017	4 454 1039 00	Service Brake Chamber, for Drum Brake, with Repair Kit	M16/120,7x117,5/344,5x208 T30 STR 75	

Diaphragms - Normal Stroke


Auger Nr.: 52576	
OEM Nr.	—
Type	9"
Auger Nr.: 52578	
OEM Nr.	—
Type	12"
Auger Nr.: 52580	
OEM Nr.	—
Type	16"
Auger Nr.: 52581	
OEM Nr.	—
Type	20"
Auger Nr.: 52582	
OEM Nr.	—
Type	24"
Auger Nr.: 52583	
OEM Nr.	—
Type	30"
Auger Nr.: 52584	
OEM Nr.	—
Type	36"



Diaphragms - Long Stroke

Auger Nr.: 52585	
OEM Nr.	—
Type	16"
Auger Nr.: 52586	
OEM Nr.	—
Type	20"
Auger Nr.: 52587	
OEM Nr.	—
Type	24"
Auger Nr.: 52588	
OEM Nr.	—
Type	30"



Auger Nr.	OEM Nr.	Description	Model	Picture				
71932	4 029 1002 00 3 029 0231 00	Sensor, ABS	S9-3718					
			S9-4218					
	S9-4220							
	S11-3720							
	Z7-3015							
	Z8-3718							
	Z8-3718 (TK285/10-ALU)							
	Z8-3718 (TK335/10-ALU)							
	Z11-3020							
	Z11-3720 -8L							
	Z11-3720 -10L							
	71934		4 029 1042 00 3 029 0232 00		Sensor, ABS L: 1000 mm	SK RS 9019 K (SN 6)		
						SK RS 9019 W		
SK RS 11019 K (SN 6)								
SK RS 11019 W								
SK RS 9022 K (SN 7)								
SK RS 9022 H (MK IV)								
SK RS 9022 W								
SK RS 11222 K (SN 7)								
SK RS 11222 K 01 (SN 7)								
SK RS 11222 W								
SK RZ 9019 K (SN 6)								
57059	4 029 1063 00	Ring, ABS ø116,5/ø147,75x18,5	SK RB 9019 KI (SN 6) INTEGRAL					
			SK RB 9019 WI INTEGRAL					
			SK RB 9022 KI (SN 7) INTEGRAL					
			SK RB 9022 WI INTEGRAL					
71397	4 029 1070 00	Ring, ABS ø150xø184x11	S9-3718					
			S9-4218					
			S9-4220					
			S11-3720					
			S11-4218					
			S11-4220					
			SL9-3718					
			SL9-4218					
			SL11-4220					
			SZL11-4218					
			SZL11-4220					
			71659		4 029 1069 00	Ring, ABS ø148,5xø184x11	S7-3015	
							Z7-3015	
							Z9-3020	
Z11-3020								
Z11-3020 -8L								
Z11-3020 -10L								
ZL9-3020								
ZL9-3720								
ZL11-3020								
ZL11-3720								

Auger Nr.	OEM Nr.	Description	Model	Picture
52104	4 177 3016 00	Rubber Bushing, Spring ø36xø65,5xø68	VRZ 28 VRZ 42 VRZ 48	
52217	4 177 3010 00	Rubber Bushing, Spring ø30xø68x104	AR 311 / EM 311 AR 311 E / EM 311 E AR 311 EH / EM 311 EH AR 311 H / EM 311 H AR 314 / EO 314 AR 314 E / EO 314 E AR 314 EH / EO 314 EH AR 314 H / EO 314 H	
52359	4 177 0008 00	Rubber Bushing, Spring ø24xø59x107		
57046	4 177 3033 00	Rubber Bushing, Spring ø30xø74x74		
54281	4 177 0020 00	Rubber Bushing, Spring ø20xø62x102		
52370	2 095 2039 00	Rubber Bushing, Spring ø15xø40x101	VDS16 - VDS20 VDZ16 - VDZ20 VDS 16 - VDS 20 VDS 24 - VDS 24 K VDZ 16 - VDZ 20 VLZ 30T - VLZ 40T VLS 22 - VRZ 20 VRZ 20 T	
53559	1 177 2002 00	Rubber Bushing, Spring ø50xø92x121	VDS16 - VDS 20 VDZ 16 - VDZ 20 VDS 24 - VDS 20 VDS 16 - VDS 24 K VDZ 16 - VDZ 20 VLS 22 - VRZ 20	
53560	1 177 1001 02	Rubber Bushing, Spring ø30xø55x61,5	VDS16 - VDS 20 VDZ 16 - VDZ 20 VDS 24 K - VDS 16 VDS 20 - VDS 24 VDZ 16 - VDZ 20 VLZ 30T - VLZ 40T VLS 22 - VRZ 20 VRZ 20	

Auger Nr.	OEM Nr.	Description	Model	Picture
52168	1 169 0003 01	Mounting, Spring 112x158x64	VDS 16 VDS 20 VDS 24 VDS 24 K VDZ 16 VLZ 40 T VRZ 20 VRZ 20 T	
52169	1 318 1001 02	Mounting, Spring ø24x69/74x110	VDS 16 VDS 20 VDS 24 VDS 24 K VDZ 16 VDZ 20 VLS 22 VRZ 20 T	
54033	4 343 0080 88	Bolt, Spring 260/M30x3,5		
54034	4 343 1048 88	Bolt, Spring 205/M30x3,5		
54035	4 343 1053 00	Bolt, Spring 240/M30x3,5		
54794	1 051 1008 00	Bolt, Spring ø50x310/M48x3	VDS 16 - VDS 20 VDZ 16 - VDZ 20 VDS 24 - VDS 20 VDS16 - VDS 24 VDS 24 K - VDZ16 VDZ 20 - VLS 22 VRZ 20	
54796	4 343 0013 88	Bolt, Spring 100/M16x2		
55276	4 343 2055 10	Bolt, Spring 250/M22x1,5	INTRAAX XO INTRAAX XU INTRADISC PLUS PO INTRADISC PLUS PU	

Auger Nr.	OEM Nr.	Description	Model	Picture
72227	4 343 0068 88	Bolt, Spring		 Sample
54053	4 247 4022 80	Nut, Spring M30x3,5		
54058	4 202 1006 80	Nut, Spring M48x3		
55275	4 331 5029 00	Bushing, Spring, Plastic ø60xø170x5		
70665	1 072 2017 00	Bushing, Spring, Plastic ø70xø92x45	VLZ 30 T VLZ 40 T VRZ 20 VRZ 20 T	
69092	1 136 0312 00	U Bolt, Spring M24x3/126x351	VDS 20 VDZ 20	
69093	1 136 0304 00	U Bolt, Spring M24x3/126x336	VDS 16 VDZ 16	
69094	1 136 0307 00	U Bolt, Spring M24x3/126x312	VDS 24 K VRZ 20	

Auger Nr.	OEM Nr.	Description	Model	Picture
69095	1 136 0309 00	U Bolt, Spring M24x3/126x298	VDS 16 VDS 20 VDS 24 VDZ 16 VDZ 20 VLS 22 VRZ 20	
69096	1 136 0003 01	U Bolt, Spring M30x2/176x433	IDDS 16 IDDZ 16	
69097	1 136 0102 00	U Bolt, Spring M20x2.5/160x325	IDDS 16 IDDZ 16	
69098	1 402 0020 00	U Bolt, Spring M24x2/159x308		
75345	3 401 0065 00 3 401 0091 25	U Bolt, Spring M22x1,5/147x325	Air suspension series M / O / U AR 411 / EM 411 AR 411H / EM 411H AR 413 AR 413 H AR 414 / EO 414 AR 414H / EO 414H AR 416 / EU 416	
75346	1 402 0065 01	U Bolt, Spring M22x1,5/147x325	Air suspension series M / O / U AR 411 / EM 411 AR 411H / EM 411H AR 413 AR 413 H AR 414 / EO 414 AR 414H / EO 414H AR 416 / EU 416	
70674	3 434 3661 00	Repair Kit, Spring		
53037	3 341 1048 19	Repair Kit, Spring M30x3,5/205	AR 112 - AR 313 WITH LIFT AR 113 / 211 / 212 / 213 AR 311 / EM 311 / 311E / EM311E AR 314 / EO 314 / 314E / EO 314E AR 316 / EU316 / 316E / EU316E AR 416 / EU416 / 416E / EU416E MODULAR SYSTEM M-O-U	

Auger Nr.	OEM Nr.	Description	Model	Picture
57071	3 143 1006 00	Repair Kit, Spring M30x3,5/205	MODULAR SYSTEM M / O / U	
57070	3 434 3645 00	Repair Kit, Spring ø30xø68x104	MODULAR SYSTEM M / O / U	
53565	3 434 3644 00	Repair Kit, Spring ø30xø68x104	Air suspension series M / O / U	
53564	3 434 3643 00	Repair Kit, Spring ø30xø68x104	Air suspension series AR/EO/EM/EU	
52376	3 227 0190 00 5 399 0020 70	Repair Kit, Spring M30x3.5/260		
53595	3 050 1008 00	Repair Kit, Spring ø50x310/M48x3	VDS 16 - VDS 20 VDZ 16 - VDZ 20 VDS 24 - VDS 20 VDS16 - VDS 24 VDS 24 K - VDZ16 VDZ 20 - VLS 22 VRZ 20	

Auger Nr.	OEM Nr.	Description	Model	Picture
AU 34810-K	2 229 2102 00	Air Spring	AR 112	
	2 229 2602 00	ø305x340	AR 113	
	2 229 0002 00			
	2 228 2202 00			
AU 34813-K	2 229 0003 00	Air Spring	AR 414H/EO 414H	
	2 229 2103 00	ø305x420	AR 414EH/EO 414EH	
	2 229 2403 00		AR 416H/EU 416H	
	2 229 2603 00		AR 416EH/EU 416EH	
			AR 311H/EM 311H	
AR 311EH/EM 311EH				
AU 344004	4 284 3003 01	Air Spring		
		ø259x449		
AU 344004-KP	3 229 0007 02	Air Spring	AR 411H/EM 411H	
	3 229 0007 01	ø280x330	AR 411EH/EM 411EH	
	3 229 0007 00		AR 414H/EO 414H	
	3 229 2007 00		AR 414EH/EO 414EH	
			AR 416H/EU 416H	
AR 416EH/EU 416EH				
AR 311H/EM 311H				
AR 311EH/EM 311EH				
AU 344022	4 284 3006 00	Air Spring		
		ø248x442		
AU 344022-KP	3 229 0029 00	Air Spring		
	3 229 2129 00	ø280x348		
	3 229 2229 00			
	3 229 2429 00			

Auger Nr.	OEM Nr.	Description	Model	Picture
AU 344022-KP05	3 229 0033 00 3 228 1033 00	Air Spring ø280x380	INTRAAX "XO" INTRAAX "XU" INTRADISC PLUS "PO" INTRADISC PLUS "PU"	
AU 344023K	3 229 0031 00 3 229 2131 00 3 229 2431 00 3 229 2231 00	Air Spring ø310x385	INTRADISC PLUS "PO" INTRADISC PLUS "PU"	
AU 344810K05	3 229 0027 00 3 229 2127 00 3 229 2227 00 3 229 2427 00	Air Spring ø330x340	INTRAAX "XO" INTRAAX "XU"	
AU 344023 -		Air Spring		
AU 344023-KP -		Air Spring		 Sample
AU 344028 -		Air Spring		

Auger Nr.	OEM Nr.	Description	Model	Picture
AU 344028-K	-	Air Spring		
AU 344813K	3 229 0005 00	Air Spring ø345x385		
AU 34220-08	4 229 1004 00	Air Spring ø216x200		
AU 342924-KP	3 229 0028 00 3 229 0041 00 3 229 2128 00	Air Spring	INTRAAX "XO" INTRAAX "XU" INTRADISC PLUS "IU" INTRADISC PLUS "PO" INTRADISC PLUS "PU" INTRADISC PLUS MEGA "IU" INTRADISC EVOLUTION "VU"	
20122	2 228 0002 00 S 2 228 2102 00 S 2 228 2602 00 S 2 228 2202 00 S	Piston, Air Spring, for AU 34810-K ø260x140	AR 112 AR 113	
20123	2 229 0003 00 S 2 229 2103 00 S 2 229 2403 00 S 2 229 2603 00 S	Piston, Air Spring, for AU 34813-K, AU 344023-K and AU 344813-K ø260x178	AR 414H/EO 414H AR 414EH/EO 414EH AR 416H/EU 416H AR 416EH/EU 416EH AR 311H/EM 311H AR 311EH/EM 311EH	

NEW

NEW

Sample

Auger Nr.	OEM Nr.	Description	Model	Picture
67899	1 072 0086 01	Bushing, Bogie Suspension ø113xø129x249		
51075	1 230 0047 00	Bushing, Stabilizer Bar ø25xø35x28		
52995	1 230 0130 00 1 230 0063 00	Bearing, Stabilizer Bar ø49x70		
53035	1 230 0131 00 1 230 0060 00	Bearing, Stabilizer Bar ø46x70		
53036	1 230 0048 00	Bearing, Stabilizer Bar ø39,5x70		
70660	4 343 2028 88	Connecting Bolt, Connecting Rod M36x4/155	VRZ 28 VRZ 42 VRZ 48	
70661	4 343 2029 88	Connecting Bolt, Connecting Rod M36x4/185	VRZ 28 VRZ 42 VRZ 48	
70662	4 343 2030 88	Connecting Bolt, Connecting Rod M36x4/225	VRZ 28 VRZ 42 VRZ 48	

Auger Nr.	OEM Nr.	Description	Model	Picture
20205	2 376 4026 00	Shock Absorber,	"INTRADISC PLUS ""PO"""	
	2 376 0026 00	Rear&Front	"INTRADISC PLUS ""PU"""	
	2 376 0028 00	ø24x329/494		
	2 376 0022 00			
20207	2 376 0027 00	Shock Absorber, Rear	INTRADISC PLUS PO	
			INTRADISC PLUS PU	
			INTRADISC EVOLUTION VO	
			INTRADISC EVOLUTION VU	
20208	2 376 0019 00	Shock Absorber, Rear		
20209	2 376 1005 00	Shock Absorber	SK RLS 9042	
			SK RLS 9042	
			SK RLS 9042	
			SK RLS 9042/20	
			SK RLS 9042/20	
			SK RLS 9042/20	
			SK RLS 11242	
20210	2 376 0071 01	Shock Absorber	"INTRADISC PLUS ""IO"""	
	2 376 0071 00			
20212	2 376 0072 01	Shock Absorber	INTRADISC PLUS ""IO""	
	2 376 0072 00			
20211	2 376 0070 01	Shock Absorber	"INTRADISC PLUS ""IO"""	
	2 376 0070 00			








Auger Nr.	OEM Nr.	Description	Model	Picture
54005	1 345 0008 01	Lock Washer, Axle ø56,5xø93x4,5	KRS 12242 / 12242/18 RBM 8442 / 8442/12 RLBM 8442 RLSM 8442 / 11242 SKRLZ 9030 / 11030 SKRS 9030/12242/9042 SK 500 (PLUS) SKZRLZ 11030 / 12030 SKRZT 12242	
52176	1 011 0007 00	Axle Nut M42x3/SW65	RS 5030 ESN 4540 / 5542 / 6030 / 5030 / 6030 EZN 5030 / 6030 WESN 5030 / 6030 WEZN 5030 / 6030 / 6030/12 EBN 5535	
54003	4 011 0039 01	Axle Nut M56x2/SW85	KRS 12242 / 12242/18 RBM 8442 / 8442/12 RLBM 8442 RLSM 8442 / 11242 SKRLZ 9030 / 11030 SKRS 9030 / 9042 SK 500 (PLUS) / 12242 SKRZT 12242 SKZRLZ 11030 / 12030 WRZM 6242 / 6242-8 / 11242	
54004	2 011 0040 01 1 011 0040 02 1 011 0040 01 1 011 0040 00	Axle Nut M56x2/SW85	SK RZ 11030 SK RS 9042 SK 500 SK RS 12242 SK RZ 6530 SK RZ 9030 SK RZ 12030 SK RZ 12037 SK RZ 12242 SK RZT 12242	
54277	1 011 0080 00 1 011 0088 00	Axle Nut M72x1,5 RHT	SK RB 9019 K (SN6) SK RB 9019 KI (SN6) INTEGRAL SK RB 9019 W SK RB 9019 WI INTEGRAL SK RB 9022 KI (SN 7)INTEGRAL SK RB 9022 KI (SK 7)INTEGRAL SK RB 9022 W SK RLB 9019 IO/IU SK RLB 9022	
54278	1 011 0081 00 1 011 0087 00	Axle Nut M72x1,5 LHT	SK RB 9019 K (SN6) SK RB 9022 W SK RB 9019 KI (SN6) INTEGRAL SK RB 9022 H SK RB 9019 WI INTEGRAL SK RB 9022 K (SK7) SK RLB 9019 IO/IU SK RB 9022 KI (SN 7)INTEGRAL SK RLB 9022	
54279	1 011 0070 01	Axle Nut M120x2 RHT	SKRLS 9042 / 9042/20 / 11242 SKRS 11019 W / 11222 K (SK7) SKRS 9019 W / 9019K (SN6) SKRZ 11019 K (SN 6) / 11019 W SKRZ 9019 W / 9019K (SN6) SKRZ 9022 K (SK 7) / 9019 W SKRZ 9042 / 9042/20 / 9022 W SKRS 9022 H (MK IV) / 9022	

Auger Nr.	OEM Nr.	Description	Model	Picture
54280	1 011 0071 01	Axle Nut M120x2 LHT	SKRLS 9042 / 9042/20 / 11242 SKRS 11019 W / 11222 K (SK7) SKRS 9019 W / 9019K (SN6) SKRZ 11019 K (SN 6) / 11019 W SKRZ 9019 W / 9019K (SN6) SKRZ 9022 K (SK 7) / 9019 W SKRZ 9042 / 9042/20 / 9022 W SKRS 9022 H (MK IV) / 9022	
70667	1 011 0041 01	Axle Nut M60x4/SW90	RZM 16242	
57073	3 011 0040 01	Repair Kit, Axle M56x2/SW85	KRS 12242 / 12242/18 RBM 8442 / 8442/12 RLBM 8442 RLSM 8442 / 11242 RSM 6242/12-8 / 6242/12-10 RZM 8442 / 8442-8 / 11030 SKRLZ 9030 / 11030 SKRS 9030 / 9042	
54644	4 230 0170 00	Bushing, Axle Steering Knuckle ø60xø65x70	RLBM 8442 RLSM 8442/9042/11242 RLSM 9042/20 SK RLB 9019/9019 IO/IO SK RLB 9022/9022 IO/IO SK RLS 9037/11242 SK RLS 9042/9042/20 SK RLZ 11030/11037/9030/9037 WRLZM 11030/11035-8/11035-10	
57538	3 434 3657 00	King Pin Kit, Axle Steering Knuckle ø60x298	SL9-3718 SL9-4218 SL11-4220 SZL11-4218 SZL11-4220 ZL8-3718 ZL9-3020 ZL9-3720 ZL11-4220	
54285	4 177 3026 00	Rubber Bushing, Balance Arm Axle ø31,5xø152x171	INTRAAX XO INTRAAX XU INTRADISC PLUS PO INTRADISC PLUS PU	
53555	4 177 3028 00	Rubber Bushing, Balance Arm Axle ø31,5xø155x114	SKRLB 9019I O/IO SKRLB 9022I O/IO INTRADISC PLUS IO INTRADISC PLUS IO	

Auger Nr.	OEM Nr.	Description	Model	Picture
55181	4 177 3028 00 S	Repair Kit, Balance Arm Axle ø31,5xø155x114 <i>Ruber Bushing: 53555</i> <i>Bushing: 55275</i>	SKRLB 9019I O/IU SKRLB 9022I O/IU INTRADISC PLUS IU INTRADISC PLUS IO	
55182	4 177 3026 00 S	Repair Kit, Balance Arm Axle ø31,5xø152x171 <i>Ruber Bushing: 54285</i>	INTRAAX XO INTRAAX XU INTRADISC PLUS PO INTRADISC PLUS PU	
68135	3 307 3006 00 3 307 3003 00	Wheel Hub, with Bearing ø120x124	SK RS 9042 / SK 1000 SK RS 9042/20 SK RS 9042 INTRAAX SK RS 11242 SK RZ 11242 SK RZ 9042 SK RZ 9042/20 SK RLS 9042 SK RLS 9042/20	
68136	3 307 3006 00 S 3 307 3003 00 S	Wheel Hub, Only Casting Body ø180x124	SK RS 9042 / SK 1000 SK RS 9042/20 SK RS 9042 INTRAAX SK RS 11242 SK RZ 11242 SK RZ 9042 SK RZ 9042/20 SK RLS 9042 SK RLS 9042/20	
68137	2 307 1042 00 2 307 1042 12 2 307 1060 00	Wheel Hub, Only Casting Body ø120xø147x182	RZM 8442 RZM 11242 WRZM 8442 WRZM 11242	
75341	2 307 1042 00 S 2 307 1042 12 S 2 307 1060 00 S	Wheel Hub, With Bearing	RZM 8442 RZM 11242 WRZM 8442 WRZM 11242	NEW Sample
75301	3 307 2056 00 S	Wheel Hub, Only Casting Body	SK RS 9030 SK RZ 6530 SK RZ 9030 SK RZ 11030 SK RZ 12030 SK RZ 12037	NEW

Auger Nr.	OEM Nr.	Description	Model	Picture
75302	3 307 2056 00 S1	Wheel Hub, With Bearing	SK RS 9030 SK RZ 6530 SK RZ 9030 SK RZ 11030 SK RZ 12030 SK RZ 12037	  Sample
75303	1 307 1159 10 3 307 1159 00 S	Wheel Hub, Only Casting Body	KRS 12242 KRS 12242/18 SK RS 9042 SK 500 SK RS 12242 SK RZ 12242	 
75304	1 307 1159 10 S 3 307 1159 00 S1	Wheel Hub, With Bearing	KRS 12242 KRS 12242/18 SK RS 9042 SK 500 SK RS 12242 SK RZ 12242	  Sample
75305	2 307 1054 00	Wheel Hub, Only Casting Body	KRZ 16242 RZM 16242	 
75306	2 307 1054 00 S	Wheel Hub, With Bearing	KRZ 16242 RZM 16242	  Sample
75307	1 307 3025 10 3 307 3025 01 S	Wheel Hub, Only Casting Body	SK RS 9019 K (SN 6) SK RS 9019 W SK RS 11019 K (SN 6) SK RS 11019 W SK RZ 9019 K (SN 6) SK RZ 9019 W SK RZ 11019 K (SN 6) SK RZ 11019 W	 
75308	1 307 3025 10 S 3 307 3025 01 S1	Wheel Hub, With Bearing	SK RS 9019 K (SN 6) SK RS 9019 W SK RS 11019 K (SN 6) SK RS 11019 W SK RZ 9019 K (SN 6) SK RZ 9019 W SK RZ 11019 K (SN 6) SK RZ 11019 W	  Sample

Auger Nr.	OEM Nr.	Description	Model	Picture
75309	1 307 1055 10	Wheel Hub, Only Casting Body		
75311	1 307 3030 11 3 307 3030 01 S 3 307 3030 00 S	Wheel Hub, Only Casting Body	SK RB 9019 KI (SN 6) INTEGRAL SK RB 9019 WI INTEGRAL SK RB 9022 KI (SN 7) INTEGRAL SK RB 9022 KI 01 (SK 7) INTEGRAL SK RB 9022 WI INTEGRAL	
75312	1 307 3030 11 S 3 307 3030 01 S1 3 307 3030 00 S1	Wheel Hub, With Bearing	SK RB 9019 KI (SN 6) INTEGRAL SK RB 9019 WI INTEGRAL SK RB 9022 KI (SN 7) INTEGRAL SK RB 9022 KI 01 (SK 7) INTEGRAL SK RB 9022 WI INTEGRAL	 Sample
75313	1 307 3043 10 3 307 3043 01 S 3 307 3043 00 S	Wheel Hub, Only Casting Body	S9-4218 S9-4220 S11-4218 S11-4220 Z9-4218 Z9-4220 Z11-4218 Z11-4220 SL9-4218	
75314	1 307 3043 10 S 3 307 3043 01 S1 3 307 3043 00 S1	Wheel Hub, With Bearing	S9-4218 S9-4220 S11-4218 S11-4220 Z9-4218 Z9-4220 Z11-4218 Z11-4220 SL9-4218	 Sample
75315	1 307 3056 10 3 307 3056 00 S	Wheel Hub, Only Casting Body		
75316	1 307 3056 10 S 3 307 3056 00 S1	Wheel Hub, With Bearing		 Sample

Auger Nr.	OEM Nr.	Description	Model	Picture
75317	1 307 3045 10 3 307 3045 00 S	Wheel Hub, Only Casting Body	BA9-22K01 BI9-22K01 BI9-19K BI9-19W BI9-22W-6 BI9-22W BIL9-22K01 BINL9-22K01	
75318	1 307 3045 10 S 3 307 3045 00 S1	Wheel Hub, With Bearing	BA9-22K01 BI9-22K01 BI9-19K BI9-19W BI9-22W-6 BI9-22W BIL9-22K01 BINL9-22K01	 Sample
75299	604 202 224	Wheel Hub, Only Casting Body, Trilex Type		
75300	604 202 224 S	Wheel Hub, With Bearing, Trilex Type		 Sample
75310	1 146 2001 00	Flange, Wheel Hub	SK RB 9019 K (SN 6) SK RB 9019 W SK RB 9022 K (SN 7) SK RB 9022 H (MK II/III) SK RB 9022 H (MK IV) SK RB 9022 H (Modul X) SK RB 9022 W	
69246	4 343 0008 00 4 373 0008 00	Seal Ring, Wheel Hub ø125xø150x13 / NBR		
69329	4 373 0006 00	Seal Ring, Wheel Hub ø180xø200x15 / NBR	KRZT 16242 TRILEX RZM 16242	








Auger Nr.	OEM Nr.	Description	Model	Picture
54883	4 373 0035 01	Seal Ring, Wheel Hub ø116,5xø152,5x25,5	KRS 12242 KRS 12242/18 SK RS 9030 SK RS 9042 SK 500 SK RS 9042 SK 500 plus SK RS 12242 SK RZ 6530 SK RZ 9030	 NEW
70666	1 368 0063 00	Thrust Ring, Wheel Hub ø110xø180x45	KRZT 16242 TRILEX RZM 16242	
69666	4 200 0025 00	Bearing, Wheel Hub ø85xø150x38,5		
69667	4 200 0026 00	Bearing, Wheel Hub ø95xø170x45,5	KRZT 14242 TRILEX KRZ 14242 KRS 14242 RZT 14242 RZM 14242	
69669	4 200 0033 00	Bearing, Wheel Hub ø60xø130x48,5	RZM 14242 RZT 14242 RZM 13130	
69671	4 200 0034 00	Bearing, Wheel Hub ø70xø150x54	KRZT 16242 TRILEX KRZ 16242 RZT 16242 RZM 16242	
69673	4 200 0015 00	Bearing, Wheel Hub ø60xø130x33,5	ESN 4540 WEZN 5030 WESN 5030 RS 5030 EZN 5030 ESN 5030 ES 5030	
69674	4 200 0032 00	Bearing, Wheel Hub ø55xø120x45,5		

Auger Nr.	OEM Nr.	Description	Model	Picture
69709	4 200 0012 00	Bearing, Wheel Hub ø45xø100x27,25	ESN 5542 ESN 4540 WEZN 6030/12" WEZN 6030 WEZN 5030 WESN 6030 WESN 5030 RS 5030	
69713	4 200 0028 00	Bearing, Wheel Hub ø105xø190x53	KRZT 16242 TRILEX KRZ 16242 RZT 16242 RZM 16242	
69714	4 200 0016 00	Bearing, Wheel Hub ø65xø140x36	WEZN 6030/12" WEZN 6030 WESN 6030 EZN 6030 ESN 6030	
69676	4 200 0023 00	Bearing, Wheel Hub ø65xø120x32,75	ESN 5542	
69684	4 200 0058 00	Bearing, Wheel Hub ø55xø100x35	EBN 3140-6 EBN 3130/12"	
69692	4 200 0057 00	Bearing, Wheel Hub ø35xø72x28	ENB 3140-6 ENB 3140/12"	
69698	4 200 0055 00	Bearing, Wheel Hub ø65xø110x34	EBN 5535 WRZM 6242-8 WRZM 6242 RSM 6242/12-10 RSM 6242/12-8	
69699	4 200 0063 00	Bearing, Wheel Hub ø45xø85x32	EBN 4540-10 EBN 4540-6 EBN 4540 EBN 4530 EBN 4535	

Auger Nr.	OEM Nr.	Description	Model	Picture
70288	4 200 0051 00	Bearing, Wheel Hub ø80xø130x35		
56618	4 200 0070 00	Bearing, Wheel Hub ø75xø130x41	KRZ 14242 KRZT 14242 TRILEX	
57013	4 200 1009 00	Bearing, Wheel Hub ø90xø150x45	RZM 12242	
57014	4 200 0060 00	Bearing, Wheel Hub ø65xø120x41	SK RS 12242 SK RZ 6530 SK RZ 9030 SK RZ 11030 SK RZ 12030 SK RZ 12037 SK RZ 12242 SK RZT 12242	
57050	4 200 1010 00	Bearing, Wheel Hub ø120xø165x29	RSM 9042 RSM 9042/20 RLSM 9042 RLSM 9042/20	
57145	4 200 0027 00	Bearing, Wheel Hub ø90xø160x42,5	RZM 13130	
57047	4 200 1016 02	Bearing, Wheel Hub ø120xø175x29/61,5	SK RS 9019 W SK RS 11019 K (SN 6) SK RS 11019 W SK RS 9022 K (SN 7) SK RS 9022 H (MK IV) SK RS 9022 W SK RS 11222 K (SN 7) SK RS 11222 K 01 (SK 7)	
57055	4 200 1017 01	Bearing, Wheel Hub ø100xø148x32,5/70,5	SK RS 6537-8 SK RS 6537-10 SK RS 9037-8 SK RS 9037-10	

Auger Nr.	OEM Nr.	Description	Model	Picture
57058	4 200 1019 00	Bearing, Wheel Hub ø82xø138x51,5+58	SK RB 9019 KI (SN 6) INTEGRAL SK RB 9019 WI INTEGRAL SK RB 9022 KI (SN 7) INTEGRAL SK RB 9022 WI INTEGRAL	
68105	4 200 0031 00	Bearing, Wheel Hub ø45xø100x38,5		
70785	4 200 0003 00	Bearing, Wheel Hub ø30xø62x17,5		
71874	4 200 1015 00 S	Bearing, Wheel Hub		
74756	4 200 0011 00	Bearing, Wheel Hub ø35xø80x23	ESN 4030 ESN 4030/12 EZN 4030 EZN 4030/12 EBN 3140 EBN 4040 ESN 4040	
57052	1 337 0040 00	Dust Cover, Wheel Hub ø66,5xø106x15	SK RS 9042 SK 500 plus SK RS 12242 SK RZ 6530 SK RZ 9030 SK RZ 11030 SK RZ 12030 SK RZ 12037 SK RZ 12242	
57053	1 092 2001 00	Dust Cover, Wheel Hub ø86xø128x12	SK RS 9042 SK 500 plus SK RS 12242 SK RZ 6530 SK RZ 9030 SK RZ 11030 SK RZ 12030 SK RZ 12037 SK RZ 12242 KRS 12242	

Auger Nr.	OEM Nr.	Description	Model	Picture
57054	1 092 2002 00	Dust Cover, Wheel Hub ø95xø142,5x9	SK RS 9042 SK 500 plus SK RS 12242 SK RZ 6530 SK RZ 9030 SK RZ 11030 SK RZ 12030 SK RZ 12037 SK RZ 12242	
57061	3 200 2001 51	Unit, Wheel Hub ø82x113,5/M18x1,5/ø168	SK RB 9019 K (SN 6) SK RB 9019 W SK RB 9022 K (SN 7) SK RB 9022 K 01 (SK 7) SK RB 9022 H (MK II/III) SK RB 9022 H (MK IV) SK RB 9022 H (Modul X) SK RB 9022 W SKRB 9019/9022	
57075	3 434 3650 00	Repair Kit, Wheel Hub ø82x113,5/M18x1,5/ø168	SK RB 9019 K (SN 6) SK RB 9019 W SK RB 9022 K (SN 7) SK RB 9022 K 01 (SK 7) SK RB 9022 H (MK II/III) SK RB 9022 H (MK IV) SK RB 9022 H (Modul X) SK RB 9022 W SKRB 9019/9022	
57063	3 434 3012 00	Repair Kit, Wheel Hub ø120xø175x29/61,5	SK RS 11019 K (SN 6) SK RS 11019 W SK RS 11222 K (SN 7) SK RS 11222 K 01 (SK 7) SK RS 11222 W SK RS 9019 K (SN 6) SK RS 9019 W SK RS 9022 H (MK IV) SK RS 9022 K (SN 7) SK RS 9022 W	
57066	3 434 3011 00	Repair Kit, Wheel Hub ø100xø148x32,5/70,5	SK RS 6537-8 SK RS 6537-10 SK RS 9037-8 SK RS 9037-10 SK RZ 9037-8 SK RZ 9037-10 SK RZ 11037-8	
57074	3 434 3018 00	Repair Kit, Wheel Hub ø82xø138x51,5+58	SK RB 9019 KI (SN 6) INTEGRAL SK RB 9019 WI INTEGRAL SK RB 9022 KI (SN 7) INTEGRAL SK RB 9022 KI 01 (SK 7) INTEGRAL SK RB 9022 WI INTEGRAL	
57065	3 434 3016 00	Repair Kit, Wheel Hub ø65xø120x41	KRS 12242 KRS 12242/18 SK RS 9030 SK RS 9042 SK 500 SK RS 9042 SK 500 plus SK RS 12242 SK RZ 6530 SK RZ 9030 SK RZ 11030	

Auger Nr.	OEM Nr.	Description	Model	Picture
57064	3 434 3623 00	Repair Kit, Wheel Hub ø120xø165x29	RSM 6542 RSM 9042 RSM 9042/20	
70671	3 434 3019 00	Repair Kit, Wheel Hub	S9-3718 S9-4218 S9-4220 S11-3720 S11-4218 S11-4220 SL9-3718 SL9-4218 SL11-4220	
70672	3 434 3021 00	Repair Kit, Wheel Hub	S7-3015 Z7-3015 Z9-3020 Z11-3020 Z11-3720 -8L Z11-3720 -10L ZL9-3020 ZL9-3720 ZL11-3020	
70668	3 434 3020 00	Repair Kit, Wheel Hub	B9-19K B9-22W B9-19W B9-22K01 BA9-22K01 BIL9-22K01 BINL9-22K01 BL9-22K01 BI9-22W	
57068	3 434 3014 01	Repair Kit, Wheel Hub ø142xø175,5x11,4	SK RS 9019 K (SN 6) SK RS 9019 W SK RS 11019 K (SN 6) SK RS 11019 W SK RS 9022 K (SN 7) SK RS 9022 H (MK IV) SK RS 9022 W SK RS 11222 K (SN 7) SK RS 11222 K 01 (SK 7)	
57067	3 434 3017 00	Repair Kit, Wheel Hub ø66/ø86/ø95	KRS 12242 KRS 12242/18 SK RS 9030 SK RS 9042 SK 500 SK RS 9042 SK 500 plus SK RS 12242 SK RZ 6530 SK RZ 9030	
70669	3 434 3023 00	Repair Kit, Wheel Hub	SK RB 9019 KI (SN 6) INTEGRAL SK RB 9019 WI INTEGRAL SK RB 9022 KI (SN 7) INTEGRAL SK RB 9022 WI INTEGRAL SK RB 9022 KI 01 (SK 7) INTE- GRAL	

Auger Nr.	OEM Nr.	Description	Model	Picture
70670	3 434 3024 00	Repair Kit, Wheel Hub	B9-19K B9-19W B9-22W B9-22K01 BA9-22K01 BI9-22K01 BI9-22W-6 BI9-22W BL9-22K01	
70673	3 434 3025 00	Repair Kit, Wheel Hub	S9-3718 S9-4218 S9-4220 S11-3720 S11-4218 S11-4220 SL9-3718 SL9-4218 SL11-4220	
57069	3 434 3013 00	Repair Kit, Wheel Hub ø126,5xø157x8,7	SK RS 6537-8 SK RS 6537-10 SK RS 9037-8 SK RS 9037-10 SK RZ 9037-8 SK RZ 9037-10 SK RZ 11037-8 SK RZ 11037-10	
54284	4 304 0093 00	Hub Cap ø131x37,5	SK RB 9019 K (SN 6) SK RB 9019 W SK RB 9022 K SK RB 9022 K (SK 7) SK RB 9022 W SK RB 9022 H SK RB 9022 H (MK IV)	
57062	4 304 0102 01 4 304 0102 00	Hub Cap ø151,3x52	SK RB 9019W Intradisc INTEGRAL SK RLB 9019W Intradisc INTEGRAL SK RB 9022K Intradisc INTEGRAL SK RLB 9022K Intradisc INTEGRAL Z9-4218 NG axle	
52360	1 304 0016 00	Hub Cap ø9x140/ø165x42,5	RBM 8442 / 8442/12 RLBM 8442 RLSM 8442 / 11242 RSM 6242-8 / 6242/12-10 / 8442 RZM 8442 / 8442-8 / 1130 SKRZT 12242 WRLZM-8 / 8130 / 8435-10 WRZM 6242 / 6242-8 / 8130 WRZM 8442-8 / 11030 / 11035-8	
52361	1 304 0046 01	Hub Cap ø9/185xø205x39,5	RSM 6542 / 9042 / 9042/20 RLSM 9042 / 9042/20	



Auger Nr.	OEM Nr.	Description	Model	Picture
54283	3 304 0086 00	Hub Cap ø150x66	SK RZ 6530 SK RS 9030 SK RZ 9030 SK RZ 11030 SK RZ 12030 SK RZ 12037 SK RS 9042 SK 500 KRS 12242	
55595	3 304 0072 00 4 304 0072 01	Hub Cap ø182x72	SKRS 9022 K (SN 7) SKRS 9022 H (MK IV) SKRS 9022 WSKRS 11222 K(SN7) SKRS 11222 K01(SK7) SKRS 11222 WSKRZ 9022 K(SN 7) SKRZ 9022 WSKRZ 11222 K(SN7) SKRZ 11222 K01(SK7)	
70663	1 304 0010 00	Hub Cap M135x3/SW130x64	KRS 14242 TRILEX RZM 14242 RZT 14242 RZM 13130	
70664	1 304 0019 00	Hub Cap M155x3/SW130x72	KRS 16242 TRILEX RZM 16242 RZT 16242	
52777	1 093 0005 00	Gasket, Hub Cap ø119xø158x0,8	RBM 8442 / 8442/12 RLBM 8442 RLSM 8442 / 11242 RSM 6242/12-8 / 6242/12-10 / 8442 RZM 8442 / 8442-8 / 11030 / 11242 WRLZM-8 / 8130 / 8435-10 / 11030 SKRZT 12242	
52778	1 093 0012 00	Gasket, Hub Cap ø165xø9/185x1	RSM 6542 RSM 9042 RSM 9042/20 RLSM 9042 RLSM 9042/20	
65585	1 303 1118 11	Stud 68/M22x1,5	SH11-22K01 SH11-22W SK RB 9019 K (SN 6) SK RB 9022 H (MK IV) SK RB 9022 K (SN 7) SK RB 9022 W SK RB 9022 WI INTEGRAL ZI11-22K01 ZI9-22K01	

Auger Nr.	OEM Nr.	Description	Model	Picture			
65587	1 303 1074 14	Stud 83/M22x1,5	S11-3720				
	1 303 1074 10		S9-3718				
	1 303 1074 11		SK RS 11019 K (SN 6)				
	1 303 1074 12		SK RS 11019 W SK RS 6537-8 SK RS 9019 K (SN 6) SK RS 9019 W SK RS 9037-8 SL9-3718				
65162	1 303 1075 12	Stud 93/M22x1,5	SK RZ 6530/9030				
	1 303 1075 11		SK RZ 9022 K (SN 7)				
	1 303 1075 10		SK RZ 9022 W SK RZ 9037-10 SK RZ 9042/11030 SK RZ 11037-10 SK RX 11222 K (SN 7) SK RZ 11242/12030 SK RZ 12037				
	65589		1 303 1045 11		Stud 97/M22x1,5/M22x1,5	KRS 14242	
			1 303 1045 10			RSM 6242/12-10	
			1 303 1048 10				
			1 303 1145 11				
65580	1 303 1040 11	Stud 112/M22x1,5/M22x1,5	KRZ 14242				
	1 303 1040 10		RZM 11030				
	1 303 1049 10		RZM 11242 RZM 12242 RZM 8442 WRLZM 11030 WRZLM 8435-10 WRZM 11030 WRZM 11035-10				
	65630		1 303 1008 11		Stud 100/M22x2/M22x2	EBN 4540-10	
			1 303 1008 10				
	65621		1 303 1028 11		Stud 111/M22x2/M22x2	KRZ 16242	
1 303 1028 10							
1 303 1028 00							
65627	1 303 1013 10	Stud 107/M22x2/M20x1,5					

Auger Nr.	OEM Nr.	Description	Model	Picture
65628	4 342 0008 10	Nut, Stud, Self-Locking M20x1,5		
65581	4 342 0019 10 4 342 0019 00	Nut, Stud, Self-Locking M22x1,5	KRS 14242 KRZ 14242 RBM 8442 RBM 8442/12 RLBM 8442 RSM 8442-8 RZM 11030 RZM 11242 WRZM 8442	
65625	4 342 0020 10	Nut, Stud M22x1,5	AR211 AR212 AR213 AR 311H/EM311H AR314H/EO314H	
65564	4 247 3012 01 4 247 3012 00	Nut, Stud M22x1,5	B9-22W BA9-22K01 BI9-22K01 RBLM 8442 RBM 8442 S11-4218 S11-4220 S7-3015 SK RZ 11222 K 01 (SK 7) WRZM 8442	
65708	2 247 3010 01	Nut, Stud M22x1,5		
65623	4 342 0009 10	Nut, Stud, Self-Locking M22x2	EBN 4540-10 KRZ 16242	
65622	4 342 0015 10 4 342 0015 00	Nut, Stud M22x2	EBN 4540-10 KRZ 16242	

Auger Nr.	OEM Nr.	Description	Model	Picture
65570	4 141 1002 00	Rondela, Stud ø20,5	EBN 4040 EBN 4530 EBN 4535 EBN 4540 EBN 5535 ESN 4040 ESN 4540	
65571	4 141 1003 00	Rondela, Stud ø22,5	EBN 4540-10	
65572	4 331 7006 00	Rondela, Stud ø22		
65584	3 302 1156 00	Repair Kit, Stud 68/M22x1,5	BI9-22K01 BI9-22W BI9-22W-6 BINL9-22K01 SI11-22K01 SI9-22W SK RB 9019 K (SN 6) Z11-22K01	
65586	3 302 1078 00	Repair Kit, Stud 83/M22x1,5	S11-3720 S9-3718 SK RS 11019 K (SN 6) SK RS 11019 W SK RS 6537-8 SK RS 9019 K (SN 6) SK RS 9019 W SK RS 9037-8 SL9-3718	
65624	3 302 1077 00	Repair Kit, Stud 83/M22x1,5		
65583	3 302 1076 00	Repair Kit, Stud 93/M22x1,5	RZM 13130 SK RS K 01 (SK 7) SK RZ 11222 K (SN 7) SK RZ 11222 W SK RZ 9022 K (SN 7) SK RZ 9022 W SK RZ K 01 (SK 7) Z11-3020 Z11-4218	

Auger Nr.	OEM Nr.	Description	Model	Picture
65588	3 302 1045 00	Repair Kit, Stud 97/M22x1,5/M22x1,5	KRS 14242 RLSM 11242 RLSM 8442 RSM 11242 RSM 6242/12-10 RSM 8442	
65579	3 302 1040 00	Repair Kit, Stud 112/M22x1,5/M22x1,5	RZM 12242 RZM 16242 WRZM 6242 WRZM 8442 WRZM 11242 WRZM 8435-10 WRZM 11035-10 WRLZM 11035-10 WRLZM 11030 KRZ 14242	
65629	3 302 1008 00	Repair Kit, Stud 100/M22x2/M22x2	EBN 4540-10	
65620	3 302 1028 00	Repair Kit, Stud 111/M22x2/M22x2	KRZ 16242	
65626	3 302 1013 00	Repair Kit, Stud 107/M22x2/M20x1,5		

Auger Nr.	OEM Nr.	Description	Model	Picture
10003	8 089 0352 50	Ball Joint L: 115 M30x1,5 RHT		
10065	2 205 0004 00	Ball Joint L: 135 M38x1,5 RHT	SK RLB 9019 IO/IU SK RLB 9022 SK RLB 9022 IO/IU SK RLS 9037 SK RLS 9042 SK RLS 9042/20 SK RLS 11242 SK RLZ 9030 SK RLZ 11030	

**SPARE PARTS FOR
COMMERCIAL VEHICLES**

SCHMITZ

we keep your business
ON THE MOVE



www.augerautotechnik.de




Auger
GERMANY





Auger Nr.	OEM Nr.	Description	Model	Picture
21010	-	Service Brake Chamber, for Drum Brake		
		M16/120,7x112,5/297,5x164		
		T16 STR 75		
21011	051007	Service Brake Chamber, for Drum Brake, With Repair Kit		
		M16/120,7x112,5/339,5x164		
		T16 STR 75		
21012	-	Service Brake Chamber, for Drum Brake		
		M16/120,7x113/298x174		
		T20 STR 75		
21013	051009	Service Brake Chamber, for Drum Brake, With Repair Kit		
		M16/120,7x113/340x174		
		T20 STR 75		
21014	-	Service Brake Chamber, for Drum Brake		
		M16/120,7x112,5/297,5x186		
		T24 STR 75		
21016	-	Service Brake Chamber, for Drum Brake		
		M16/120,7x117,5/302,5x208		
		T30 STR 75		

Auger Nr.	OEM Nr.	Description	Model	Picture
21017	051017	Service Brake Chamber, for Drum Brake, with Repair Kit M16/120,7x117,5/344,5x208 T30 STR 75		
21018	-	Double Diaphragm Brake Chamber, for Drum Brake M16/120,7x274,5/459,5x208 T24-30 STR 75/75		
71932	056718 050019	Sensor, ABS		
74981	051368	Sensor, ABS L: 5100 mm		
74982	051214	Sensor, ABS L: 3800 mm		

Auger Nr.	OEM Nr.	Description	Model	Picture
52108	750841	Rubber Bushing, Spring ø50xø100,5x130		
52750	028158BHC	Rubber Bushing, Spring ø30xø69x102		
A 34661	750208	Air Spring ø150,8xø240x390		
A 34662	750209	Air Spring ø198,1xø300x360		
A 34719	750215	Air Spring ø198,1xø300x530		
A 34728	750212	Air Spring ø198,1xø290x470		

Auger Nr.	OEM Nr.	Description	Model	Picture
AU 344028	-	Air Spring		
AU 344028-K	015323	Air Spring		
AU 349285-K	017685	Air Spring		
AU 344158-KP	750999	Air Spring ø275x410		
20123	015323 S	Piston, Air Spring, for AU 344028-K ø260x178		
20186	016508 912565	Shock Absorber ø16x275/385		

Auger Nr.	OEM Nr.	Description	Model	Picture
20205	1041843 013250	Shock Absorber, Rear&Front ø24x329/494		
20207	013774 016270	Shock Absorber, Rear		
20208	014050	Shock Absorber, Rear		

Auger Nr.	OEM Nr.	Description	Model	Picture
57013	014440	Bearing, Wheel Hub ø90xø150x45		
57014	010278 015052	Bearing, Wheel Hub ø65xø120x41		
57023	013682	Seal Ring, Wheel Hub ø114,5xø138,7x11,5		
57056	016405	Seal Ring, Wheel Hub ø126,85xø153/ø157x8.7		

Auger Nr.	OEM Nr.	Description	Model	Picture
21900	050457	Air Tank ø206x357/M22x1,5 / Capacity:10 lt		
21905	050458	Air Tank ø276x747/M22x1,5 / Capacity:40 lt		
21909	050460	Air Tank ø396x567/M22x1,5 / Capacity:60 lt		
21910	050461	Air Tank ø396x732/M22x1,5 / Capacity:80 lt		
21911	050462	Air Tank ø396x902/M22x1,5 / Capacity:100 lt		

**SPARE PARTS FOR
COMMERCIAL VEHICLES**

SMB


we keep your business
ON THE MOVE















www.augerautotechnik.de

Auger
GERMANY

Auger Nr.	OEM Nr.	Description	Model	Picture
31218	MO 03176	Brake Drum		
31219	MO 06166	Brake Drum		
65422	M 006204	Brake Shoe, Brake Drum, Unlined ø406x178mm		
65423	M 006093	Brake Shoe, Brake Drum, Unlined ø406x203mm		
52921	M 002866	Pin, Brake Shoe ø31,7x70		
52368	M 002971	Roller, Brake Shoe ø19/ø31,7x55,5		

Auger Nr.	OEM Nr.	Description	Model	Picture
53848	M 007371	Roller, Brake Shoe ø19/ø25x57		
54831	M 002693	Lock Plate, Brake Shoe ø19,5x52,5		
52920	M 002874	Spring, Brake Shoe ø32x204		
53849	M 007150	Spring, Brake Shoe ø28x176		
52369	M 003001	Spring Pin, Brake Shoe ø6,3x70		
52782	M 009279	Repair Kit, Brake Shoe ø19/ø31,75x55,5/70		

Auger Nr.	OEM Nr.	Description	Model	Picture
54413	M 010552	Repair Kit, Brake Shoe ø19/ø25x57		
52216	-	Retainer, Brake Cam Shaft for 53841 ø70x13		
52367	M 003060	Retainer, Brake Cam Shaft ø70x13		
70681	M 023387	Bushing, Brake Cam Shaft ø38xø42x45		
53165	M 010676	Repair Kit, Brake Cam Shaft ø37,5/ø40xø70x509		
53841	M 050147	Repair Kit, Brake Cam Shaft ø38/ø40xø70x456		






Auger Nr.	OEM Nr.	Description	Model	Picture
58326	M 094527 M 071101	Brake Slack Adjuster, Automatic ø14x205/153/140/127/115x 60° / Saddle Type		
58370	M 050082	Brake Slack Adjuster, Automatic ø14x215/153/129/105x130° / Saddle Type		
68908	Haldex : 80023D	Brake Slack Adjuster Automatic ø14x105/129/153/215 / S-ABA		
31217	M 200135	Brake Disc		
52272	M 010544	Brake Dust Cover ø180xø463x82		
52273	M 007363 M 007355	Brake Dust Cover ø182xø460x74		

Auger Nr.	OEM Nr.	Description	Model	Picture
54676	M 046565 M 046573	Brake Dust Cover ø150xø403x61		
54677	M 002904 M 002912	Brake Dust Cover ø150xø403x61		
54678	M 009309	Brake Dust Cover Kit ø128xø303x22		
54679	M 051275	Brake Dust Cover Kit ø150xø403x61		
54680	M 009260	Brake Dust Cover Kit ø182xø460x74		

Auger Nr.	OEM Nr.	Description	Model	Picture
52217	M 001502	Rubber Bushing, Spring ø30xø68x104		
AU 344156-K05	M 001472	Air Spring ø300x380		
AU 344157-KP08	M 078580	Air Spring ø270x400		
AU 344157-KP10	M 060924	Air Spring ø270x400		
AU 344159-K05	M 001782	Air Spring ø300x400		
AU 344159-KP09	M 001774	Air Spring ø280x400		

Auger Nr.	OEM Nr.	Description	Model	Picture
54411	M 002564	Axle Nut 25xSW120 M88x2 RHT		
54412	M 007916	Axle Nut 25xSW120 M88x2 LHT		
68151	M 006050 M 007851	Wheel Hub, Only Casting Body		
75336	M 006050 S M 007851 S	Wheel Hub, With Bearing		  Sample
75337	M 006077	Wheel Hub, Only Casting Body		 
75338	M 006077 S	Wheel Hub, With Bearing		  Sample

Auger Nr.	OEM Nr.	Description	Model	Picture
75339	M 069034	Wheel Hub, Only Casting Body		
55805	M 100500	Repair Kit, Wheel Hub $\varnothing 107,5 \times \varnothing 153 / \varnothing 184 \times 20$		
55806	M 100845	Repair Kit, Wheel Hub $\varnothing 107,5 \times \varnothing 153 / \varnothing 185 \times 20$		
55807	M 100888	Repair Kit, Wheel Hub $\varnothing 90 \times \varnothing 147 \times 40$		
55808	M 100861	Repair Kit, Wheel Hub $\varnothing 90 \times \varnothing 147 \times 40$		
53847	M 008892	Seal Ring, Wheel Hub $\varnothing 108 \times \varnothing 134 / \varnothing 153 \times 30$		

Auger Nr.	OEM Nr.	Description	Model	Picture
69385	M 003125	Seal Ring, Wheel Hub ø108xø152,6/ø185x19 / NBR		
65170	M 003133	Stud 74/M22x1,5		
65714	M 006891	Stud 89/M22x1,5		
68153	M 069123 M 069131	Stud M22x1,5/88		
65708	M 003141	Nut, Stud M22x1,5		

**SPARE PARTS FOR
COMMERCIAL VEHICLES**

TRAILOR

we keep your business
ON THE MOVE









www.augerautotechnik.de








Auger
GERMANY

Auger Nr.	OEM Nr.	Description	Model	Picture
31197	6503540 J	Brake Drum		
31198	6502807 M	Brake Drum		
31199	6498900 W	Brake Drum		
31200	6502806 L	Brake Drum		
31201	6502796 E	Brake Drum		
65422	6504773 S	Brake Shoe, Brake Drum, Unlined ø406x178mm		
65428	1649000	Brake Shoe, Brake Drum, Unlined ø406x178mm		

Auger Nr.	OEM Nr.	Description	Model	Picture
65423	6504787 A	Brake Shoe, Brake Drum, Unlined ø406x203mm		
65427	1674000	Brake Shoe, Brake Drum, Unlined ø406x203mm		
52921	1652010 R	Pin, Brake Shoe ø31,7x70		
53752	6502382 B	Pin, Brake Shoe ø31,7x88		
52910	1650000 S	Bushing, Brake Shoe ø32xø35x36,5		
52368	1642000 S	Roller, Brake Shoe ø19/ø31,7x55,5		
54831	6504774 T	Lock Plate, Brake Shoe ø19,5x52,5		
52775	6501811 Y	Spring, Brake Shoe ø29x168		

Auger Nr.	OEM Nr.	Description	Model	Picture
52891	1643000 C	Spring, Brake Shoe ø28,5x202		
53849	7000107 D	Spring, Brake Shoe ø28x176		
52369	1646000 J	Spring Pin, Brake Shoe ø6,3x70		
53756	6503338 F	Repair Kit, Brake Shoe, Single ø19/ø31.75x55.5/88		
53757	6503338 FS	Repair Kit, Brake Shoe, Double ø19/ø31,75x55,5/88 <i>Pin: 53752</i> <i>Roller: 52368</i> <i>Spring: 52775</i>		
53758	6502102 W	Repair Kit, Brake Shoe, Single ø19/ø31.75x55.5/70		
53759	6502102 WS	Repair Kit, Brake Shoe, Double ø19/ø31,75x55,5/70 <i>Pin: 52921</i> <i>Roller: 52368</i> <i>Bushing: 52910</i>		
53760	6504775 W	Repair Kit, Brake Shoe, Single ø19/ø31.75x55.5/70		

Auger Nr.	OEM Nr.	Description	Model	Picture
53761	6504775 WS	Repair Kit, Brake Shoe, Double ø19/ø31,75x55,5/70 <i>Pin: 52921</i> <i>Roller: 52368</i> <i>Spring: 52891</i> <i>Spring Pin: 54916</i>		
53763	-	Repair Kit, Brake Shoe ø19/ø31,75x55,5/70 <i>Pin: 52921</i> <i>Roller: 52368</i> <i>Spring: 52891</i> <i>Spring Pin: 54916</i>		
53767	6502101 T	Repair Kit, Brake Shoe M8x1,25/25		
53771	-	Repair Kit, Brake Shoe, Single ø19/ø31.75x55.5/88 <i>Pin: 53752</i> <i>Roller: 52368</i> <i>Spring: 52775</i> <i>Bushing: 52910</i>		
53772	-	Repair Kit, Brake Shoe, Double ø19/ø31.75x55.5/88 <i>Pin: 53752</i> <i>Roller: 52368</i> <i>Spring: 52775</i> <i>Bushing: 52910</i>		
53773	-	Repair Kit, Brake Shoe, Single ø19/ø31.75x55.5/88 <i>Pin: 53752</i> <i>Roller: 52368</i> <i>Spring: 52891</i> <i>Bushing: 52910</i>		
53774	-	Repair Kit, Brake Shoe, Double ø19/ø31.75x55.5/88 <i>Pin: 53752</i> <i>Roller: 52368</i> <i>Spring: 52891</i> <i>Bushing: 52910</i>		







Auger Nr.	OEM Nr.	Description	Model	Picture
52216	1669000 G	Retainer, Brake Cam Shaft ø70x13		
52367	-	Retainer, Brake Cam Shaft for 53165, 53762 and 54675 ø70x13		
52210	1639000 W	Spherical Bearing, Brake Cam Shaft ø38xø70x63		
52211	1656000 E	Bushing, Brake Cam Shaft ø38xø48x22,5		
52212	1655000 W	Bushing, Brake Cam Shaft ø38xø48x22,5		
52206	6503721 R	Bushing, Brake Cam Shaft ø38,2xø42x44,8		
53753	6502103 XS	Repair Kit, Brake Cam Shaft, Single ø38xø70x63		

Auger Nr.	OEM Nr.	Description	Model	Picture
52275	6502103 X	Repair Kit, Brake Cam Shaft, Double ø38xø70x63		
52276	6503723 T	Repair Kit, Brake Cam Shaft, Double ø38xø70x63		
53754	6503723 TS	Repair Kit, Brake Cam Shaft, Single ø38xø70x63		
53762	-	Repair Kit, Brake Cam Shaft ø38xø70x63 <i>Bushing: 52206</i> <i>Retainer: 52367</i> <i>Spherical Bearing: 52210</i>		
54675	-	Repair Kit, Brake Cam Shaft ø38xø70x63 <i>Bushing: 52247</i> <i>Retainer: 52367</i> <i>Spherical Bearing: 52210</i>		
53841	M 050147	Repair Kit, Brake Cam Shaft ø38/ø40xø70x456		
53165	M 010676	Repair Kit, Brake Cam Shaft ø37,5/ø40xø70x509		

Auger Nr.	OEM Nr.	Description	Model	Picture
58289	T0017649 Z	Brake Slack Adjuster Automatic ø14x210/180/150/125x130° / Saddle Type		
58370	7000327 W	Brake Slack Adjuster Automatic ø14x215/153/129/105x130° / Saddle Type		
52271	6502810 F	Brake Dust Cover ø227,5xø463x66		
52272	6504785 Y	Brake Dust Cover ø180xø463x82		
52273	6504771 P	Brake Dust Cover ø182xø460x74		
53751	6502809 R	Brake Dust Cover ø206xø468x76		

Auger Nr.	OEM Nr.	Description	Model	Picture
52217	6504210 X	Rubber Bushing, Spring ø30xø68x104		
53745	6115000 X	Rubber Bushing, Spring ø19/35xø85,5x113		
53746	6127000 M	Rubber Bushing, Spring ø25xø48,5x76		
53747	2210000 Z	Rubber Bushing, Spring ø32xø64x55		
54029	6113300 A	Bolt, Spring 164/M16x1,5		
54043	6502176 T	Bolt, Spring 140/M24x3		

Auger Nr.	OEM Nr.	Description	Model	Picture
54044	6504212 Z	Bolt, Spring 200/M30x3,5		
54048	2033000 M	Bolt, Spring 150/M20x2,5		
53299	6401000 J	Nut, Spring 20/M20x2,5		
54049	6114000 K	Nut, Spring 16/M16x1,5		
54050	-	Nut, Spring, for 53764 and 53770 24/M24x3		
54051	-	Nut, Spring, Self-Locking, for 53766 27,1/M30x3,5		

Auger Nr.	OEM Nr.	Description	Model	Picture
53769	-	Repair Kit, Spring M20x2,5/150 <i>Bolt: 54048</i> <i>Nut: 53299</i>		
53770	-	Repair Kit, Spring M24x3/140 <i>Bolt: 54043</i> <i>Nut: 54050</i>		
53755	-	Repair Kit, Spring ø19/35xø85,5x113 <i>Rubber Bushing: 53745</i> <i>Bolt: 54029</i> <i>Nut: 54049</i>		
53766	-	Repair Kit, Spring ø30xø68x104 <i>Rubber Bushing: 52217</i> <i>Bolt: 54044</i> <i>Nut: 54051</i>		
53764	6502105 Z	Repair Kit, Spring, Single ø25xø48,5x76		
53765	6502105 ZS	Repair Kit, Spring, Double ø25xø48,5x76		

Auger Nr.	OEM Nr.	Description	Model	Picture
53768	2211015 T	Repair Kit, Spring ø32xø64x55		
AU 34810-K	6504646 G	Air Spring ø305x340		
AU 34813-K	65022347 Y 65023482	Air Spring ø305x420		
20122	6504646G S	Piston, Air Spring, for AU 34810-K ø260x140		
20123	0036158E S 65022347Y S 65023482 S	Piston, Air Spring, for AU 34813-K ø260x178		
20215	7000057 L	Shock Absorber, Rear ø20x320/470		

Auger Nr.	OEM Nr.	Description	Model	Picture
53749	6502801 E	Axle Nut, Left M60x2 LHT		
53750	6502802 F	Axle Nut, Right M60x2 RHT		
54004	6502188 Z	Axle Nut M56x2/SW85		
68149	6502795 D 0018321 C	Wheel Hub, Only Casting Body ø130/ø145x173		
68151	7000094 T	Wheel Hub, Only Casting Body		
75336	7000094 TS	Wheel Hub, With Bearing		 Sample

Auger Nr.	OEM Nr.	Description	Model	Picture
75337	7000096 X	Wheel Hub, Only Casting Body		
75338	7000096 XS	Wheel Hub, With Bearing		
57014	6502196 Z	Bearing, Wheel Hub ø65xø120x41		
70288	6015000 D	Bearing, Wheel Hub ø80xø130x35		
55801	6502085 P	Seal Ring, Wheel Hub, Stefa Type ø110xø146x16,5		
55802	6502085 P S	Seal Ring, Wheel Hub, Stemco Type ø110,8xø146x24,5		

NEW

NEW

Sample

Auger Nr.	OEM Nr.	Description	Model	Picture
53748	6503954 M 6024000 P	Hub Cab ø10/ø152,5/ø173x58		
65170	6502798 G	Stud 74/M22x1,5		
65714	6502799 J	Stud 90/M22x1,5		
65708	6497000 L 7000016 A	Nut, Stud M22x1,5		
70813	6013000 G	Nut, Stud M22x1,5		

**SPARE PARTS FOR
COMMERCIAL VEHICLES**








YORK

we keep your business
ON THE MOVE









www.augerautotechnik.de







Auger
GERMANY

Auger Nr.	OEM Nr.	Description	Model	Picture
52921	-	Pin, Brake Shoe, for 53823, 53929 and 53930 ø31,7x70		
52910	501787	Bushing, Brake Shoe ø32xø35x36,5		
53817	500356	Roller, Brake Shoe ø19xø28,5x60		
53779	503320	Spring, Brake Shoe ø29,5x201		
53818	506498	Spring, Brake Shoe ø37,5x171		
53820	786228	Spring, Brake Shoe ø20x154		
52369	500372	Spring Pin, Brake Shoe ø6,3x70		


Auger Nr.	OEM Nr.	Description	Model	Picture
53823	-	Repair Kit, Brake Shoe ø19/ø28,5x60 <i>Pin: 52921</i> <i>Roller: 53817</i> <i>Bushing: 52910</i> <i>Spring: 53818</i> <i>Spring Pin: 54916</i>		
53929	-	Repair Kit, Brake Shoe ø19/ø28,5x60 <i>Pin: 52921</i> <i>Roller: 53817</i> <i>Bushing: 52910</i> <i>Spring: 53779-53820</i> <i>Spring Pin: 54916</i>		
53930	-	Repair Kit, Brake Shoe ø19/ø28,5x60 <i>Pin: 52921</i> <i>Roller: 53817</i> <i>Bushing: 52910</i> <i>Spring: 53779</i> <i>Spring Pin: 54916</i>		
53158	500363	Retainer, Brake Cam Shaft ø70x11,5		
53816	501574	Retainer, Brake Cam Shaft ø70x11,5		
52210	500362	Spherical Bearing, Brake Cam Shaft ø38xø70x63		

Auger Nr.	OEM Nr.	Description	Model	Picture
53157	786123	Bushing, Brake Cam Shaft ø39xø48x45		
53159	503087	Bushing, Brake Cam Shaft ø38,5xø47,5x45		
53819	502765	Bushing, Brake Cam Shaft ø39xø48x46		
53160	534601	Repair Kit, Brake Cam Shaft ø38xø70x63		
53161	-	Repair Kit, Brake Cam Shaft ø38xø70x63 <i>Bushing: 53159 Retainer: 53158 Spherical Bearing: 52210</i>		
53821	-	Repair Kit, Brake Cam Shaft ø38xø70x63 <i>Bushing: 53159 Retainer: 53816 Spherical Bearing: 52210</i>		

Auger Nr.	OEM Nr.	Description	Model	Picture
53822	-	Repair Kit, Brake Cam Shaft ø38xø70x63 <i>Bushing: 53157</i> <i>Retainer: 53816</i> <i>Spherical Bearing: 52210</i>		
53824	-	Repair Kit, Brake Cam Shaft ø38xø70x63 <i>Bushing: 53819</i> <i>Retainer: 53158</i> <i>Spherical Bearing: 52210</i>		
58341	-	Brake Slack Adjuster Automatic 140x110° / Bent		
58342	-	Brake Slack Adjuster Automatic 140x110° / Bent		
53814	500808/9	Brake Dust Cover ø132,5xø430x16		
53815	501875/6	Brake Dust Cover ø132,5xø466x16		

Auger Nr.	OEM Nr.	Description	Model	Picture
52217	506242	Rubber Bushing, Spring ø30xø68x104		
52251	500958	Rubber Bushing, Spring ø51xø79x106		
52253	503624	Rubber Bushing, Spring ø41,5xø70/ø89x112,5		
52279	770701	Rubber Bushing, Spring ø32xø55,5x58,5		
52266	-	Repair Kit, Spring ø51xø79x106 <i>Rubber Bushing: 52251</i>		
AU 34810K	785168	Air Spring ø305x340		

Auger Nr.	OEM Nr.	Description	Model	Picture
AU 34813-K	785170 505859	Air Spring ø305x420		
AU 340081-K	HS 251087	Air Spring ø290x410		
AU 344156-KP	HA 10000 1	Air Spring ø300x380		
20122	785168 S	Piston, Air Spring, for AU 34810-K ø260x140		
20123	785170 S	Piston, Air Spring, for AU 34813-K ø260x178		
20213	508571	Shock Absorber, Rear&Front		

Auger Nr.	OEM Nr.	Description	Model	Picture
54419	502461 S 502462 S	Repair Kit, Axle 16G-3/8"		

**SPARE PARTS FOR
COMMERCIAL VEHICLES**

KÖGEL

we keep your business
ON THE MOVE




www.augerautotechnik.de

Auger
GERMANY

Auger Nr.	OEM Nr.	Description	Model	Picture
21004	-	Service Brake Chamber M16/120,7x97,5/140,5x164 T16 STR 57		
21005	334652	Service Brake Chamber, for Disc Brake, With Repair Kit M16/120,7x97,5/140,5x164 T16 STR 57		
21006	-	Service Brake Chamber M16/120,7x105/164x174 T20 STR 64		
21007	337900	Service Brake Chamber, for Disc Brake, With Repair Kit M16/120,7x105/164x174 T20 STR 64		
21008	-	Service Brake Chamber M16/120,7x103/160x186 T24 STR 64		
21009	337902	Service Brake Chamber for Disc Brake, With Repair Kit M16/120,7x103/160x186 T24 STR 64		
21010	-	Service Brake Chamber M16/120,7x112,5/297,5x164 T16 STR 75		

Auger Nr.	OEM Nr.	Description	Model	Picture
21011	79537	Service Brake Chamber, for Drum Brake, With Repair Kit	M16/120,7x112,5/339,5x164 T16 STR 75	
21012	175207	Service Brake Chamber	M16/120,7x113/298x174 T20 STR 75	
21013	175202 79302	Service Brake Chamber, for Drum Brake, With Repair Kit	M16/120,7x113/340x174 T20 STR 75	
21016	-	Service Brake Chamber	M16/120,7x117,5/302,5x208 T30 STR 75	
21017	175204 79545	Service Brake Chamber, for Drum Brake, With Repair Kit	M16/120,7x117,5/344,5x208 T30 STR 75	
21014	-	Service Brake Chamber	M16/120,7x112,5/297,5x186 T24 STR 75	
21018	-	Double Diaphragm Brake Chamber	M16/120,7x274,5/459,5x208 T24-30 STR 75/75	

Auger Nr.	OEM Nr.	Description	Model	Picture
21020	-	Double Diaphragm Brake Chamber M16/120,7x271,5/456,5x208 T30-30 STR 75/75		
21021	343320	Double Diaphragm Brake Chamber, for Drum Brake, With Repair Kit M16/120,7x271,5/498,5x208 T30-30 STR 75/75		
71932	80376	Sensor, ABS		
71934	335665	Sensor, ABS L: 1000 mm		
74966	650053	Sensor, ABS L: 350 mm		
74981	330419	Sensor, ABS L: 5100 mm		
74983	330417	Sensor, ABS L: 4000 mm		

Auger Nr.	OEM Nr.	Description	Model	Picture
74498	339077	Solenoid Valve, Air Suspension, ECAS Single		
75755	337323	Levelling Valve		
75760	324727 324722	Levelling Valve		

**SPARE PARTS FOR
COMMERCIAL VEHICLES**

KRONE

we keep your business
ON THE MOVE



www.augerautotechnik.de

Auger
GERMANY

Auger Nr.	OEM Nr.	Description	Model	Picture
21004	-	Service Brake Chamber M16/120,7x97,5/140,5x164 T16 STR 57		 
21005	5812866 58128660	Service Brake Chamber for Disc Brake, With Repair Kit M16/120,7x97,5/140,5x164 T16 STR 57		 
21010	0945157	Service Brake Chamber M16/120,7x112,5/297,5x164 T16 STR 75		 
21011	945157	Service Brake Chamber for Drum Brake, With Repair Kit M16/120,7x112,5/339,5x164 T16 STR 75		 
21012	0945154	Service Brake Chamber M16/120,7x113/298x174 T20 STR 75		 
21013	945154	Service Brake Chamber for Drum Brake, With Repair Kit M16/120,7x113/340x174 T20 STR 75		 
21016	-	Service Brake Chamber M16/120,7x117,5/302,5x208 T30 STR 75		 

Auger Nr.	OEM Nr.	Description	Model	Picture
21017	945152	Service Brake Chamber for Drum Brake, With Repair Kit	M16/120,7x117,5/344,5x208 T30 STR 75	
21014	-	Service Brake Chamber	M16/120,7x112,5/297,5x186 T24 STR 75	
21018	-	Double Diaphragm Brake Chamber	M16/120,7x274,5/459,5x208 T24-30 STR 75/75	
21020	-	Double Diaphragm Brake Chamber	M16/120,7x271,5/456,5x208 T30-30 STR 75/75	
21021	-	Double Diaphragm Brake Chamber, for Drum Brake, With Repair Kit	M16/120,7x271,5/498,5x208 T30-30 STR 75/75	
71934	5807884	Sensor, ABS L: 1000 mm		
74981	5811089	Sensor, ABS L: 5100 mm		
74982	5811313 58113130	Sensor, ABS L: 3800 mm		

Auger Nr.	OEM Nr.	Description	Model	Picture
74498	5058206720	Solenoid Valve, Air Suspension, ECAS Single		
75755	505813397 5058133970 5813397	Levelling Valve		
75760	5058104930 5810493 58104930	Levelling Valve		
75761	515005712	Levelling Valve		